

# **Bri-Mar Manufacturing LLC**

## MODEL FLATBED TRAILERS



### **WARNING**

This User's Manual contains safety information and instructions for your trailer.

You must read this manual before loading or towing your trailer.

You must follow all safety precautions and instructions.

Bri-Mar Manufacturing LLC  
1080 South Main Street  
Chambersburg, PA 17201  
1-800-732-5845 Phone  
1-717-263-6479 Facsimile  
Revised January 2008

Please pay particular attention to the boxes throughout this manual highlighting certain caution (yellow), warning (orange) and danger (red) situations.

Table of Contents  
FLATBED TRAILERS

<b>1</b>	<b>INTRODUCTION / GENERAL INFORMATION</b>	<b>1</b>
1.1	TRAILER MODELS	1
1.2	BREAKING-IN A NEW TRAILER	1
1.2.1	<i>Retighten Lug Nuts at First 10, 25 &amp; 50 Miles</i>	1
1.2.2	<i>Adjust Brake Shoes at First 200 Miles</i>	2
1.2.3	<i>Synchronizing the Brake Systems</i>	2
1.2.4	<i>Tire Pressure</i>	3
1.3	WARRANTY	3
<b>2</b>	<b>GENERAL SAFETY INFORMATION</b>	<b>5</b>
2.1	SAFETY ALERT SYMBOLS AND SIGNAL WORDS	5
2.2	MAJOR HAZARDS	6
2.2.1	<i>Improper Sizing of the Trailer to the Tow Vehicle</i>	6
2.2.2	<i>Driving Too Fast</i>	7
2.2.3	<i>Failure to Adjust Driving Behavior When Towing a Trailer</i>	7
2.2.4	<i>Trailer Not Properly Coupled to the Hitch</i>	8
2.2.5	<i>Proper Use of Safety Chains</i>	9
2.2.6	<i>Proper Connection of Breakaway Brake</i>	9
2.2.7	<i>Mismatch of Trailer and Hitch</i>	10
2.2.8	<i>Unsafe Tire, Lug Nuts or Wheels</i>	10
2.2.9	<i>Improper Loading</i>	12
2.2.10	<i>Unsafe Load Distribution</i>	13
2.2.11	<i>Shifting Cargo</i>	14
2.2.12	<i>Inappropriate Cargo</i>	15
2.2.13	<i>Inoperable Brakes, Lights or Mirrors</i>	15
2.2.14	<i>Hazards From Modifying Your Trailer</i>	16
2.2.15	<i>Hazards from Accessories</i>	17
2.2.15.1	<i>Battery and Charger</i>	17
2.2.15.2	<i>DC Hydraulic Power Unit</i>	18
2.2.16	<i>Safety Warning Labels on Your Trailer</i>	19
2.2.17	<i>Trailer Towing Guide</i>	22
2.2.18	<i>Safe Trailer Towing Guidelines</i>	23
2.2.19	<i>Reporting Safety Defects</i>	24
<b>3</b>	<b>TIRE SAFETY INFORMATION</b>	<b>25</b>
3.1	TRAILER TIRE INFORMATION	26
3.2	STEPS FOR DETERMINING CORRECT LOAD LIMIT – TRAILER	27
3.2.1	<i>Trailers 10,000 Pounds GVWR or Less</i>	29
3.2.2	<i>Trailers Over 10,000 Pounds GVWR</i>	29
3.3	STEPS FOR DETERMINING CORRECT LOAD LIMIT – TOW VEHICLE	30
3.4	GLOSSARY OF TIRE TERMINOLOGY	30

# Table of Contents

## FLATBED TRAILERS

3.5	TIRE SAFETY - EVERYTHING RIDES ON IT.....	37
3.5.1	<i>Safety First—Basic Tire Maintenance</i> .....	38
3.5.2	<i>Finding Your Vehicle's Recommended Tire Pressure and Load Limits</i> .....	38
3.5.3	<i>Understanding Tire Pressure and Load Limits</i> .....	39
3.5.4	<i>Checking Tire Pressure</i> .....	39
3.5.5	<i>Steps for Maintaining Proper Tire Pressure</i> .....	40
3.5.6	<i>Tire Size</i> .....	40
3.5.7	<i>Tire Tread</i> .....	41
3.5.8	<i>Tire Balance and Wheel Alignment</i> .....	41
3.5.9	<i>Tire Repair</i> .....	41
3.5.10	<i>Tire Fundamentals</i> .....	41
3.5.10.1	Information on Passenger Vehicle Tires .....	42
3.5.10.2	UTQGS Information .....	44
3.5.10.3	Additional Information on Light Truck Tires .....	45
3.5.11	<i>Tire Safety Tips</i> .....	46
4	<b>COUPLING TO THE TOW VEHICLE</b> .....	47
4.1	USE AN ADEQUATE TOW VEHICLE AND HITCH .....	47
4.1.1	<i>Trailer Information</i> .....	47
4.1.2	<i>Tow Vehicle</i> .....	49
4.2	COUPLING AND UNCOUPLING THE TRAILER .....	51
4.2.1	<i>Various Coupler Designs</i> .....	52
4.2.2	<i>Trailer with Ball-Hitch Coupler</i> .....	53
4.2.2.1	Before Coupling the Trailer to the Tow Vehicle.....	55
4.2.2.2	Prepare the Coupler and Hitch .....	56
4.2.2.3	Couple the Trailer to the Tow Vehicle.....	57
4.2.3	<i>Trailer with Ring and Pintle Coupler</i> .....	58
4.2.3.1	Before Coupling The Trailer To The Tow Vehicle.....	59
4.2.3.2	Prepare The Ring and Pintle .....	60
4.2.3.3	Couple The Trailer To The Tow Vehicle.....	60
4.2.4	<i>Rig the Safety Chains – Bumper Pull Trailer</i> .....	61
4.2.5	<i>Connect the Electrical Cable – Bumper Pull Trailers</i> .....	62
4.2.6	<i>Attach and Test Electric Breakaway Brake System – Bumper Pull Trailers</i> .....	63
4.2.7	<i>Attach and Test Surge Brake Breakaway Brake System</i> .....	65
4.2.7.1	Testing The Surge Brake Operation (If Equipped) .....	66
4.2.7.2	Uncoupling a Bumper Pull Trailer .....	68
4.2.8	<i>Gooseneck Trailer with Ball Coupler or King Pin</i> .....	68
4.2.8.1	Prepare the Gooseneck Receiver.....	71
4.2.8.2	Couple the Trailer to the Tow Vehicle.....	72
4.2.8.3	Rig the Safety Chains.....	73
4.2.8.4	Attach and Test the Breakaway Brake System .....	74

# Table of Contents

## FLATBED TRAILERS

4.2.8.5	Connect the Electrical Cable .....	76
4.2.8.6	Uncoupling the Gooseneck Trailer .....	77
4.3	ADJUST HITCH HEIGHT .....	79
4.4	ADJUST GOOSENECK HEIGHT .....	81
<b>5</b>	<b>LOADING AND UNLOADING THE TRAILER .....</b>	<b>83</b>
5.1	TONGUE WEIGHT .....	83
5.2	CHECKING TONGUE WEIGHT .....	85
5.3	LOADING TRAILER .....	86
5.3.1	<i>Preparing the Trailer for Loading .....</i>	<i>87</i>
5.3.2	<i>Loading a Rigid Deck Trailer .....</i>	<i>87</i>
5.3.3	<i>Loading a Non-Powered Tilt Deck Trailer .....</i>	<i>90</i>
5.3.4	<i>Loading a Hydraulic Tilt Deck Trailer .....</i>	<i>91</i>
<b>6</b>	<b>CHECKING THE TRAILER BEFORE AND DURING EACH TOW .</b> <b>.....</b>	<b>95</b>
6.1	PRE-TOW CHECKLIST .....	95
6.2	MAKE REGULAR STOPS .....	95
<b>7</b>	<b>ACCESSORIES .....</b>	<b>97</b>
7.1	ACCESSORY BATTERY .....	97
7.2	BATTERY CHARGER .....	98
7.3	DC HYDRAULIC POWER UNIT .....	99
<b>8</b>	<b>INSPECTION SERVICE &amp; MAINTENANCE .....</b>	<b>101</b>
8.1	INSPECTION, SERVICE & MAINTENANCE SUMMARY CHARTS .....	101
8.2	INSPECTION AND SERVICE INSTRUCTIONS .....	104
8.2.1	<i>Axle Bolts, Frame, Suspension, &amp; Structure .....</i>	<i>104</i>
8.2.2	<i>Trailer Structure .....</i>	<i>105</i>
8.2.2.1	Fasteners and Frame Members .....	105
8.2.2.2	Welds .....	105
8.2.2.3	Slide-Out Ramps .....	106
8.2.3	<i>Trailer Brakes - Electric .....</i>	<i>106</i>
8.2.3.1	Brake Shoes and Drums .....	106
8.2.3.2	Manually Adjusting Brake Shoes .....	106
8.2.3.3	Brakes, Electric .....	107
8.2.3.4	Tow Vehicle Operated Electric Brakes .....	108
8.2.3.5	Magnets for all Electric Brakes .....	108
8.2.4	<i>Trailer Brakes – Surge .....</i>	<i>109</i>
8.2.4.1	Hydraulic Surge Brake .....	109
8.2.4.2	Master Cylinder Bleeding .....	109
8.2.5	<i>Trailer Connection to Tow Vehicle .....</i>	<i>111</i>
8.2.5.1	Coupler and Ball .....	111

Table of Contents  
FLATBED TRAILERS

8.2.5.2	Ring and Pintle.....	111
8.2.5.3	Gooseneck.....	112
8.2.5.4	Fifth Wheel Kingpin .....	113
8.2.6	<i>Landing Leg or Jack</i> .....	113
8.2.7	<i>Lights and Signals</i> .....	113
8.2.8	<i>Accessory Battery</i> .....	113
8.2.9	<i>Accessory DC Power Unit</i> .....	114
8.2.9.1	DC Power Unit Maintenance .....	115
8.2.9.2	DC Power Unit Troubleshooting.....	115
8.2.10	<i>Tires</i> .....	116
8.2.11	<i>Wheel Rims</i> .....	118
8.2.12	<i>Wheel Bearings</i> .....	118
8.2.13	<i>Lubrication Points</i> .....	118
8.2.14	<i>Lug Nuts (Bolts)</i> .....	118
<b>9</b>	<b>ELECTRICAL DRAWINGS</b> .....	<b>121</b>

# 1 INTRODUCTION / GENERAL INFORMATION

## **1.1 TRAILER MODELS**

### **Trailer Models:**

#### **Equipment Haulers**

- EH 14
- EH 16
- EH 18
- EH 20
- EH 820
- EH 824
- HT 16
- HT 18
- HT 20D
- HT 820
- HT 824D
- T 512
- T 712

#### **Car Haulers**

- CH 16
- CH 18
- CH 20

## **1.2 BREAKING-IN A NEW TRAILER**

### **1.2.1 Retighten Lug Nuts at First 10, 25 & 50 Miles**

Wheel lugs can shift and settle quickly after being first assembled, and must be checked after the **first** 10, 25 and 50 miles of driving. Failure to perform this check may result in a wheel coming loose from the trailer, causing a crash leading to death or serious injury.

# Introduction / General Information

---

## WARNING

Lug nuts are prone to loosen after being first assembled. Death or serious injury can result.

Check lug nuts for tightness on a new trailer, and after re-mounting a wheel at 10, 25 and 50 miles.

### **1.2.2 Adjust Brake Shoes at First 200 Miles**

Brake shoes and drums experience a rapid initial wear. The brakes must be adjusted after the first 200 miles of use, and each 3,000 miles thereafter. Some axles are fitted with a mechanism that will automatically adjust the brake shoes when the trailer is “hard braked” from a rearward direction. Read your axle and brake manual to see if your brakes adjust automatically. If you do not have the axle and brake manual, call Bri-Mar Manufacturing LLC at 1-800-732-5845 for a free copy.

A hard stop is used to:

- Confirm that the brakes work;
- Confirm that the trailer brakes are properly synchronized with the tow vehicle brakes using the brake controller in the tow vehicle
- Adjust the brake shoes as necessary.
- For surge brakes check the Master cylinder reservoir for fluid.

If your trailer is not fitted with automatically adjusting brakes, the brakes will need to be manually adjusted. See section 8.2.3.2, “Manually Adjusting Brake Shoes,” for instructions.

### **1.2.3 Synchronizing the Brake Systems**

Trailer brakes are designed to work in synchronization with the brakes on the tow vehicle.



## Introduction / General Information

---

When the tow vehicle and trailer braking systems are synchronized, both braking systems contribute to slowing, and the tongue of the trailer will neither dive nor rise sharply.

### **WARNING**

If trailer and tow vehicle brakes do not work properly together, death or serious injury can occur.

Road test the brakes in a safe area at no more than 30 m.p.h. before each tow

To insure safe brake performance and synchronization, read and follow the axle/brake and the brake controller manufacturers' instructions. If you do not have these instructions, call Bri-Mar Manufacturing LLC at 1-800-732-5845 for a free copy.

### **1.2.4 Tire Pressure**

Check tire pressures on both the trailer and tow vehicle. Inflate to the pressure stated on the vehicles Certification / VIN label.

### **1.3 WARRANTY**

Bri-Mar Manufacturing, L.L.C., hereinafter referred to as manufacturer, warrants each trailer to be free from defects in material and workmanship for a period of (24) months under normal wear and rated load capacity.

The warranty begins on the date that the trailer is put into service with a limit of (30) months from shipment from the manufacturer.

The manufacturer will warrant it's paint from defects as a result of improper preparation and application for a period of (12) months.

The warranty applies to all trailers that have not been altered or repaired without the manufacturer's authorization.

The manufacturer reserves the right to make changes in design or changes in specifications at any time, without incurring any obligation to owners of trailers previously sold.

## Introduction / General Information

---

The warranty does not cover: customer dissatisfaction, transportation to and from the servicing dealer, lack of maintenance, accidents, operator's misuse or altered electrical systems.

All axle assemblies, brake systems, wheels, tires, light systems, hitch couplers, jacks, power units, cylinders, or other accessories or purchased parts are warranted by the respective manufacturer.

This warranty is in lieu of all other warranties, guarantees of agreements, whether expressed or implied, and no other person, agent, dealer, or company is authorized to change, modify, or extend it's terms in any manner whatsoever.


## 2 GENERAL SAFETY INFORMATION

---

---

### 2.1 SAFETY ALERT SYMBOLS AND SIGNAL WORDS

An Owner's Manual that provides general trailer information cannot cover all of the specific details necessary for the proper combination of every trailer, tow vehicle and hitch. Therefore, you must read, understand and follow the instructions given by the tow vehicle and trailer hitch manufacturers, as well as the instructions in this manual. Our trailers are built with components produced by various manufacturers. Some of these items have separate instruction manuals. Where this manual indicates that you should read another manual, and you do not have that manual, call Bri-Mar Manufacturing LLC at 1-800-732-5845 for a free copy.

The safety information in this manual is denoted by the safety alert symbol: 

The level of risk is indicated by the following signal words.

#### **Danger**

DANGER – Immediate hazards which WILL result in severe personal injury or death if the warning is ignored.

#### **WARNING**

WARNING – Hazards or unsafe practices which COULD result in severe personal injury or death if the warning is ignored.

#### **Caution**

CAUTION – Hazards or unsafe practices which could result in minor or moderate injury if the warning is ignored.

# General Safety Information

## Notice

NOTICE – Practices that could result in damage to the trailer or other property.

## 2.2 MAJOR HAZARDS

Loss of control of the trailer or trailer/tow vehicle combination can result in death or serious injury. The most common causes for loss of control of the trailer are:

- Improper sizing the trailer for the tow vehicle, or vice versa.
- Excessive Speed: Driving too fast for the conditions.
- Failure to adjust driving behavior when towing a trailer.
- Overloading and/or improper weight distribution.
- Improper or mis-coupling of the trailer to the hitch.
- Improper braking and steering under sway conditions.
- Not maintaining proper tire pressure.
- Not keeping lug nuts tight.

### 2.2.1 Improper Sizing of the Trailer to the Tow Vehicle.

Trailers that weigh too much for the towing vehicle can cause stability problems, which can lead to death or serious injury. Furthermore, the additional strain put on the engine and drive-train may lead to serious tow vehicle maintenance problems. For these reasons the maximum towing capacity of your towing vehicle should not be exceeded. The towing capacity of your tow vehicle, in terms of maximum Gross Trailer Weight (GTW) and maximum Gross Combined Weight Rating (GCWR) can be found in the tow vehicles Owner's Manual.

## **Danger**

Use of an under-rated hitch, ball or tow vehicle can result in loss of control leading to death or serious injury.

Make certain your hitch and tow vehicle are rated for your trailer.

# General Safety Information

---

## **2.2.2 Driving Too Fast**

With ideal road conditions, the maximum recommended speed for safely towing a trailer is 60 mph. If you drive too fast, the trailer is more likely to sway, thus increasing the possibility for loss of control. Also your tires may overheat, thus increasing the possibility of a blowout.

### **WARNING**

Driving too fast for conditions can result in loss of control and cause death or serious injury.

Adjust speed down when towing trailer.

## **2.2.3 Failure to Adjust Driving Behavior When Towing a Trailer**

When towing a trailer, you will have decreased acceleration, increased stopping distance, and increased turning radius (which means you must make wider turns to keep from hitting curbs, vehicles, and anything else that is on the inside corner). Furthermore the trailer will change the handling characteristics of your towing vehicle, making it more sensitive to steering inputs and more likely to be pushed around in windy conditions or when being passed by large vehicles. In addition, you will need a longer distance to pass, due to slower acceleration and increased length. With this in mind:

- Be alert for slippery conditions. You are more likely to be affected by slippery road surfaces when driving a tow vehicle with a trailer, than driving a tow vehicle without a trailer.
- Anticipate the trailer “swaying.” Swaying can be caused by excessive steering, wind gusts, roadway edges, or by the trailer reaction to the pressure wave created by passing trucks and busses.
- When encountering trailer sway take your foot off the gas, and steer as little as possible in order to stay on the road. Use small “trim-like” steering adjustments. Do not attempt to steer out of the sway; you’ll only make it worse. Also, do not apply the tow vehicle brakes to correct trailer swaying. On the other hand, application of the trailer

## General Safety Information

---

brakes alone will tend to straighten out the combination, especially when going downhill.

- Check rearview mirrors frequently to observe the trailer and traffic.
- Use lower gear when driving down steep or long grades. Use the engine and transmission as a brake. Do not ride the brakes, as they can overheat and become ineffective.
- Be aware of your trailer height, especially when approaching bridges, roofed areas and around trees.

### **2.2.4 Trailer Not Properly Coupled to the Hitch**

It is critical that the trailer be securely coupled to the hitch ball, and that the safety chains and emergency break-away brake cable are correctly attached. Uncoupling may result in death or serious injury to you and to others.

#### **WARNING**

Proper selection and condition of the coupler and hitch are essential to safely towing your trailer. A loss of coupling may result in death or serious injury.

- Be sure the hitch load rating is equal to or greater than the load rating of the coupler.
- Be sure the hitch size matches the coupler size.
- Observe the hitch for wear, corrosion and cracks before coupling. Replace worn, corroded or cracked hitch components before coupling the trailer to the tow vehicle.
- Be sure the hitch components are tight before coupling the trailer to the tow vehicle.

# General Safety Information

## WARNING

An improperly coupled trailer can result in death or serious injury.

Do not move the trailer until:

- The coupler is secured and locked to hitch;
- The safety chains are secured to the tow vehicle; and
- The trailer jack(s) are fully retracted.

Do not tow the trailer on the road until:

- Tires and wheels are checked;
- The trailer brakes are checked;
- The breakaway switch is connected to the tow vehicle;
- The load is secured to the trailer; and
- The trailer lights are connected and checked.

### **2.2.5 Proper Use of Safety Chains**

If your trailer comes loose from the hitch for any reason, we have provided safety chains so that control of the trailer can still be maintained

## WARNING

Improper rigging of the safety chains can result in loss of control of the trailer and tow vehicle, leading to death or serious injury, if the trailer uncouples from the tow vehicle.

- Fasten chains to frame of tow vehicle. Do not fasten chains to any part of the hitch unless the hitch has holes or loops specifically for that purpose.
- Cross chains underneath hitch and coupler with enough slack to permit turning and to hold tongue up, if the trailer comes loose.

### **2.2.6 Proper Connection of Breakaway Brake**

If equipped with brakes your trailer will be equipped with a breakaway brake system that can apply the brakes on your trailer if your trailer

## General Safety Information

---

comes loose from the hitch ball for any reason. You will have a separate set of instructions for the breakaway brake if your trailer is so equipped. The breakaway brake system, including battery, must be in good condition and properly rigged to be effective.

### WARNING

An ineffective or inoperative breakaway brake system can result in a runaway trailer, leading to death or serious injury if the coupler or hitch fails.

The breakaway cable must be connected to the tow vehicle, and NOT to any part of the hitch.

Before towing the trailer, test the function of the breakaway brake system. If the breakaway brake system is not working, do not tow the trailer. Have it serviced or repaired.

### **2.2.7 Mismatch of Trailer and Hitch**

### Danger

Use of a hitch with a load rating less than the load rating of the trailer can result in loss of control and may lead to death or serious injury.

Use of a tow vehicle with a towing capacity less than the load rating of the trailer can result in loss of control, and may lead to death or serious injury.

Be sure your hitch and tow vehicle are rated for the Gross Vehicle Weight Rating (GVWR) of your trailer.

### **2.2.8 Unsafe Tire, Lug Nuts or Wheels**

Just as with your tow vehicle the trailer tires and wheels are important safety items. Therefore, it is essential to inspect the trailer tires before each tow.



## General Safety Information

---

If a tire has a bald spot, bulge, cut, cracks, or is showing any cords, replace the tire before towing. If a tire has uneven tread wear, take the trailer to a dealer service center for diagnosis. Uneven tread wear can be caused by tire imbalance, axle misalignment or incorrect inflation.

Tires with too little tread will not provide adequate frictional forces on wet roadways and can result in loss of control, leading to death or serious injury.

Improper tire pressure causes increased tire wear and may reduce trailer stability, which can result in a tire blowout or possible loss of control. Therefore, before each tow you must also check the tire pressure. Remember, the proper tire pressure is listed on the Certification / VIN label, normally mounted on the front left side of the trailer, and should be checked when tires are cold. Allow 3 hours cool-down after driving as much as 1 mile at 40 mph before checking tire pressure.

### WARNING

Improper tire pressure may cause an unstable trailer. Blowout and loss of control may occur. Death or serious injury can result.

Make sure of proper tire pressure before towing trailer. Inflate tires to pressure stated on the Certification / VIN label.

The tightness of the lug nuts is very important in keeping the wheels properly seated to the hub. Before each tow, check to make sure they are tight.

### WARNING

Metal creep between the wheel rim and lug nuts (bolts) will cause rim to loosen.

Death or injury can occur if wheel comes off.

Tighten lug nuts (bolts) before each tow.

The proper tightness (torque) for lug nuts is listed in Section 8.2.13 in the “Inspection and Service Instructions” chapter of this manual. Use a

## General Safety Information

---

torque wrench to tighten the lug nuts, use the crisscross star pattern as shown in the Inspection, Service and Maintenance section.

Lug nuts are also prone to loosen after first being assembled. When driving a new trailer (or after wheels have been remounted), check to make sure they are tight after the **first** 10, 25 and 50 miles of driving and before each tow thereafter.

Failure to perform this check can result in a wheel separating from the trailer and a crash, leading to death or serious injury.

### WARNING

Lug nuts are prone to loosen after being first assembled. Death or serious injury can result.

Check lug nuts for tightness on a new trailer, and after re-mounting a wheel at 10, 25 and 50 miles.

### WARNING

Inadequate lug nut torque can cause a wheel separating from the trailer, leading to death or serious injury can result.

Be sure lug nuts are tight before each tow.

### **2.2.9 Improper Loading**

The total weight of the load you put in or on the trailer, plus the empty weight of the trailer itself, must not exceed the trailer's Gross Vehicle Weight Rating (GVWR). If you do not know the empty weight of the trailer plus the cargo weight, you must weigh the loaded trailer at a commercial scale. In addition, you must distribute the load in the trailer such that the load on any axle does not exceed the Gross Axle Weight Rating (GAWR). If your trailer is equipped with a Tire & Loading Information Placard, mounted next to the Certification / VIN label, the cargo capacity weight stated on that placard is only a close estimate. The GVWR and GAWR's are listed on the Certification / VIN label mounted on the front left side of the trailer.

# General Safety Information

---

## WARNING

An overloaded trailer can result in failure or in loss of control of the trailer, leading to death or serious injury.

Never load a trailer so that the weight on any tire exceeds its rating.

Never exceed the trailer Gross Vehicle Weight Rating (GVWR).

Never exceed an axle Gross Axle Weight Rating (GAWR).

### **2.2.10 Unsafe Load Distribution**

Uneven load distribution can cause tire, wheel, axle or structural failure. Be sure your trailer is properly loaded.

Improper front / rear load distribution can lead to trailer swaying or poor tow vehicle handling. Trailer sway results from tongue weights that are too low, and poor tow vehicle stability results from tongue weights that are too high. Refer to the Chapter heading “Loading the Trailer” for more information.

In the following table, the second column shows the rule of thumb percentage of total weight of the trailer plus its cargo (Gross Trailer Weight, or “GTW”) that should appear on the tongue of the trailer. For example, a trailer with a gooseneck hitch, with a loaded weight of 12,000 pounds, should have 20-25% of 12,000 pounds (2400-3000 lbs.) on the gooseneck. After loading, be sure to check that none of the axles are overloaded.

# General Safety Information

Tongue Weight as a Percentage of Loaded Trailer Weight	
Type of Hitch	Percentage
Ball Hitch (or Bumper Hitch)	10-15%
	6-10% for smaller utility and cargo trailers
Gooseneck Hitch	20-25%
Fifth Wheel Hitch	

Towing stability also depends on keeping the center of gravity as low as possible.

## WARNING

Improper tongue weight (load distribution) can result in loss of control of the trailer, leading to death or serious injury.

Make certain that tongue weight is within the allowable range.

Be sure to:

- Distribute the load front-to-rear to provide proper tongue weight (see chart).
- Distribute the load evenly, right and left.
- Keep the center of gravity low.

### 2.2.11 Shifting Cargo

Since the trailer “ride” can be bumpy and rough, you must secure your cargo so that it does not shift while the trailer is being towed.

## General Safety Information

### WARNING

A shifting load can result in failure, or to loss of control of the trailer, and can lead to death or serious injury.

You must tie down all loads with proper sized fasteners, ropes, straps, etc. to prevent the load from shifting while trailering.

### **2.2.12 Inappropriate Cargo**

A utility trailer must not be used to carry certain items, such as people, containers of hazardous substances or containers of flammable substances.

### WARNING

Never transport people inside or on your trailer. Besides putting their lives at risk, the transport of people may be illegal.

### WARNING

Do not transport flammable, explosive, poisonous or other dangerous materials in your trailer. The exception is fuel in the tank of a vehicle or equipment being hauled.

### **2.2.13 Inoperable Brakes, Lights or Mirrors**

Be sure that the electric brakes and all of the lights on your trailer are functioning properly before towing your trailer. Electric brakes and lights on a trailer are controlled via a connection to the tow vehicle, generally a multi-pin electrical connector. Check the trailer tail lights by turning on your tow vehicle headlights. Check the trailer brake lights by having someone step on the tow vehicle brake pedal while you look at trailer lights. Do the same thing to check the turn signal lights.

If your trailer has electric brakes, your tow vehicle will have an electric brake controller that sends power to the trailer brakes. Before towing the

## General Safety Information

---

trailer on the road, you must operate the brake controller while trying to pull the trailer in order to confirm that the electric brakes operate. While towing the trailer at less than 5 mph, manually operate the electric brake controller in the tow vehicle cab. You should feel the operation of the trailer brakes. If your trailer has hydraulic “surge” brakes, pull the emergency break-away brake lanyard to check the operation of the surge mechanism.

### WARNING

Improper electrical connection between the tow vehicle and the trailer will result in inoperable lights and electric brakes, and can lead to collision.

Before each tow:

- Check that all lights and turn signals work.
- Check that the electric brakes work by operating the brake controller inside the tow vehicle

Standard mirrors usually do not provide adequate visibility for viewing traffic to the sides and rear a towed trailer. You must provide mirrors that allow you to safely observe approaching traffic.

### **2.2.14 Hazards From Modifying Your Trailer**

Essential safety items can be damaged by altering your trailer. Even simply driving a nail or screw to hang something can damage an electrical circuit, LP gas line or other feature of the trailer.

Before making any alteration to your trailer, contact your dealer or Bri-Mar Manufacturing LLC at 1-800-732-5845 and describe the alteration you are contemplating. Alteration of the trailer structure or modification of mechanical, electrical, plumbing, heating or other systems on your trailer must be performed only by qualified technicians who are familiar with the system as installed on your trailer.

# General Safety Information

---

## **2.2.15 Hazards from Accessories**

The “Accessories” chapter of this manual contains some information about certain optional accessories that may be on your trailer. Read and follow all of these instructions before operating the accessories.

### **2.2.15.1 Battery and Charger**

A battery charger is used to charge the battery from an external power source. Caution should be used when charging batteries. Batteries produce explosive gas during normal operation. Do not smoke or have sparks or open flames near battery compartment. Batteries contain sulfuric acid which can cause severe burns and blindness if exposed to skin or eyes. Always use eye and skin protection when working around batteries. If you are exposed to the acid, flush with water for 15 minutes and get prompt medical attention.

The charger must be properly connected to 120 Volt outlet to charge your battery safely. Make sure that the connections to the battery are tight. Connect to your trailer using a grounded extension cord designed for outdoor use. Plug into a “GFI” ( Ground Fault Interrupted ) receptacle to prevent possible shock.

### **WARNING**

To reduce the risk of explosion, explosive gases, or injury while using your battery charger, follow the precautions listed below:

Read all instructions and cautions printed on the battery charger and battery.

Connect the charger with a 3 prong (grounded) outdoor power cord to a “GFI” outlet.

Always charge battery in a well ventilated area.

To reduce risk of electrical shock, unplug the charger from the outlet before attempting any maintenance or cleaning.

Do not operate the charger if it has a damaged power cord or plug. Have the cord replaced.

## General Safety Information

---

### **2.2.15.2 DC Hydraulic Power Unit**

A DC hydraulic power unit is used on powered tilt deck trailers. The hydraulic system is under extreme pressure. Pressure will be in the hydraulic cylinder and lines even when the power unit is not operating. Never disconnect a hydraulic line or fitting while the tilt deck is raised. In the event of a system leak, hydraulic fluid can be expelled at high velocity piercing the skin and entering the blood stream. Wear eye and skin protection when servicing the hydraulic system. Do not wear jewelry or metal objects when servicing the power unit. Disconnect the ground wire first and then the positive wire from the power unit battery to prevent inadvertent operation while servicing the unit.

Reconnect the battery in reverse order to prevent tools from contacting the frame and short circuiting the battery. A manual is available from Bri-Mar Manufacturing LLC for service information on your power unit.

### **WARNING**

Escaping fluid under pressure can penetrate the skin causing serious injury.

Avoid the hazard by relieving pressure before connecting or disconnecting hydraulic lines. Tighten all connections before applying pressure.

Search for leaks with a piece of cardboard or wood. Protect hands and body from high pressure fluids.

If an accident occurs, see a doctor immediately. Any fluid injected into the skin must be surgically remove within a few hours or serious infection may result. Doctors unfamiliar with this type of injury should reference a knowledgeable medical source.



# General Safety Information




Figure 2-1. Equipment Hauler Safety Warning Label Locations.

# General Safety Information




Figure 2-2. Hydraulic Tilt Safety Warning Label Locations.

# General Safety Information




Figure 2-3 - Car Hauler Safety Warning Label Locations

## General Safety Information

---

### WARNING

To protect you and others against death or serious injury, all of the labels shown must be on the trailer and must be legible.

If any of these labels are missing or cannot be read, call Bri-Mar Manufacturing LLC at 1-800-732-5845 for free replacement labels.

You will need to provide us with the part number shown at the bottom of the label(s) or on the drawing in order for us to send the correct one(s).

### **2.2.17 Trailer Towing Guide**

Driving a vehicle with a trailer in tow is vastly different from driving the same vehicle without a trailer in tow. Acceleration, maneuverability and braking are all diminished with a trailer in tow. It takes longer to get up to speed, you need more room to turn and pass, and more distance to stop when towing a trailer. You will need to spend time adjusting to the different feel and maneuverability of the tow vehicle with a loaded trailer. Because of the significant differences in all aspects of maneuverability when towing a trailer, the hazards and risks of injury are also much greater than when driving without a trailer. You are responsible for keeping your vehicle and trailer in control, and for all the damage that is caused if you lose control of your vehicle and trailer.

As you did when learning to drive an automobile, find an open area with little or no traffic for your first practice trailering. Of course, before you start towing the trailer, you must follow all of the instructions for inspection, testing, loading and coupling. Also, before you start towing, adjust the mirrors so you can see the trailer as well as the area to the rear of it.

Drive slowly at first, 5 mph or so, and turn the wheel to get the feel of how the tow vehicle and trailer combination responds. Next, make some right and left hand turns. Watch in your side mirrors to see how the trailer follows the tow vehicle. Turning with a trailer attached requires more room.

Stop the rig a few times from speeds no greater than 10 mph. If your trailer is equipped with brakes, try using different combinations of

# General Safety Information

---

trailer/electric brake and tow vehicle brake. Note the effect that the trailer brakes have when they are the only brakes used. When properly adjusted, the trailer brakes will come on just before the tow vehicle brakes.

It will take practice to learn how to back up a tow vehicle with a trailer attached. Take it slow. Before backing up, get out of the tow vehicle and look behind the trailer to make sure that there are no obstacles. Some drivers place their hands at the bottom of the steering wheel, and while the tow vehicle is in reverse, “think” of the hands as being on the top of the wheel. When the hands move to the right (counter-clockwise, as you would do to turn the tow vehicle to the left when moving forward), the rear of the trailer moves to the right. Conversely, rotating the steering wheel clockwise with your hands at the bottom of the wheel will move the rear of the trailer to the left, while backing up. If you are towing a bumper hitch rig, be careful not to allow the trailer to turn too much, because it will hit the rear of the tow vehicle. To straighten the rig, either pull forward, or turn the steering wheel in the opposite direction.

## **2.2.18 Safe Trailer Towing Guidelines**

- Recheck the load tiedowns to make sure the load will not shift during towing.
- Before towing, check coupling, safety chains, safety brake, tires, wheels and lights.
- Check the lug nuts or bolts for tightness.
- Check coupler tightness after towing 50 miles.
- Adjust the brake controller to engage the trailer brakes before the tow vehicle brakes. Follow the instructions given with the brake controller manufacturer’s literature.
- Use your mirrors to verify that you have room to change lanes or pull into traffic.
- Use your turn signals well in advance.
- Allow plenty of stopping space for your trailer and tow vehicle.
- Do not drive so fast that the trailer begins to sway due to speed. Generally never drive faster than 60 m.p.h.
- Allow plenty of room for passing. A rule of thumb is that the passing distance with a trailer is 4 times the passing distance without a trailer.

# General Safety Information

---

- Shift your automatic transmission into a lower gear for city driving.
- Use lower gears for climbing and descending grades.
- Do not ride the brakes while descending grades, they may get so hot that they stop working. Then you will potentially have a runaway tow vehicle and trailer.
- To conserve fuel, don't use full throttle to climb a hill. Instead, build speed on the approach.
- Slow down for bumps in the road. Take your foot off the brake when crossing the bump.
- Do not brake while in a curve unless absolutely necessary. Instead, slow down before you enter the curve.
- Do not apply the tow vehicle brakes to correct extreme trailer swaying. Instead, lightly apply the trailer brakes with the hand controller.
- Make regular stops, about once each hour. Confirm that
  - The coupler is secure to the hitch and is locked,
  - Electrical connectors are made,
  - There is appropriate slack in the safety chains,
  - There is appropriate slack in the breakaway switch pullpin cable,
  - The tires are not visibly low on pressure, and
  - The cargo is secure and in good condition.

## **2.2.19 Reporting Safety Defects**

If you believe that your vehicle has a defect that could cause a crash or could cause injury or death, you should immediately inform the National Highway Traffic Safety Administration (NHTSA) in addition to notifying us.

If NHTSA receives similar complaints, it may open an investigation, and if it finds that a safety defect exists in a group of vehicles, it may order a recall and remedy campaign. However, NHTSA cannot become involved in individual problems between you, your dealer, or us.

To contact NHTSA, you may either call the Vehicle Safety Hotline toll-free at 1-888-327-4236 (TTY: 1-800-424-9153), go to <http://www.safercar.gov>; or write to: Administrator, NHTSA, 1200 New Jersey Avenue SE, Washington, DC 20590. You can also obtain other information about motor vehicle safety from <http://www.safercar.gov>.

# 3 TIRE SAFETY INFORMATION

---

---

This portion of the User’s Manual contains tire safety information as required by 49 CFR 575.6.

Section 2.1 contains “Trailer Tire Information”

Section 2.2 contains “Steps for Determining Correct Load Limit - Trailer”.

Section 2.3 contains “Steps for Determining Correct Load Limit – Tow Vehicle”.

Section 2.4 contains a Glossary of Tire Terminology, including “cold inflation pressure”, “maximum inflation pressure”, “recommended inflation pressure”, and other non-technical terms.

Section 2.5 contains information from the NHTSA brochure entitled “Tire Safety – Everything Rides On It”.

This brochure, as well as the preceding subsections, describe the following items;

- Tire labeling, including a description and explanation of each marking on the tires, and information about the DOT Tire Identification Number (TIN).
- Recommended tire inflation pressure, including a description and explanation of:
  - Cold inflation pressure.
  - Vehicle Placard and location on the vehicle.
  - Adverse safety consequences of under inflation (including tire failure).
  - Measuring and adjusting air pressure for proper inflation.
- Tire Care, including maintenance and safety practices.
- Vehicle load limits, including a description and explanation of the following items:
  - Locating and understanding the load limit information, total load capacity, and cargo capacity.

# Tire Safety Information

---

- Calculating total and cargo capacities with varying seating configurations including quantitative examples showing / illustrating how the vehicles cargo and luggage capacity decreases as combined number and size of occupants' increases. This item is also discussed in Section 3.
- Determining compatibility of tire and vehicle load capabilities.
- Adverse safety consequences of overloading on handling and stopping on tires.

## **3.1 TRAILER TIRE INFORMATION**

Trailer tires may be worn out even though they still have plenty of tread left. This is because trailer tires have to carry a lot of weight all the time, even when not in use. It is actually better for the tire to be rolling down the road than to be idle. During use, the tire releases lubricants that are beneficial to tire life. Using the trailer tires often also helps prevent flat spots from developing.

The main cause of tire failure is improper inflation. Check the cold tire inflation pressures at least once a week for proper inflation levels. "Cold" means that the tires are at the same temperature as the surrounding air, such as when the vehicle has been parked overnight. Wheel and tire manufacturers recommend adjusting the air pressure to the trailer manufacturer's recommended cold inflation pressure, in pounds per square inch (PSI) stated on the vehicle's Federal Certification Label or Tire Placard when the trailer is loaded to its gross vehicle weight rating (GVWR). If the tires are inflated to less than the recommended inflation level or the GVWR of the trailer is exceeded, the load carrying capacity of the tire could be dramatically affected. If the tires are inflated more than the recommended inflation level, handling characteristics of the tow vehicle/trailer combination could be affected. Refer to the owner's manual or talk to your dealer or vehicle manufacturer if you have any questions regarding proper inflation practices.

Tires can lose air over a period of time. In fact, tires can lose 1 to 3 PSI per month. This is because molecules of air, under pressure, weave their way from the inside of the tire, through the rubber, to the outside. A drop in tire pressure could cause the tire to become overloaded, leading



# Tire Safety Information

---

to excessive heat build up. If a trailer tire is under-inflated, even for a short period of time, the tire could suffer internal damage.

High speed towing in hot conditions degrades trailer tires significantly. As heat builds up during driving, the tire's internal structure starts to breakdown, compromising the strength of the tire. It is recommended to drive at moderate speeds.

Statistics indicate the average life of a trailer tire is about five years under normal use and maintenance conditions. After three years, replacing the trailer tires with new ones should be considered, even if the tires have adequate tread depth. Some experts claim that after five years, trailer tires are considered worn out and should be replaced, even if they have had minimal or no use. This is such a general statement that it may not apply in all cases. It is best to have your tires inspected by a tire supplier to determine if your tires need to be replaced.

If you are storing your trailer for an extended period, make sure the tires are fully inflated to the maximum rated pressure and that you store them in a cool, dry place, such as a garage. Use tire covers to protect the trailer tires from the harsh effects of the sun.

## **3.2 STEPS FOR DETERMINING CORRECT LOAD LIMIT – TRAILER**

Determining the load limits of a trailer includes more than understanding the load limits of the tires alone. On all trailers there is a Federal Certification / VIN label that is located on the forward half of the left (road) side of the unit. This certification/VIN label will indicate the trailer's Gross Vehicle Weight Rating (GVWR). This is the most weight the fully loaded trailer can weigh. It will also provide the Gross Axle Weight Rating (GAWR). This is the most a particular axle can weigh. If there are multiple axles, the GAWR of each axle will be provided.

If your trailer has a GVWR of 10,000 pounds or less, there is a vehicle placard located in the same location as the certification label described above. This placard provides tire and loading information. In addition, this placard will show a statement regarding maximum cargo capacity. Cargo can be added to the trailer, up to the maximum weight specified on the placard. The combined weight of the cargo is provided as a single

## Tire Safety Information

---

number. In any case, remember: the total weight of a fully loaded trailer can not exceed the stated GVWR.


For trailers with living quarters installed, the weight of water and propane also need to be considered. The weight of fully filled propane containers is considered part of the weight of the trailer before it is loaded with cargo, and is not considered part of the disposable cargo load. Water however, is a disposable cargo weight and is treated as such. If there is a fresh water storage tank of 100 gallons, this tank when filled would weigh about 800 pounds. If more cargo is being transported, water can be off-loaded to keep the total amount of cargo added to the vehicle within the limits of the GVWR so as not to overload the vehicle. Understanding this flexibility will allow you, the owner, to make choices that fit your travel needs.

When loading your cargo, be sure it is distributed evenly to prevent overloading front to back and side to side. Heavy items should be placed low and as close to the axle positions as reasonable. Too many items on one side may overload a tire. The best way to know the actual weight of the vehicle is to weigh it at a public scale. Talk to your dealer to discuss the weighing methods needed to capture the various weights related to the trailer. This would include the weight empty or unloaded, weights per axle, wheel, hitch or king-pin, and total weight.

Excessive loads and/or underinflation cause tire overloading and, as a result, abnormal tire flexing occurs. This situation can generate an excessive amount of heat within the tire. Excessive heat may lead to tire failure. It is the air pressure that enables a tire to support the load, so proper inflation is critical. The proper air pressure may be found on the Certification / VIN label and/or on the Tire Placard. This value should never exceed the maximum cold inflation pressure stamped on the tire.

# Tire Safety Information

## 3.2.1 Trailers 10,000 Pounds GVWR or Less



Tire Information Placard – Figure 3-1

1. Locate the statement, “The weight of cargo should never exceed XXX kg or XXX lbs.,” on your vehicle’s placard. See figure 3-1.
2. This figure equals the available amount of cargo and luggage load capacity.
3. Determine the combined weight of luggage and cargo being loaded on the vehicle. That weight may not safely exceed the available cargo and luggage load capacity.
4. The trailer’s placard refers to the Tire Information Placard attached adjacent to or near the trailer’s VIN (Certification) label at the left front of the trailer.

## 3.2.2 Trailers Over 10,000 Pounds GVWR

(Note: These trailers are not required to have a tire information placard on the trailer and may not have one installed)

1. Determine the empty weight of your trailer by weighing the trailer using a public scale or other means. This step does not have to be repeated.
2. Locate the GVWR (Gross Vehicle Weight Rating) of the trailer on your trailer’s VIN (Certification) label.
3. Subtract the empty weight of your trailer from the GVWR stated on the VIN label. That weight is the maximum available cargo capacity of the trailer and may not be safely exceeded.

# Tire Safety Information

---

## **3.3 STEPS FOR DETERMINING CORRECT LOAD LIMIT – TOW VEHICLE**

1. Locate the statement, “The combined weight of occupants and cargo should never exceed XXX lbs.,” on your vehicle’s placard.
2. Determine the combined weight of the driver and passengers who will be riding in your vehicle.
3. Subtract the combined weight of the driver and passengers from XXX kilograms or XXX pounds.
4. The resulting figure equals the available amount of cargo and luggage capacity. For example, if the “XXX” amount equals 1400 lbs. and there will be five 150 lb. passengers in your vehicle, the amount of available cargo and luggage capacity is 650 lbs.  $(1400 - 750 (5 \times 150) = 650 \text{ lbs.})$ .
5. Determine the combined weight of luggage and cargo being loaded on the vehicle. That weight may not safely exceed the available cargo and luggage capacity calculated in Step # 4.
6. If your vehicle will be towing a trailer, load from your trailer will be transferred to your vehicle. Consult the tow vehicle’s manual to determine how this weight transfer reduces the available cargo and luggage capacity of your vehicle.

## **3.4 GLOSSARY OF TIRE TERMINOLOGY**

### **Accessory weight**

The combined weight (in excess of those standard items which may be replaced) of automatic transmission, power steering, power brakes, power windows, power seats, radio and heater, to the extent that these items are available as factory-installed equipment (whether installed or not).

### **Bead**

The part of the tire that is made of steel wires, wrapped or reinforced by ply cords and that is shaped to fit the rim.

### **Bead separation**

This is the breakdown of the bond between components in the bead.

### **Bias ply tire**

## Tire Safety Information

---

A pneumatic tire in which the ply cords that extend to the beads are laid at alternate angles substantially less than 90 degrees to the centerline of the tread.

### **Carcass**

The tire structure, except tread and sidewall rubber which, when inflated, bears the load.

### **Chunking**

The breaking away of pieces of the tread or sidewall.

### **Cold inflation pressure**

The pressure in the tire before you drive.

### **Cord**

The strands forming the plies in the tire.

### **Cord separation**

The parting of cords from adjacent rubber compounds.

### **Cracking**

Any parting within the tread, sidewall, or inner liner of the tire extending to cord material.

### **CT**

A pneumatic tire with an inverted flange tire and rim system in which the rim is designed with rim flanges pointed radially inward and the tire is designed to fit on the underside of the rim in a manner that encloses the rim flanges inside the air cavity of the tire.

### **Curb weight**

The weight of a motor vehicle with standard equipment including the maximum capacity of fuel, oil, and coolant, and, if so equipped, air conditioning and additional weight optional engine.

### **Extra load tire**

A tire designed to operate at higher loads and at higher inflation pressures than the corresponding standard tire.

# Tire Safety Information

---

## **Groove**

The space between two adjacent tread ribs.

## **Gross Axle Weight Rating**

The maximum weight that any axle can support, as published on the Certification / VIN label on the front left side of the trailer. Actual weight determined by weighing each axle on a public scale, with the trailer attached to the towing vehicle.

## **Gross Vehicle Weight Rating**

The maximum weight of the fully loaded trailer, as published on the Certification / VIN label. Actual weight determined by weighing trailer on a public scale, without being attached to the towing vehicle.

## **Hitch Weight**

The downward force exerted on the hitch ball by the trailer coupler.

## **Innerliner**

The layer(s) forming the inside surface of a tubeless tire that contains the inflating medium within the tire.

## **Innerliner separation**

The parting of the innerliner from cord material in the carcass.

## **Intended outboard sidewall**

The sidewall that contains a white-wall, bears white lettering or bears manufacturer, brand, and/or model name molding that is higher or deeper than the same molding on the other sidewall of the tire or the outward facing sidewall of an asymmetrical tire that has a particular side that must always face outward when mounted on a vehicle.

## **Light truck (LT) tire**

A tire designated by its manufacturer as primarily intended for use on lightweight trucks or multipurpose passenger vehicles. May be used on trailers.

## **Load rating**

The maximum load that a tire is rated to carry for a given inflation pressure.

# Tire Safety Information

---

## **Maximum load rating**

The load rating for a tire at the maximum permissible inflation pressure for that tire.

## **Maximum permissible inflation pressure**

The maximum cold inflation pressure to which a tire may be inflated.

## **Maximum loaded vehicle weight**

The sum of curb weight, accessory weight, vehicle capacity weight, and production options weight.

## **Measuring rim**

The rim on which a tire is fitted for physical dimension requirements.

## **Non-pneumatic rim**

A mechanical device which, when a non-pneumatic tire assembly incorporates a wheel, supports the tire, and attaches, either integrally or separably, to the wheel center member and upon which the tire is attached.

## **Non-pneumatic spare tire assembly**

A non-pneumatic tire assembly intended for temporary use in place of one of the pneumatic tires and rims that are fitted to a passenger car in compliance with the requirements of this standard.

## **Non-pneumatic tire**

A mechanical device which transmits, either directly or through a wheel or wheel center member, the vertical load and tractive forces from the roadway to the vehicle, generates the tractive forces that provide the directional control of the vehicle and does not rely on the containment of any gas or fluid for providing those functions.

## **Non-pneumatic tire assembly**

A non-pneumatic tire, alone or in combination with a wheel or wheel center member, which can be mounted on a vehicle.

## **Normal occupant weight**

# Tire Safety Information

---

This means 68 kilograms (150 lbs.) times the number of occupants specified in the second column of Table I of 49 CFR 571.110.

## **Occupant distribution**

The distribution of occupants in a vehicle as specified in the third column of Table I of 49 CFR 571.110.

## **Open splice**

Any parting at any junction of tread, sidewall, or innerliner that extends to cord material.

## **Outer diameter**

The overall diameter of an inflated new tire.

## **Overall width**

The linear distance between the exteriors of the sidewalls of an inflated tire, including elevations due to labeling, decorations, or protective bands or ribs.

## **Pin Weight**

The downward force applied to the 5<sup>th</sup> wheel or gooseneck ball, by the trailer kingpin or gooseneck coupler.

## **Ply**

A layer of rubber-coated parallel cords.

## **Ply separation**

A parting of rubber compound between adjacent plies.

## **Pneumatic tire**

A mechanical device made of rubber, chemicals, fabric and steel or other materials, that, when mounted on an automotive wheel, provides the traction and contains the gas or fluid that sustains the load.

## **Production options weight**

The combined weight of those installed regular production options weighing over 2.3 kilograms (5 lbs.) in excess of those standard items which they replace, not previously considered in curb weight or



# Tire Safety Information

---

accessory weight, including heavy duty brakes, ride levelers, roof rack, heavy duty battery, and special trim.

## **Radial ply tire**

A pneumatic tire in which the ply cords that extend to the beads are laid at substantially 90 degrees to the centerline of the tread.

## **Recommended inflation pressure**

This is the inflation pressure provided by the vehicle manufacturer on the Tire Information label and on the Certification / VIN tag.

## **Reinforced tire**

A tire designed to operate at higher loads and at higher inflation pressures than the corresponding standard tire.

## **Rim**

A metal support for a tire or a tire and tube assembly upon which the tire beads are seated.

## **Rim diameter**

This means the nominal diameter of the bead seat.

## **Rim size designation**

This means the rim diameter and width.

## **Rim type designation**

This means the industry of manufacturer's designation for a rim by style or code.

## **Rim width**

This means the nominal distance between rim flanges.

## **Section width**

The linear distance between the exteriors of the sidewalls of an inflated tire, excluding elevations due to labeling, decoration, or protective bands.

## **Sidewall**

That portion of a tire between the tread and bead.

# Tire Safety Information

---

## **Sidewall separation**

The parting of the rubber compound from the cord material in the sidewall.

## **Special Trailer (ST) tire**

The "ST" is an indication the tire is for trailer use only.

## **Test rim**

The rim on which a tire is fitted for testing, and may be any rim listed as appropriate for use with that tire.

## **Tread**

That portion of a tire that comes into contact with the road.

## **Tread rib**

A tread section running circumferentially around a tire.

## **Tread separation**

Pulling away of the tread from the tire carcass.

## **Treadwear indicators (TWI)**

The projections within the principal grooves designed to give a visual indication of the degrees of wear of the tread.

## **Vehicle capacity weight**

The rated cargo and luggage load plus 68 kilograms (150 lbs.) times the vehicle's designated seating capacity.

## **Vehicle maximum load on the tire**

The load on an individual tire that is determined by distributing to each axle its share of the maximum loaded vehicle weight and dividing by two.

## **Vehicle normal load on the tire**

The load on an individual tire that is determined by distributing to each axle its share of the curb weight, accessory weight, and normal occupant weight (distributed in accordance with Table I of CRF 49 571.110) and dividing by 2.

# Tire Safety Information

---

## **Weather side**

The surface area of the rim not covered by the inflated tire.

## **Wheel center member**

In the case of a non-pneumatic tire assembly incorporating a wheel, a mechanical device which attaches, either integrally or separably, to the non-pneumatic rim and provides the connection between the non-pneumatic rim and the vehicle; or, in the case of a non-pneumatic tire assembly not incorporating a wheel, a mechanical device which attaches, either integrally or separably, to the non-pneumatic tire and provides the connection between tire and the vehicle.

## **Wheel-holding fixture**

The fixture used to hold the wheel and tire assembly securely during testing.

## **3.5 TIRE SAFETY - EVERYTHING RIDES ON IT**

The National Traffic Safety Administration (NHTSA) has published a brochure (DOT HS 809 361) that discusses all aspects of Tire Safety, as required by CFR 575.6. This brochure is reproduced in part below. It can be obtained and downloaded from NHTSA, free of charge, from the following web site:

[http://www.nhtsa.dot.gov/cars/rules/TireSafety/ridesonit/tires\\_index.html](http://www.nhtsa.dot.gov/cars/rules/TireSafety/ridesonit/tires_index.html)

Studies of tire safety show that maintaining proper tire pressure, observing tire and vehicle load limits (not carrying more weight in your vehicle than your tires or vehicle can safely handle), avoiding road hazards, and inspecting tires for cuts, slashes, and other irregularities are the most important things you can do to avoid tire failure, such as tread separation or blowout and flat tires. These actions, along with other care and maintenance activities, can also:

- Improve vehicle handling
- Help protect you and others from avoidable breakdowns and accidents
- Improve fuel economy

# Tire Safety Information

---

- Increase the life of your tires.

This booklet presents a comprehensive overview of tire safety, including information on the following topics:

- Basic tire maintenance
- Uniform Tire Quality Grading System
- Fundamental characteristics of tires
- Tire safety tips.

Use this information to make tire safety a regular part of your vehicle maintenance routine. Recognize that the time you spend is minimal compared with the inconvenience and safety consequences of a flat tire or other tire failure.

## **3.5.1 Safety First—Basic Tire Maintenance**

Properly maintained tires improve the steering, stopping, traction, and load-carrying capability of your vehicle. Underinflated tires and overloaded vehicles are a major cause of tire failure. Therefore, as mentioned above, to avoid flat tires and other types of tire failure, you should maintain proper tire pressure, observe tire and vehicle load limits, avoid road hazards, and regularly inspect your tires.

## **3.5.2 Finding Your Vehicle's Recommended Tire Pressure and Load Limits**

Tire information placards and vehicle certification labels contain information on tires and load limits. These labels indicate the vehicle manufacturer's information including:

- Recommended tire size
- Recommended tire inflation pressure
- Vehicle capacity weight (VCW—the maximum occupant and cargo weight a vehicle is designed to carry)
- Front and rear gross axle weight ratings (GAWR—the maximum weight the axle systems are designed to carry).

Both placards and certification labels are permanently attached to the trailer near the left front.

# Tire Safety Information

---

## **3.5.3 Understanding Tire Pressure and Load Limits**

Tire inflation pressure is the level of air in the tire that provides it with load-carrying capacity and affects the overall performance of the vehicle. The tire inflation pressure is a number that indicates the amount of air pressure—measured in pounds per square inch (psi)—a tire requires to be properly inflated. (You will also find this number on the vehicle information placard expressed in kilopascals (kPa), which is the metric measure used internationally.)

Manufacturers of passenger vehicles and light trucks determine this number based on the vehicle's design load limit, that is, the greatest amount of weight a vehicle can safely carry and the vehicle's tire size. The proper tire pressure for your vehicle is referred to as the "recommended cold inflation pressure." (As you will read below, it is difficult to obtain the recommended tire pressure if your tires are not cold.)

Because tires are designed to be used on more than one type of vehicle, tire manufacturers list the "maximum permissible inflation pressure" on the tire sidewall. This number is the greatest amount of air pressure that should ever be put in the tire under normal driving conditions.

## **3.5.4 Checking Tire Pressure**

It is important to check your vehicle's tire pressure at least once a month for the following reasons:

- Most tires may naturally lose air over time.
- Tires can lose air suddenly if you drive over a pothole or other object or if you strike the curb when parking.
- With radial tires, it is usually not possible to determine underinflation by visual inspection.

For convenience, purchase a tire pressure gauge to keep in your vehicle. Gauges can be purchased at tire dealerships, auto supply stores, and other retail outlets.

The recommended tire inflation pressure that vehicle manufacturers provide reflects the proper psi when a tire is cold. The term cold does not relate to the outside temperature. Rather, a cold tire is one that has not been driven on for at least three hours. When you drive, your tires get

# Tire Safety Information

---

warmer, causing the air pressure within them to increase. Therefore, to get an accurate tire pressure reading, you must measure tire pressure when the tires are cold or compensate for the extra pressure in warm tires.

## **3.5.5 Steps for Maintaining Proper Tire Pressure**

- Step 1: Locate the recommended tire pressure on the vehicle's tire information placard, certification label, or in the owner's manual.
- Step 2: Record the tire pressure of all tires.
- Step 3: If the tire pressure is too high in any of the tires, slowly release air by gently pressing on the tire valve stem with the edge of your tire gauge until you get to the correct pressure.
- Step 4: If the tire pressure is too low, note the difference between the measured tire pressure and the correct tire pressure. These "missing" pounds of pressure are what you will need to add.
- Step 5: At a service station, add the missing pounds of air pressure to each tire that is underinflated.
- Step 6: Check all the tires to make sure they have the same air pressure (except in cases in which the front and rear tires are supposed to have different amounts of pressure).

If you have been driving your vehicle and think that a tire is underinflated, fill it to the recommended cold inflation pressure indicated on your vehicle's tire information placard or certification label. While your tire may still be slightly underinflated due to the extra pounds of pressure in the warm tire, it is safer to drive with air pressure that is slightly lower than the vehicle manufacturer's recommended cold inflation pressure than to drive with a significantly underinflated tire. Since this is a temporary fix, don't forget to recheck and adjust the tire's pressure when you can obtain a cold reading.

## **3.5.6 Tire Size**

To maintain tire safety, purchase new tires that are the same size as the vehicle's original tires or another size recommended by the manufacturer. Look at the tire information placard, the owner's manual, or the sidewall of the tire you are replacing to find this information. If you have any doubt about the correct size to choose, consult with the tire dealer.

## Tire Safety Information

---

### **3.5.7 Tire Tread**

The tire tread provides the gripping action and traction that prevent your vehicle from slipping or sliding, especially when the road is wet or icy. In general, tires are not safe and should be replaced when the tread is worn down to 1/16 of an inch. Tires have built-in treadwear indicators that let you know when it is time to replace your tires. These indicators are raised sections spaced intermittently in the bottom of the tread grooves. When they appear "even" with the outside of the tread, it is time to replace your tires. Another method for checking tread depth is to place a penny in the tread with Lincoln's head upside down and facing you. If you can see the top of Lincoln's head, you are ready for new tires.

### **3.5.8 Tire Balance and Wheel Alignment**

To avoid vibration or shaking of the vehicle when a tire rotates, the tire must be properly balanced. This balance is achieved by positioning weights on the wheel to counterbalance heavy spots on the wheel-and-tire assembly. A wheel alignment adjusts the angles of the wheels so that they are positioned correctly relative to the vehicle's frame. This adjustment maximizes the life of your tires. These adjustments require special equipment and should be performed by a qualified technician.

### **3.5.9 Tire Repair**

The proper repair of a punctured tire requires a plug for the hole and a patch for the area inside the tire that surrounds the puncture hole. Punctures through the tread can be repaired if they are not too large, but punctures to the sidewall should not be repaired. Tires must be removed from the rim to be properly inspected before being plugged and patched.


### **3.5.10 Tire Fundamentals**

Federal law requires tire manufacturers to place standardized information on the sidewall of all tires. This information identifies and describes the fundamental characteristics of the tire and also provides a tire identification number for safety standard certification and in case of a recall.

# Tire Safety Information

## 3.5.10.1 Information on Passenger Vehicle Tires

Please refer to the diagram below.



### **P**

The "P" indicates the tire is for passenger vehicles.

### **Next number**

This three-digit number gives the width in millimeters of the tire from sidewall edge to sidewall edge. In general, the larger the number, the wider the tire.

### **Next number**

This two-digit number, known as the aspect ratio, gives the tire's ratio of height to width. Numbers of 70 or lower indicate a short sidewall for improved steering response and better overall handling on dry pavement.

### **R**

The "R" stands for radial. Radial ply construction of tires has been the industry standard for the past 20 years.

### **Next number**

This two-digit number is the wheel or rim diameter in inches. If you



## Tire Safety Information

---

change your wheel size, you will have to purchase new tires to match the new wheel diameter.

### Next number

This two- or three-digit number is the tire's load index. It is a measurement of how much weight each tire can support. You may find this information in your owner's manual. If not, contact a local tire dealer. Note: You may not find this information on all tires because it is not required by law.

### M+S

The "M+S" or "M/S" indicates that the tire has some mud and snow capability. Most radial tires have these markings; hence, they have some mud and snow capability.

### Speed Rating

The speed rating denotes the speed at which a tire is designed to be driven for extended periods of time. The ratings range from 99 miles per hour (mph) to 186 mph. These ratings are listed below. Note: You may not find this information on all tires because it is not required by law.

Letter Rating	Speed Rating
Q	99 mph
R	106 mph
S	112 mph
T	118 mph
U	124 mph
H	130 mph
V	149 mph
W	168* mph
Y	186* mph

\* For tires with a maximum speed capability over 149 mph, tire manufacturers sometimes use the letters ZR. For those with a maximum speed capability over 186 mph, tire manufacturers always use the letters ZR.

### U.S. DOT Tire Identification Number

This begins with the letters "DOT" and indicates that the tire meets all federal standards. The next two numbers or letters are the plant code

# Tire Safety Information

---

where it was manufactured, and the last four numbers represent the week and year the tire was built. For example, the numbers 3197 means the 31st week of 1997. The other numbers are marketing codes used at the manufacturer's discretion. This information is used to contact consumers if a tire defect requires a recall.

## **Tire Ply Composition and Materials Used**

The number of plies indicates the number of layers of rubber-coated fabric in the tire. In general, the greater the number of plies, the more weight a tire can support. Tire manufacturers also must indicate the materials in the tire, which include steel, nylon, polyester, and others.

## **Maximum Load Rating**

This number indicates the maximum load in kilograms and pounds that can be carried by the tire.

## **Maximum Permissible Inflation Pressure**

This number is the greatest amount of air pressure that should ever be put in the tire under normal driving conditions.

## **3.5.10.2 UTQGS Information**

### **Treadwear Number**

This number indicates the tire's wear rate. The higher the treadwear number is, the longer it should take for the tread to wear down. For example, a tire graded 400 should last twice as long as a tire graded 200.

### **Traction Letter**

This letter indicates a tire's ability to stop on wet pavement. A higher graded tire should allow you to stop your car on wet roads in a shorter distance than a tire with a lower grade. Traction is graded from highest to lowest as "AA", "A", "B", and "C".

### **Temperature Letter**


This letter indicates a tire's resistance to heat. The temperature grade is for a tire that is inflated properly and not overloaded. Excessive speed, underinflation or excessive loading, either separately or in combination, can cause heat build-up and possible tire failure. From highest to lowest, a tire's resistance to heat is graded as "A", "B", or "C".

# Tire Safety Information

---

## 3.5.10.3 Additional Information on Light Truck Tires

Please refer to the following diagram.



Tires for light trucks have other markings besides those found on the sidewalls of passenger tires.

### LT

The "LT" indicates the tire is for light trucks or trailers.

### ST

An "ST" is an indication the tire is for trailer use only.

### Max. Load Dual kg (lbs) at kPa (psi) Cold

This information indicates the maximum load and tire pressure when the tire is used as a dual, that is, when four tires are put on each rear axle (a total of six or more tires on the vehicle).

### Max. Load Single kg (lbs) at kPa (psi) Cold

This information indicates the maximum load and tire pressure when the tire is used as a single.

# Tire Safety Information

---

## **Load Range**

This information identifies the tire's load-carrying capabilities and its inflation limits.

## **3.5.11 Tire Safety Tips**

### **Preventing Tire Damage**

- Slow down if you have to go over a pothole or other object in the road.
- Do not run over curbs or other foreign objects in the roadway, and try not to strike the curb when parking.

### **Tire Safety Checklist**

- Check tire pressure regularly (at least once a month), including the spare.
- Inspect tires for uneven wear patterns on the tread, cracks, foreign objects, or other signs of wear or trauma.
- Remove bits of glass and foreign objects wedged in the tread.
- Make sure your tire valves have valve caps.
- Check tire pressure before going on a long trip.
- Do not overload your vehicle. Check the Tire Information Placard or Owner's Manual for the maximum recommended load for the vehicle.

## 4 COUPLING TO THE TOW VEHICLE

---

---

Follow all of the safety precautions and instructions in this manual to ensure safety of persons, cargo, and satisfactory life of the trailer.

### 4.1 USE AN ADEQUATE TOW VEHICLE AND HITCH

If the vehicle or hitch is not properly selected and matched to the Gross Vehicle Weight Rating (GVWR) of your trailer, you can cause an accident that could lead to death or serious injury. If you already have a tow vehicle, know your vehicle tow rating and make certain the trailer's rated capacity is less than or equal to the tow vehicle's rated towing capacity. If you already have (or plan to buy) a trailer, make certain that the tow rating of the tow vehicle is equal to or greater than that of the trailer.

#### **Danger**

Use of a hitch with a load rating less than the load rating of the trailer can result in loss of control and may lead to death or serious injury.

Use of a tow vehicle with a towing capacity less than the load rating of the trailer can result in loss of control, and may lead to death or serious injury.


Be sure your hitch and tow vehicle are rated for the Gross Vehicle Weight Rating of your trailer.

#### 4.1.1 Trailer Information

Figure 4-1 shows the location of the Vehicle Identification Number (VIN) tag on your trailer.

## Coupling To The Tow Vehicle

---



*Figure 4-1 - VIN Tag Location*

The trailer Certification / VIN tag contains the following critical safety information for the use of your trailer:

**MANUFACTURER:** Name of trailer manufacturer

**DATE OF MANUFACTURE:** Month and year the trailer was manufactured.

**GVWR:** The Gross Vehicle Weight Rating is the maximum allowable gross weight of the trailer and its contents. The gross weight of the trailer includes the weight of the trailer and all of the items within it (such as cargo and other supplies). GVWR is sometimes referred to as GTW (Gross Trailer Weight), or MGTW (Maximum Gross Trailer Weight). GVWR, GTW and MGTW are all the same rating.

**GAWR:** The Gross Axle Weight Rating is the maximum gross weight that an axle can support. It is the lowest of axle, wheel, or tire rating. Sometimes the tire or wheel rating is lower than the axle manufacturers rating, and will then determine GAWR.

The sum total of the GAWR for all trailer axles may be less than the GVWR for the trailer, because some of the trailer load is carried by the

## Coupling To The Tow Vehicle

---

tow vehicle, rather than by the trailer axle(s). The total weight of the cargo and trailer must not exceed the GVWR, and the load on an axle must not exceed its GAWR.

**TIRE SIZE:** The tire size recommended for your trailer and load range.

**PSIC:** The “pounds per square inch- cold” is the tire pressure (Kilopascals / Pounds per Square Inch) measured when Cold.

**VIN:** The Vehicle Identification Number.

**VEHICLE TYPE:** Generally the word “trailer” is used.

**CERTIFICATION STATEMENT:** “This trailer meets all the Federal Motor Vehicle Safety Standards in effect on the date of manufacture shown above”.

### **4.1.2 Tow Vehicle**

When equipping a new vehicle or an older vehicle to tow your trailer, ask the vehicle dealer for advice on how to outfit the towing vehicle. Discuss the following information and equipment with the vehicle dealer.

**Overall Carrying and Towing Capacity of Vehicle:** Vehicle manufacturers will provide you with the maximum towing capacities of their various models, as well as the GCWR. No amount of reinforcement will give a 100 horsepower, 2,500 pound truck the towing capacity that a 300 horsepower, 5,000 pound truck has.

**Towing Hitch:** The towing hitch attached to your tow vehicle must have a capacity equal to or greater than the load rating of the trailer you intend to tow. The hitch capacity must also be matched to the tow vehicle capacity.

**Suspension System:** A tow vehicle equipped with a factory installed “Towing Package” likely comes equipped with heavy duty springs, heavy duty tires and other suspension components which are able to serve the size and weight of the trailer that the vehicle is rated to tow. However, the addition of additional equipment may further improve the

## Coupling To The Tow Vehicle

---

tow vehicle performance. These may include adjustable air shocks, helper springs, etc.

**Brake Controller:** The brake controller is part of the tow vehicle and is essential in the operation of the electric brakes on the trailer. If your trailer has electric brakes it requires a brake controller be installed at the driver's position. The brake controller is not the same as the safety breakaway brake system that is installed on the trailer.

**Side View Mirrors:** The size of the trailer that is being towed and your state law regulations determine the size of the mirrors. However, some states prohibit extended mirrors on a tow vehicle, except while a trailer is actually being towed. In this situation, detachable extended mirrors are necessary. Check with your dealer or the appropriate state agency for mirror requirements.

**Heavy Duty Flasher:** A Heavy Duty Flasher is an electrical component that may be required when your trailer turn signal lights are attached to the tow vehicle flasher circuit.

**Electrical Connector:** An Electrical Connector connects the light and brake systems on the trailer to the light and brake controls on the towing vehicle.

**Heavy Duty Engine Oil Cooling System:** The tow vehicle engine works harder when a trailer is being towed. Depending on the size of the trailer, you may need to install a separate engine oil cooler. Inadequate cooling may result in sudden engine failure. Ask the tow vehicle dealer if it is necessary to install a heavy duty cooling system.

**Automatic Transmission Oil Cooler:** The automatic transmission of a towing vehicle handles more power when a trailer is being towed. Inadequate cooling will shorten transmission life, and may result in sudden transmission failure. Ask the tow vehicle dealer if it is necessary to install a separate oil cooler for the automatic transmission.

**Fire Extinguisher:** It is sensible to have a fire extinguisher in the tow vehicle.



# Coupling To The Tow Vehicle

---

**Emergency Flares and Emergency Triangle Reflectors:** It is wise to carry these warning devices even if you are not towing a trailer. It is particularly important to have these when towing a trailer because the hazard flashers of your towing vehicle will not operate for as long a period of time when the battery is running both the trailer lights and tow vehicle lights.

## **4.2 COUPLING AND UNCOUPLING THE TRAILER**

A secure coupling (or fastening) of the trailer to the tow vehicle is essential. A loss of coupling may result in death or serious injury. Therefore, you must understand and follow all of the instructions for coupling.

The following parts are involved in making a secure coupling between the trailer and tow vehicle:

**Coupling:** That part of the trailer connecting mechanism by which the connection is actually made to the trailer hitch. This does not include any structural member, extension of the trailer frame, or brake controller.

**Hitch:** That part of the connecting mechanism including the ball support platform and ball and those components that extend and are attached to the towing vehicle, including bumpers intended to serve as hitches.

**Safety chains:** Chains permanently attached to the trailer such that if the coupler connection comes loose, the safety chains can keep the trailer attached to the tow vehicle. With properly rigged safety chains, it is possible to keep the tongue of the trailer from digging into the road pavement, even if the coupler-to-hitch connection comes apart.

**Trailer lighting (and braking) connector:** A device that connects electrical power from the tow vehicle to the trailer. Electricity is used to turn on brake lights, running lights, and turn signals as required. In addition, if your trailer has a separate braking system, the electrical connector will also supply power to the trailer brakes from the tow vehicle.

## Coupling To The Tow Vehicle

---

**Breakaway switch:** If the trailer becomes de-coupled from the towing vehicle, the breakaway switch lanyard, attached independently to the tow vehicle hitch, will pull a pin in the emergency electrical break-away switch on the trailer. The breakaway switch is activated by a separate battery supply in the trailer such as to energize the trailer brakes independently of the towing vehicle. It is important to check the state of charge of the emergency break-away battery before each trip. Simply pull the pin out of the switch by hand and then try to pull the trailer. If you feel a significant drag force the brakes are activated. Be sure to re-insert the pin in the break-away switch. Also be sure to allow enough slack in the breakaway brake lanyard such that the switch will only activate (pin pulls out) if the coupler connection comes loose.

**Jack:** A device on the trailer that is used to raise and lower the trailer tongue. On larger trailers the jack is sometimes called the “landing gear.”

### WARNING

An improperly coupled trailer can result in death or serious injury.

Do not move the trailer until:

- The coupler is secured and locked to hitch;
- The safety chains are secured to the tow vehicle; and
- The trailer jack(s) are fully retracted.

Do not tow the trailer on the road until:

- Tires and wheels are checked;
- The trailer brakes are checked;
- The breakaway switch is connected to the tow vehicle;
- The load is secured to the trailer; and
- The trailer lights are connected and checked.

### 4.2.1 Various Coupler Designs

Trailers are produced with a variety of coupler devices. One of the sections below will pertain to your trailer.

# Coupling To The Tow Vehicle

---


- Bumper Pull Ball Hitch Coupler
- Bumper Pull Ball Hitch Coupler With Surge Brake
- Bumper Pull Ring Coupler
- Gooseneck Ball Coupler or King Pin

If the coupler on your trailer does not resemble one of the couplers shown in the figures, see the separate coupler instructions. If you do not have separate coupler instructions, call Bri-Mar Manufacturing LLC at 1-800-732-5845 for a free copy.

## **4.2.2 Trailer with Ball-Hitch Coupler**

A ball hitch coupler connects to a ball that is located on or under the rear bumper of tow vehicle. See figure 4-2. This system of coupling a trailer to a tow vehicle is sometimes referred to as “bumper pull.”

The tongue jack is mounted to the A-frame (front, or tongue) part of the trailer. By rotating the jack handle clockwise, the jack will extend and raise the tongue of the trailer.




*Figure 4-2 – Trailer With Ball Hitch Coupler*

---

## Coupling To The Tow Vehicle

---

Your trailer may be equipped with a Hydraulic Surge Brake system. See figure 4-3. Surge braking is accomplished by replacing a trailer's standard tongue coupler with an actuator and adding hydraulic brake assemblies. The "surge" or "push" of the trailer toward the tow vehicle during deceleration automatically synchronizes these trailer brakes with the tow vehicle brakes. As the trailer pushes against the vehicle, the actuator telescopes together and applies force to its master cylinder, supplying hydraulic pressure to the trailer's brakes.



*Figure 4-3 - Ball Hitch Coupler With Surge Brake System*

We have utilized a coupler that is suitable for the size and weight of the trailer. The load rating of the coupler and the necessary ball size are listed on the trailer tongue. You must provide a hitch and ball for your tow vehicle, where the load rating of the hitch and ball is equal to or greater than that of your trailer. Also, the ball size must be the same as the coupler size. If the hitch ball is too small, too large, is underrated, is loose or is worn, the trailer can come loose from the tow vehicle, and may cause death or serious injury.

**THE TOW VEHICLE, HITCH AND BALL MUST HAVE A RATED TOWING CAPACITY EQUAL TO OR GREATER THAN THE TRAILER Gross Vehicle Weight Rating (GVWR).**

**IT IS ESSENTIAL THAT THE HITCH BALL BE OF THE SAME SIZE AS THE COUPLER.**

## Coupling To The Tow Vehicle

---

The ball size and load rating (capacity) are marked on the ball; hitch capacity is marked on the hitch.

### **4.2.2.1 Before Coupling the Trailer to the Tow Vehicle**

Be sure the size and rating of hitch ball match the size and rating of the coupler. Hitch balls and couplers are marked with their size and rating.

#### **WARNING**

Coupler-to-hitch mismatch can result in uncoupling, leading to death or serious injury.

Be sure the **LOAD RATING** of the hitch ball is equal or greater than the load rating of the coupler.

Be sure the **SIZE** of the hitch ball matches the size of the coupler.

- Wipe the hitch ball clean and inspect it visually and by feel for flat spots, cracks and pits.

#### **WARNING**

A worn, cracked or corroded hitch ball can fail while towing, and may result in death or serious injury.

Before coupling trailer, inspect the hitch ball for wear, corrosion and cracks.

Replace worn or damaged hitch ball.

- Rock the ball to make sure it is tight to the hitch, and visually check that the hitch ball nut is solid against the lock washer and hitch frame.
- Wipe the inside and outside of the coupler clean and inspect it visually for cracks and deformations; feel the inside of the coupler for worn spots and pits.
- Be sure the coupler is tight to the tongue of the trailer. All coupler fasteners must be visibly solid against the trailer frame.

## Coupling To The Tow Vehicle

---

### WARNING

A loose hitch ball nut can result in uncoupling, leading to death or serious injury.

Make sure the hitch ball is tight to the hitch before coupling the trailer.


- Raise the bottom surface of the coupler to be above the top of the hitch ball.

#### **4.2.2.2 Prepare the Coupler and Hitch**

- Lubricate the hitch ball and the inside of the coupler with a thin layer of automotive bearing grease. If your trailer is equipped with a jack, raise the coupler above the ball height.
- Open the coupler locking mechanism. See figure 4-4.
  - In the open position, the coupler is able to drop fully onto the hitch ball.
  - See the coupler instructions for details of placing the coupler in the “open” position.
- Slowly back up the tow vehicle so that the hitch ball is near or aligned under the coupler.

## Coupling To The Tow Vehicle

---



*Figure 4-4 - Coupler Mechanism "Open"*

### **4.2.2.3 Couple the Trailer to the Tow Vehicle**

If your trailer does not have a jack, you will have to lift the coupler and place it over the ball.

- If you have a jack, lower the trailer tongue until the coupler fully engages the hitch ball. If the coupler does not line up with the hitch ball, adjust the position of the tow vehicle.
- Engage the coupler locking mechanism. In the engaged position, the locking mechanism securely holds the coupler to the hitch ball.
- Insert a pin or lock through the hole in the locking mechanism.
- Be sure the coupler is all the way on the hitch ball and the locking mechanism is engaged. A properly engaged locking mechanism will allow the coupler to raise the rear of the tow vehicle. Using the trailer jack, test to see that you can raise the rear of the tow vehicle by 1 inch, after the coupler is locked to the hitch.

## Coupling To The Tow Vehicle

### Notice

The tongue jack can be damaged by overloading. Do not use the tongue jack to raise the tow vehicle more than 1 inch.

**If the coupler cannot be secured to the hitch ball, do not tow the trailer.** Call Bri-Mar Manufacturing LLC at 1-800-732-5845 or your dealer for assistance.

- Lower the trailer so that its entire tongue weight is held by the hitch, and continue retracting the jack to its fully retracted position. Go to section 4.2.4 “Rig The Safety Chains – Bumper Pull Trailer” to continue connecting trailer to tow vehicle.

### 4.2.3 Trailer with Ring and Pintle Coupler

A ring connects to the pintle that is located on or under the rear bumper of tow vehicle. See figure 4-5. This system of coupling a trailer to a tow vehicle is sometimes referred to as “bumper pull.”




Figure 4-5 - Trailer With Ring and Pintle Coupler

We have utilized a ring that is suitable for the size and weight of the trailer. The load rating of the ring and the necessary pintle size are listed on the trailer tongue. You must provide a pintle for your tow vehicle, where the load rating of the hitch and pintle is equal to or greater than that of your trailer. Also, the pintle size must be the same as the ring size. If the pintle is too small, too large, is underrated, is loose or is worn, the trailer can come loose from the tow vehicle, and may cause death or serious injury.



## Coupling To The Tow Vehicle

---

**THE TOW VEHICLE, HITCH AND PINTLE MUST HAVE A RATED TOWING CAPACITY EQUAL TO OR GREATER THAN THE TRAILER Gross Vehicle Weight Rating (GVWR).**

**IT IS ESSENTIAL THAT THE PINTLE BE OF THE SAME SIZE AS THE COUPLER.**

The pintle size and load rating (capacity) are marked on the pintle; ring capacity is marked on the ring.

### **4.2.3.1 Before Coupling The Trailer To The Tow Vehicle**

Be sure the size and rating of hitch pintle match the size and rating of the ring. Hitch ring and pintles are marked with their size and rating.

#### **WARNING**

Coupler-to-hitch mismatch can result in uncoupling, leading to death or serious injury.

Be sure the **LOAD RATING** of the pintle is equal or greater than the load rating of the ring.

Be sure the **SIZE** of the pintle matches the size of the ring.

- Wipe the hitch pintle clean and inspect it visually and by feel for flat spots, cracks and pits.

#### **WARNING**

A worn, cracked or corroded pintle can fail while towing, and may result in death or serious injury.

Before coupling trailer, inspect the pintle for wear, corrosion and cracks.

Replace worn or damaged pintle.

- Rock the pintle to make sure it is tight to the hitch, and visually check that the pintle fasteners are solid against the hitch frame.

## Coupling To The Tow Vehicle

---

- Wipe the inside and outside of the ring clean and inspect it visually for cracks and deformations; feel the inside of the ring for worn spots and pits.
- Be sure the ring is tight to the tongue of the trailer. All ring fasteners must be visibly solid against the trailer frame.

### WARNING

A loose pintle can result in uncoupling, leading to death or serious injury. Make sure the pintle is tight to the hitch before coupling the trailer.

- Raise the bottom surface of the ring to be above the top of the open pintle.

#### **4.2.3.2 Prepare The Ring and Pintle**

- Lubricate the inside of the pintle with a thin layer of automotive bearing grease.
- Remove the safety latch pin and open the pintle locking mechanism.
  - In the open position, the ring is able to drop fully onto the pintle.
  - See the coupler instructions for details of placing the pintle in the “open” position.
- Slowly back up the tow vehicle so that the pintle is near or aligned under the ring.

#### **4.2.3.3 Couple The Trailer To The Tow Vehicle**

- Lower the trailer tongue until the ring fully engages the pintle. If the ring does not line up with the pintle, adjust the position of the tow vehicle.
- Engage the pintle locking mechanism. In the engaged position, the locking mechanism securely holds the ring to the pintle.
- Insert the safety lock pin through the hole in the locking mechanism.
- Be sure the ring is all the way on the pintle and the locking mechanism is engaged. A properly engaged locking mechanism will allow the ring to raise the rear of the tow vehicle. Using the trailer jack, test to see that you can raise the rear of the tow vehicle by 1 inch, after the pintle is locked to the ring.

---

## Coupling To The Tow Vehicle

---

### Notice

The tongue jack can be damaged by overloading. Do not use the tongue jack to raise the tow vehicle more than 1 inch.

**If the pintle cannot be secured to the ring, do not tow the trailer.**

Call Bri-Mar Manufacturing LLC, at 1-800-732-5845 or your dealer for assistance.

Lower the trailer so that its entire tongue weight is held by the hitch, and continue retracting the jack to its fully retracted position. Fully retract jack drop leg and insert pin. Go to section 4.2.4 “Rig The Safety Chains – Bumper Pull Trailer” to continue connecting trailer to tow vehicle.

#### **4.2.4 Rig the Safety Chains – Bumper Pull Trailer**

- Visually inspect the safety chains and hooks for wear or damage. Replace worn or damaged safety chains and hooks before towing.
- Rig the safety chains so that they:
  - Cris-cross underneath the coupler so if the trailer uncouples, the safety chains can hold the tongue up above the road.
  - Loop around a frame member of the tow vehicle or to holes provided in the hitch system (but, do **not** attach them to an interchangeable part of the hitch assembly)
  - Attach hooks up from underneath the hole (do not just drop into hole); and
  - Provide enough slack to permit tight turns, but not be close to the road surface to drag. See figure 4-6 or 4-7.

## Coupling To The Tow Vehicle




Figure 4-6 - Safety Chain Arrangement W/O Surge Brakes




Figure 4-7 - Safety Chain Arrangement W/ Surge Brakes

### WARNING

Incorrect rigging of the safety chains can result in loss of control of the trailer and tow vehicle, leading to death or serious injury, if the trailer uncouples from the tow vehicle.

Chains must:

- Fasten to frame of tow vehicle, not to hitch or ball.
- Cross underneath hitch and coupler with minimum slack to permit turning and to hold tongue up, if the trailer comes loose.

### **4.2.5 Connect the Electrical Cable – Bumper Pull Trailers**

Connect the trailer lights to the tow vehicle's electrical system using the electrical connectors.

## Coupling To The Tow Vehicle

---

- Check all lights for proper operation.
  - Clearance and Running Lights (Turn on tow vehicle headlights).
  - Brake Lights (Step on tow vehicle brake pedal).
  - Turn Signals (Operate tow vehicle directional signal lever).
- Check electric brakes for proper operation using brake controller mounted in the cab.

If your trailer has electric brakes, your tow vehicle will have an electric brake controller that sends power to the trailer brakes. Before towing the trailer on the road, you must operate the brake controller while trying to pull the trailer in order to confirm that the electric brakes operate. While towing the trailer at less than 5 m.p.h., manually operate the electric brake controller in the tow vehicle cab. You should feel the operation of the trailer brakes.

### WARNING

Improper electrical connection between the tow vehicle and the trailer will result in inoperable lights and electric brakes, and can lead to collision.

Before each tow:

- Check that all lights and turn signals work.
- Check that the electric brakes work by operating the brake controller inside the tow vehicle.

### **4.2.6 Attach and Test Electric Breakaway Brake System – Bumper Pull Trailers**

If the coupler or hitch fails, a properly connected and working breakaway brake system will apply electric brakes on the trailer. The safety chains will keep the tow vehicle attached and as the brakes are applied at the trailer's axles, the trailer/tow vehicle combination will come to a controlled stop.

## Coupling To The Tow Vehicle

---

The trailer breakaway brake system includes a battery, a switch with a pullpin, and a lanyard. Read and follow the instructions here.

The breakaway brake system may be fitted with a “charging” capability that draws power from the tow vehicle. If the electrical system on your tow vehicle does not provide power to the breakaway brake battery, you must periodically charge the battery to keep the breakaway brake system in working order.




Figure 4-8 - Breakaway Brake Connection

- Connect the pullpin lanyard to the tow vehicle so that the pullpin will be pulled out before all of the slack in the safety chains is taken up. See figure 4-8. Do **not** connect the pullpin cable to a safety chain or to the hitch ball or hitch ball assembly. This would keep the breakaway brake system from operating when it is needed.
- To test the breakaway brake battery remove the pullpin from the switch and attempt to pull the trailer forward. You should feel the trailer resisting being towed, but the wheels will not necessarily be locked. If the brakes do not function, do not tow the trailer until brakes, or battery, are repaired.
- Immediately replace the pullpin. The breakaway brake system battery discharges rapidly when the pullpin is removed.

## Coupling To The Tow Vehicle

### WARNING

An ineffective breakaway brake system can result in a runaway trailer, leading to death or serious injury, if the coupler or ball hitch fails.

Connect the breakaway cable to the tow vehicle; and NOT to the hitch, ball or support.

Before towing the trailer, test the function of the breakaway brake system. If the breakaway brake system is not working, do not tow the trailer. Have it serviced or repaired.

Do **not** tow the trailer with the breakaway brake system ON because the brakes will overheat which can result in permanent brake failure.

### WARNING

Failure to replace the pullpin can result in ineffective brakes, leading to loss of control, serious injury or death.

If you do not use your trailer for three or more months, or during winter months:

- Store the battery indoors; and
- Charge the battery every three months.

Replace the breakaway brake battery according to the intervals specified by battery manufacturer.

### **4.2.7 Attach and Test Surge Brake Breakaway Brake System**

If the coupler or hitch fails, the safety chains should keep the tow vehicle attached to the trailer allowing the trailer/tow vehicle combination to come to a stop.

If the safety chains also fail, a properly connected and working breakaway system will apply the hydraulic brakes on the trailer.

## Coupling To The Tow Vehicle

---

Before towing, check that the breakaway lever and chain are properly positioned. If the breakaway lever and chain are not located correctly due to either the chain being pulled during use or by accident, it **MUST** be reset prior to the trailer being moved.

See the Surge Brake service manual for the correct resetting procedure.

### **WARNING**

The breakaway system is designed to operate **ONLY** if the trailer separates completely from the tow vehicle.

**DO NOT** use the breakaway system as a parking brake.

The trailer safety chains' length **MUST** be set short enough so the actuator's breakaway chain is **NOT** pulled if the coupler separates from the tow vehicle's hitch but remains connected by the safety chains. The breakaway system will be activated if **BOTH** the trailer's coupler **AND** safety chains have failed, allowing the trailer to completely separate from the tow vehicle. Provide just enough slack in the trailer safety chains to allow tight turns. The chains should not drag on the ground. Safety chains must be used. When towing, avoid sharp turns which can cause the actuator to bind against the tow vehicle. This can damage the actuator and trailer, causing brake failure. Avoid towing across severe bumps or dips which may cause the tow hitch to lever against the actuator/coupler and compromise the connection.

### **4.2.7.1 Testing The Surge Brake Operation (If Equipped)**

Hydraulic surge actuator systems provide automatic and smooth trailer braking without special application by the tow vehicle driver. While this is extremely convenient it can sometimes be difficult to determine if the surge setup is functioning properly. The following steps provide a quick field-test to confirm that the trailer brake system is operational.



## Coupling To The Tow Vehicle

### WARNING

The field-test procedure indicates only if the trailer brake system is functional, but DOES NOT provide information on how efficiently it will operate.

Regular inspection, maintenance, and adjustment of all brake system components (including the surge actuator, tubing, hoses, brake clusters, drums, and associated hardware/support structure) are still required to ensure maximum brake performance and smooth, even brake operation.

Move the trailer to flat, level ground, pulling **FORWARD** several feet before parking. This forward motion will ensure trailers equipped with free-backing brakes are in their normal operating mode. Disconnect the trailer from the tow vehicle and jack up the trailer's tongue until it is horizontal.

Hook the trailer's safety chains (NOT the actuator's breakaway cable/chain) together to form a loop, which is centered below the actuator's coupler. Place wheel chock blocks two feet behind the trailer to prevent a runaway trailer.

Place a sturdy board, such as a 2 inch by 4 inch piece of lumber, into the chain loop below the coupler. The board should be 4 feet or longer so it will extend several feet above the actuator. Keep the end of the board a few inches off the ground, and position it to press against the front end of the actuator's coupler. Press the board towards the rear of the trailer.

Keep pressing the top of the board to stroke the actuator and its internal master cylinder. If the trailer brake system is operational, the brakes will apply and keep the trailer from rolling away from you. Properly adjusted uni-servo or duo-servo type brakes will prevent you from moving the trailer back more than a few inches. Free-backing type brakes will initially provide rolling resistance, but continued force on the board will switch them into free-backing mode, and you'll be able to move the trailer backwards.

If you have uni-servo or duo-servo brakes, and stroking the actuator (as described above) causes the trailer to roll away from you freely or with only minimal resistance, the brakes are NOT applying properly. If you have free-backing brakes and stroking the actuator (as described above)

## Coupling To The Tow Vehicle

---

causes the trailer to roll away without initial resistance, then the brakes are NOT applying properly. The brake system MUST be evaluated to determine the cause of the problem and corrective action MUST be taken before the trailer is used.

Use this procedure each time you tow your trailer to check your surge brake system operation.

### **4.2.7.2 Uncoupling a Bumper Pull Trailer**

Follow these steps to uncouple your trailer from the tow vehicle:

- Block trailer tires to prevent the trailer from rolling, before jacking the trailer up.
- Disconnect the electrical connector.
- Disconnect the breakaway brake switch lanyard or surge brake chain.
- Disconnect the safety chains from the tow vehicle.
- Unlock the coupler and open it.
- Before extending jack, make certain the ground surface below the jack pad will support the tongue load.
- Rotate the jack handle (or crank) clockwise. This will slowly extend the jack and transfer the weight of the trailer tongue to the jack. Raise the trailer coupler above the tow vehicle hitch.

### **4.2.8 Gooseneck Trailer with Ball Coupler or King Pin**

A gooseneck trailer with a ball coupler on the trailer connects to a gooseneck ball that you must have installed in the bed of the tow vehicle. See figure 4-9. A gooseneck trailer with a king pin on the trailer connects to a fifth wheel that you must have installed in the bed of the tow vehicle. This system of coupling a trailer to a tow vehicle permits the tow vehicle to turn to sharper angles than are permitted by a bumper hitch system. A gooseneck coupler consists of a tube in an inverted “U” shape and a gooseneck ball receiver. The operation of the gooseneck trailer is the same for the ball and king pin attachment with the exception of the hitch connection. See your fifth wheel instructions provided by the manufacturer for connecting, disconnecting and locking information.

## Coupling To The Tow Vehicle

---



*Figure 4-9- Gooseneck Trailer With Ball Coupler*

We have utilized a gooseneck ball receiver that is suitable for the size and weight of the trailer. The load rating of the coupler and the necessary ball size are listed on the gooseneck.

You must provide a gooseneck ball and support structure that is marked with a rating that meets or exceeds the GVWR of your trailer **and** matches the size of the gooseneck ball receiver. If the gooseneck ball is too small, is underrated, is loose or is worn, the trailer can come loose from the tow vehicle, and may lead to death or serious injury.

**THE TOW VEHICLE, SUPPORT STRUCTURE AND GOOSENECK BALL MUST HAVE A RATED TOWING CAPACITY EQUAL TO OR GREATER THAN THE TRAILER Gross Vehicle Weight Rating (GVWR).**

**IT IS ESSENTIAL THAT THE GOOSENECK BALL BE OF THE SAME SIZE AS THE GOOSENECK BALL RECEIVER.**

The ball size and load rating (capacity) are marked on the ball; hitch capacity is marked on the hitch.

## Coupling To The Tow Vehicle


### WARNING

Coupler-to-hitch mismatch can result in uncoupling, leading to death or serious injury.

Be sure the **LOAD RATING** of the hitch ball is equal or greater than the load rating of the coupler.

Be sure the **SIZE** of the hitch ball matches the size of the coupler.

A gooseneck trailer will have one or two drop leg jacks for raising and lowering the receiver. See figure 4-10. Because several drop leg jack mechanisms are available, the general instructions below may vary slightly from the jack manufacturer's instructions. If the trailer jack on your trailer does not resemble the jack shown in the figures, follow the jack instructions provided by the jack manufacturer. If you do not have these instructions, call Bri-Mar Manufacturing LLC at 1-800-732-5845 for a free copy.



*Figure 4-10 - Gooseneck Trailer With Drop Leg Jack*

Before attempting to tow the trailer:

- Be sure the size and rating of the gooseneck ball match the size and rating of the receiver. Gooseneck balls and receivers are marked with their size and ratings.

## Coupling To The Tow Vehicle

---

- Wipe the gooseneck ball clean and inspect it visually and by feel for flat spots, cracks and pits.

### WARNING

A worn, cracked or corroded gooseneck ball can fail while towing, and may result in death or serious injury.

Before coupling the trailer, inspect the gooseneck ball for wear, corrosion and cracks; and replace worn or damaged gooseneck ball.

- Rock the ball to make sure it is tight to the ball support, and visually check that the gooseneck ball nut is solid against the lock washer and ball support frame.

### WARNING

A loose gooseneck ball can result in uncoupling, leading to death or serious injury.

Make sure the gooseneck ball nut is tight before coupling the trailer.

- Wipe the inside and outside of the receiver clean and inspect it visually for cracks; and feel the inside of the receiver for worn spots and pits. If any of these conditions exist, have the receiver replaced before coupling the trailer.
- Lubricate the inside of the gooseneck ball receiver with automotive bearing grease.
- Be sure the receiver is tight to the trailer. All receiver fasteners must be visibly solid against the trailer frame.
- Release the jack handle or crank from its holder.
- Rotate the handle/crank clockwise to raise the bottom surface of the gooseneck to be above the top of the gooseneck ball.

### **4.2.8.1 Prepare the Gooseneck Receiver**

- Release the lock plate on the gooseneck ball receiver. With the spring-loaded lock plate locking pin in the OPEN position, rotate the lock plate to a position that allows the gooseneck ball to enter the receiver.

## Coupling To The Tow Vehicle

---

- Slowly back up the tow vehicle so that the ball is aligned under the gooseneck ball receiver.

### WARNING

If the trailer drops during coupling, death or serious injury may result.

There must be no one under the trailer or coupler before or during the coupling operation.

### **4.2.8.2 Couple the Trailer to the Tow Vehicle**

- Rotate the jack handle counter-clockwise. This will retract the jack causing the receiver to drop down so it can fully engage the gooseneck ball and transfer the weight of the trailer tongue to the towing vehicle hitch. If the receiver does not line up with the ball, raise the receiver again and adjust the position of the tow vehicle. Then lower the receiver over the ball. When the drop leg base is no longer resting on the ground, the towing vehicle hitch is holding all of the weight of the trailer tongue.
- Close the lock plate on the gooseneck ball receiver.
- Move the spring-loaded lock plate locking pin to the CLOSED position. Be sure the locking pin is holding the lock plate.
- Be sure the receiver is all the way on the gooseneck ball and the lock plate is engaged. A properly engaged locking mechanism will allow the coupler to raise the rear of the tow vehicle. Using the trailer jack, test to see that you can raise the rear of the tow vehicle by 1 inch.

### Notice

The drop leg jack can be damaged by overloading. Do not use the drop leg jack to raise the tow vehicle more than 1 inch.

**If the gooseneck ball cannot be secured to the receiver, do not tow the trailer.** Call Bri-Mar Manufacturing LLC at 1-800-732-5845 or your dealer for assistance.

## Coupling To The Tow Vehicle

---

- After testing to see that the receiver is properly secured and locked to the ball, retract the jack to its fully retracted position.
- Return the drop legs to their upper positions. The drop legs are held in the lowered position with a plunger pin. Rotating the plunger pin while pulling it outward will cause it to come out of engagement with the drop leg and the leg will rapidly rise.

### **Caution**

The drop legs are heavily spring loaded in the lowered position. They will rapidly return to the upper position when released and can inflict serious bruises, scrapes or pinching.

Keep your feet, shins and hands well clear of the drop legs and drop leg bases when releasing the drop legs.

#### **4.2.8.3 Rig the Safety Chains**

- Visually inspect the safety chains and hooks for wear or damage. Replace worn or damaged safety chains and hooks before towing.
- Rig the safety chains so that they attach to the “safety chain receivers” in the bed of the truck. See figure 4-11. If you are not certain of the hitch provisions for receiving safety chains, contact the hitch manufacturer or installer. Do NOT attach the safety chains to the gooseneck ball or its support; and
- Rig the safety chains so they have sufficient slack to permit turning, but not too much slack – the safety chains must keep the gooseneck on the tow vehicle bed if the trailer uncouples.

## Coupling To The Tow Vehicle




Figure 4-11 – Proper Safety Chain Arrangement

### WARNING

Improper rigging of the safety chains can result in loss of control of the trailer and tow vehicle, leading to death or serious injury, if the trailer uncouples from the tow vehicle.

- Fasten chains to safety chain receivers on the hitch, not to ball.
- Have sufficient slack to permit turning and to keep gooseneck on bed of the tow vehicle, if the trailer comes loose.

#### **4.2.8.4 Attach and Test the Breakaway Brake System**

If the coupler or hitch fails, a properly connected and working breakaway brake system will apply electric brakes on the trailer. See figure 4-12. The safety chains will keep the tow vehicle attached and as the brakes are applied at the trailer's axles, the trailer/tow vehicle combination will come to a controlled stop.

Read and follow the instructions here as well as the instructions that have been prepared by the breakaway brake controller manufacturer. If you do not have these instructions, call Bri-Mar Manufacturing LLC at 1-800-732-5845 for a free copy.



## Coupling To The Tow Vehicle

---




Figure 4-12 – Connect Breakaway Brake Lanyard

The breakaway brake system may be fitted with a charging line that draws power from the tow vehicle through the connector. If the electrical system on your tow vehicle does not provide power to the breakaway brake battery you must periodically charge the battery on the trailer to keep the breakaway brake system in working order.

- Visually inspect the breakaway brake system for broken parts.
- Connect the pullpin lanyard to the tow vehicle so that the pullpin will be pulled out before all of the slack in the safety chains is taken up (see “Safety Chains” figure). Do **not** connect the pullpin lanyard to a safety chain or a safety chain receiver or to the gooseneck ball or its support. This would keep the breakaway brake system from operating when it is needed. Contact the hitch manufacturer or installer if you are not certain of the hitch provisions for breakaway brake connection
- To check the breakaway brake battery pull out the pullpin from the switch and attempt to pull the trailer forward. You should feel the trailer resisting being towed, but the wheels will not necessarily lock up.

## Coupling To The Tow Vehicle

---

- Immediately replace the pullpin. The breakaway brake system battery discharges rapidly when the pullpin is removed.

### WARNING

An ineffective or inoperative breakaway brake system can result in a runaway trailer leading to death or serious injury if the coupler or hitch fails.

Connect the breakaway lanyard to the tow vehicle; and NOT to the safety chain, safety chain receiver, gooseneck ball or gooseneck ball support.

Test the function of the breakaway brake system before towing the trailer. Do not tow the trailer if the breakaway brake system is not working. Have it serviced or repaired.

Do **not** tow the trailer with the breakaway brake system ON because the brakes will overheat which can result in permanent brake failure.

### WARNING

Failure to replace the pullpin can result in ineffective brakes, leading to loss of control, serious injury or death.

If you do not use your trailer for three or more months, or during winter months:

- Store the battery indoors; and
- Charge the battery every three months.

Replace the breakaway brake battery at intervals recommended by the battery manufacturer's instructions.

### **4.2.8.5 Connect the Electrical Cable**

Connect the trailer lights to the tow vehicle's electrical system using the electrical connectors.

- Check all lights for proper operation:

## Coupling To The Tow Vehicle

---

- Clearance and Running Lights (Turn on tow vehicle headlights).
  - Brake Lights (Step on tow vehicle brake pedal).
  - Turn Signals (Operate tow vehicle directional signal lever).
- 
- Check electric brakes for proper operation

If your trailer has electric brakes, your tow vehicle will have an electric brake controller that sends power to the trailer brakes. Before towing the trailer on the road, you must operate the brake controller while trying to pull the trailer in order to confirm that the electric brakes operate. While towing the trailer at less than 5 m.p.h., manually operate the electric brake controller in the tow vehicle cab. You should feel the operation of the trailer brakes.

### WARNING

Improper electrical connection between the tow vehicle and the trailer will result in inoperable lights and electric brakes, and can lead to collision.

Before each tow:

- Check that all lights and turn signals work
- Check that the electric brakes work by operating the brake controller inside the tow vehicle

### **4.2.8.6 Uncoupling the Gooseneck Trailer**

Follow these steps to uncouple your gooseneck trailer from the tow vehicle:

- Block trailer tires to prevent the trailer from rolling, before jacking the trailer up.
- If the tow vehicle has a tailgate, lower it.
- Disconnect the electrical connector.
- Disconnect the breakaway brake switch lanyard.
- Disconnect the safety chains from the tow vehicle.
- Move the spring-loaded gooseneck receiver lock plate locking pin to the OPEN position

## Coupling To The Tow Vehicle

---

- Rotate the lock plate to a position that permits the gooseneck ball to exit the receiver.
- Before releasing dropleg jack, make certain ground surface below jack base will support the trailer tongue load.
- Rotate the drop leg plunger pin handle so that the plunger pin is released from the drop leg.
- Push down on the drop leg base with your foot to place a drop leg to the desired lowered position.
- Rotate the plunger pin handle so that the plunger pin is attempting to engage the drop leg.
- Slowly raise your foot, permitting the drop leg to raise. The plunger pin will engage a hole in the drop leg.

### Caution

The drop legs are heavily spring loaded in the lowered position. They will rapidly return to the upper position when released and can inflict serious bruises, scrapes or pinching.

Keep your feet, shins and hands well clear of the drop legs and drop leg bases when releasing the drop legs.

Always wear shoes or boots while performing this operation

- Be sure the plunger pin is fully engaged. Push it in by hand if necessary. The bent part of the plunger pin handle must be touching the plunger pin housing.
- If your trailer has two drop leg jacks, lower them both to the same level, following the above instructions.

### Notice

If the drop legs are not set at the same level, one of the drop leg jacks can be overloaded and can be damaged.

- Release the handle (or crank) from its holder and engage it with the jack shaft.
- Rotate the handle (or crank) clockwise to slowly extend the jack and transfer the weight of the trailer tongue to the jack.

## Coupling To The Tow Vehicle

---

- On two speed jacks, pushing the handle shaft toward the gearbox can perform rapid extension. This shifts the gearbox into a high speed mode.
- When the drop leg base contacts the ground, shift the gearbox into low speed mode by pulling out on the handle shaft until it locks into low gear.

### Notice

Do not use high speed to lift the trailer, the drop leg jack mechanism can be damaged.

High speed is used only to rapidly move the drop leg base into contact with the ground.

- Continue to extend the jack(s), making sure that the ground is providing stable and level support for the trailer.
- After the jack(s) are extended and the gooseneck ball receiver is well clear of the gooseneck ball, to permit driving the tow vehicle away, disengage the handle from its shaft and return to its holder.

### 4.3 ADJUST HITCH HEIGHT

The height of the hitch on the trailer must be adjusted so that the trailer, when loaded to rated capacity, is level while connected to the tow vehicle. A level trailer allows equal weight distribution on the axles.

Your dealer or a trailer service center can perform this adjustment or you can use the following steps to adjust the hitch height yourself.

### WARNING

Improper hitch height adjustment can result in overloaded tires, blowout and loss of control, leading to death or serious injury.

Adjust the hitch height so that the loaded trailer is level.

## Coupling To The Tow Vehicle

- Connect trailer to tow vehicle and load the trailer to rated capacity (see Loading and Unloading The Trailer).
- Park the tow vehicle and trailer on a firm level surface.
- Stand away from the trailer and visually verify if the trailer is level front-to-rear. If the front of the trailer is higher than the rear, the hitch must be raised. If the front of the trailer is lower than the rear, the hitch must be lowered.
- Uncouple trailer from tow vehicle (See Uncoupling a Bumper Pull Trailer).
- Remove the lock nuts (1) and cap screws on hitch. **Discard** lock nuts. See figure 4-13.




Figure 4-13 – Adjust Hitch Height

### **WARNING**

Used lock nuts are prone to loosen, resulting in the hitch separating from the trailer, which can lead to death or serious injury.

NEVER re-use a lock nut.

Two new lock nuts are provided with your trailer to use for the hitch adjustment. Use new lock nuts each time the hitch height is adjusted.

Contact your dealer for the proper grade and size of lock nut.

- Raise or lower the hitch as necessary.

## Coupling To The Tow Vehicle

---

- Install cap screws and **NEW** lock nuts (A). See figure 4-13.
- Tighten lock nuts to 113 lb. ft. of torque.
- Couple the trailer to the tow vehicle, verify that the trailer is level front to rear. Adjust if necessary.
- Unload trailer (see Loading and Unloading The Trailer) and disconnect from tow vehicle (see Uncoupling a Bumper Pull Trailer).

### **4.4 ADJUST GOOSENECK HEIGHT**


The height of the ball receiver on the trailer must be adjusted so that the trailer, when loaded to rated capacity, is level while connected to the tow vehicle. A level trailer allows equal weight distribution on the axles. There must also be adequate clearance between the bottom of the trailer and the sides of the tow vehicle bed.

Connect trailer to tow vehicle (see Coupling To The Tow Vehicle) and load the trailer to rated capacity (see Loading and Unloading The Trailer). Park the tow vehicle and trailer on a firm level surface.

Stand back from the trailer and visually verify if the trailer is level front-to-rear. If the front of the trailer is higher than the rear, the hitch must be retracted. If the front of the trailer is lower than the rear, the hitch must be extended.

Uncouple trailer from tow vehicle (See Coupling To The Tow Vehicle).

## Coupling To The Tow Vehicle



Gooseneck Height Adjustment - Figure 4-14

Loosen the jam nut and bolt (1). Remove locking pin (2). Extend or retract the receiver as needed. The maximum the receiver can be extended is 8 inches. See figure 4-14.

Reinstall locking pin (2). Tighten bolt (1) to 150-170 lb. ft. of torque. Tighten jam nut to 80-90 lb. ft. of torque prevent bolt from loosening.

### WARNING

Improper gooseneck height adjustment can result in overloaded tires, blowout and loss of control, leading to death or serious injury.

Adjust the gooseneck receiver so that the trailer runs level.



# 5 LOADING AND UNLOADING THE TRAILER

---

Improper trailer loading causes many accidents and deaths. To safely load a trailer, you must consider:

- Overall load weight;
- Load weight distribution;
- Proper tongue weight; and
- Securing the load properly.

To determine that you have loaded the trailer within its rating, you must consider the *distribution* of weight, as well as the total weight of the trailer and its contents. The trailer axles carry most of the total weight of the trailer and its contents (Gross Vehicle Weight, or “GVW”). The remainder of the total weight is carried by the tow vehicle hitch. It is essential for safe towing that the trailer tongue and tow vehicle hitch carry the proper amount of the loaded trailer weight, otherwise the trailer can develop an undesirable sway at towing speeds, or the rear of the towing vehicle can be overloaded.

The load distribution must be such that no component part of the trailer is loaded beyond its rating. This means that you must consider the rating of the tires, wheels and axles. For tandem and triple axle trailers, you must make sure that the front-to-rear load distribution does not result in overloading any axle.

Towing stability also depends on keeping the center of gravity as low as possible. Load heavy items on the floor and over the axles. When loading additional items, be sure to maintain even side-to-side weight distribution and proper tongue weight. The total weight of the trailer and its contents must never exceed the total weight rating of the trailer (Gross Vehicle Weight Rating, or “GVWR”).

## **5.1 TONGUE WEIGHT**

It is critical to have a portion of the trailer load carried by the tow vehicle. That is, the trailer tongue must exert a downward force on the hitch. This is necessary for two reasons. First, the proper amount of

## Loading And Unloading The Trailer

---

tongue weight is necessary for the tow vehicle to be able to maintain control of the tow vehicle/trailer system. If, for example, the tongue exerts an upward pull on the hitch, instead of pushing down on it (because the trailer is overloaded behind its axle(s)), the rear wheel of the tow vehicle can lose traction or grip and cause loss of control. Also, even if there is some weight on the tongue, but not enough weight on the tongue, the trailer can become unstable at high speeds. Remember, the faster you go the more likely the trailer is to sway.

If, on the other hand, there is too much tongue weight, the tow vehicle is prone to jack-knife. Furthermore, the front wheels of the tow vehicle can be too lightly loaded and cause loss of steering control and traction, if the front wheels are driving.

In addition to tow vehicle control, tongue weight is necessary to insure that the trailer axle(s) do not exceed their Gross Axle Weight Rating (GAWR).

In the following table, the second column notes the rule of thumb percentage of total weight of the trailer plus its cargo (Gross Vehicle Weight, or “GVW”) that should appear on the tongue of the trailer. For example, a trailer with a gooseneck hitch, with a loaded weight of 12,000 pounds, should have 20-25% of 12,000 pounds on the tongue. That is, the example trailer would have 2,400 to 3,000 pounds on its tongue.

# Loading And Unloading The Trailer

Tongue Weight as a Percentage of Loaded Trailer Weight	
Type of Hitch	Percentage
Ball Hitch (or Bumper Hitch)	10-15% for large trailers 6-10% for smaller utility and cargo trailers
Gooseneck Hitch	20-25%
Fifth Wheel Hitch	

## WARNING

Improper tongue weight (load distribution) can result in loss of control of the trailer, leading to death or serious injury.

Make certain that tongue weight is within the allowable range.

Be sure to:

- Distribute the load front-to-rear to provide proper tongue weight (see chart);
- Distribute the load evenly, right and left, to avoid tire overload; and
- Keep the center of gravity low.

## 5.2 CHECKING TONGUE WEIGHT

To check the tongue weight, the tow vehicle and trailer must be on level ground, as they will be when the trailer is being towed.

For lighter trailers the recommended method of checking tongue weight is to use an accessory called a “tongue weight scale.” If a tongue weight scale is not available from your dealer, call Bri-Mar Manufacturing LLC at 1-800-732-5845 for assistance.

---

## Loading And Unloading The Trailer

---

An alternate method of checking tongue weight involves the use of a bathroom scale. The loaded trailer must be on a smooth and level surface, and you must block the trailer wheels, front and rear.

### WARNING

An unrestrained trailer can fall off its support, resulting in serious injury or death.

Block trailer wheels, front and rear, before checking tongue weight.

For most trailers it is easier to go to a truck stop where there is a “certified” scale. Pull the tow vehicle only onto the scale and get the weight. This weight must be less than your tow vehicle’s GVWR. Pull the trailer onto the scale and decouple it from the tow vehicle, leaving just the trailer on the scale. Get a “ticket”, which lists the total trailer weight. Re-connect the trailer to your tow vehicle and drive the tow vehicle wheels off the scale, just leaving the trailer axles on the scale. Get a second “ticket”, which lists the trailer’s axle weight. Simply subtract the axle weight from the total weight to determine the hitch weight.

While you are at the scale, you should weigh the entire combination vehicle. This result should be less than the Gross Combined Weight Rating (GCWR) for your towing vehicle. Some scales allow you to get individual axle weights also. If this is possible, get the tow vehicles front and rear axle weights to make sure they are in the same proportion as the tow vehicle alone, and that the rear axle is not overloaded. This is the best way to check that a weight distribution (or load leveling) hitch is adjusted properly, i.e., you have the proper number of chain links attached to the snap-up brackets.

### **5.3 LOADING TRAILER**

Couple the trailer to the tow vehicle before loading. This is essential for the bumper pull trailer because the tongue of a bumper pull trailer can rise during loading, before the cargo is properly distributed. To measure the tongue weight, you will have to uncouple the trailer after it is loaded.

## Loading And Unloading The Trailer

---

Do not transport people, containers of hazardous substances, cans or containers of flammable substances, such as gasoline, kerosene, paint, etc. However, fuel in the tank of an off-road vehicle, or a car or motorcycle, etc. may be carried on your trailer.

### WARNING

Do not transport flammable, explosive, poisonous or other dangerous materials in your trailer. The exception is fuel in the tank of vehicles or equipment that are being hauled.

### 5.3.1 Preparing the Trailer for Loading

Before loading cargo onto the trailer:

- Inspect the deck of the trailer for corrosion or damage; and
- Inspect the hold down openings and/or “D”-rings. Hold down openings must be sturdy with no visible cracks or kinks. D-rings must be tight to the deck and must not be bent.

If the deck or any required hold-down is damaged, do not load the cargo. Bring the trailer to your dealer or a competent repair service before using it to carry cargo.

### WARNING

Damaged or loose “D”-rings can break, allowing cargo to become loose inside the trailer. Loose cargo can shift the center of gravity, and result in loss of control of the trailer.

Inspect “D”-rings, and test them for looseness before loading cargo.

Do not use a damaged or loose “D”-ring to secure cargo.

### 5.3.2 Loading a Rigid Deck Trailer

Flatbed trailers have either a rigid deck or a tilt deck, depending on the exact model. This subsection describes loading a rigid deck trailer.

# Loading And Unloading The Trailer

---

Before loading a rigid deck trailer, couple the trailer to the tow vehicle and make sure the rigid-deck is level. Do not load or unload the trailer when the deck is not level.

Your trailer may be equipped with removable ramps or fold down ramps. Make sure the top of the ramp (or ramps) is secure to the trailer, and the bottom is resting on firm ground.

## Caution

The weight of each loading ramp is 60 lbs.

Use a safe lifting procedure to prevent personal injury when handling ramps.

- **Removable Ramps:** Release pin (1) and pull ramp (2) rearward. See figure 5-1. Place pins on ramps into holes on rear of trailer. Several holes are provided. Use holes as needed based on the width of equipment to load.




Figure 5-1 - Removable Ramps

**Fold Down Ramp:** Remove pins (1) and strap (2). Lay ramp down. See figure 5-2.

## Loading And Unloading The Trailer



Figure 5-2 – Fold Down Ramp

### WARNING

Load can suddenly move or topple, which can result in death or serious injury.

Do not load or unload your open trailer unless it is prevented from tipping and is on firm and level ground.

- Load the cargo onto the trailer with approximately 60% of the cargo on the front half of the trailer.
- Secure the cargo to the trailer using appropriate straps, chains and tensioning devices. Refer to [www.fmsca.dot.gov](http://www.fmsca.dot.gov) for regulations regarding cargo securement rules.

### WARNING

Shifting cargo can result in loss of control of the trailer, and can lead to death or serious injury.

Tie down all loads with proper sized fasteners, ropes, straps, etc.

# Loading And Unloading The Trailer

---

- Return the ramp(s) to their stowed position(s), and secure them so that they will not move during transit.

## 5.3.3 **Loading a Non-Powered Tilt Deck Trailer**

Your trailer may be equipped with a non-powered tilt deck. The pivoting feature allows for easier loading and unloading. See figure 5-3.



*Figure 5-3 – Tilt Deck Trailer*

The tilt deck trailer is fitted with a spring-loaded catch that keeps the trailer in the driving position. After the trailer is loaded and the cargo is secured with hold downs, be sure the spring-loaded catch has locked the trailer into “driving position.”

- Couple the trailer securely to the tow vehicle before attempting to unlock the deck and load the trailer.
- Unlock the deck and pivot it to the loading position. See figure 5-3. Before loading the cargo, be certain the deck catch pin is retracted. Keep bystanders away from trailer while loading and unloading.

### **WARNING**

Loading a pivoting-deck trailer before retracting the deck catch pin can crack the catch pin, which can cause loss of cargo or loss of control of the trailer. Death or serious injury may result.

Before loading the trailer, retract the deck catch pin.

If the deck catch pin becomes bent, do not straighten it. Replace the deck catch pin before towing the load.

- Load the cargo onto the trailer with approximately 60% of the cargo in the front half of the bed. As the cargo is moved forward on the deck, the deck will pivot down into the driving position.



## Loading And Unloading The Trailer

---

- Extend the deck catch pin into the deck to lock the deck into the driving position. Ensure that the catch engages the hole in the pivoting deck.

### WARNING

An unlocked pivoting deck can result in loss of cargo or loss of control of the trailer, which can result in death or serious injury.

Before towing the trailer:

- Lock the pivoting deck in the driving position.
  - Double-check that the catch engages the hole in the pivoting deck.
- 
- Secure the cargo onto the trailer using appropriate straps and tensioning devices. Refer to [www.fmsca.dot.gov](http://www.fmsca.dot.gov) for regulations regarding cargo securement rules.

### WARNING

Shifting cargo can result in loss of control of the trailer, and can lead to death or serious injury.

Tie down all loads with proper sized fasteners, ropes, straps, etc.

### **5.3.4 Loading a Hydraulic Tilt Deck Trailer**

Your trailer is equipped with a DC power unit, hydraulic pump and cylinder that tilts the trailer deck for loading and unloading. See figure 5-4.

# Loading And Unloading The Trailer



Figure 5-4 - Hydraulic Tilt Deck Trailer

## Hazards For Hydraulic Tilt Trailers

The major hazards associated with hydraulic tilt trailers are:

- Getting under a raised trailer deck.
- Modifying or altering hydraulic components.

### Danger

**NEVER** alter or substitute any hydraulic system component. Death or serious injury may result.

An altered or component substituted hydraulic system may malfunction, resulting in the dump body falling without warning.

**NEVER** alter or substitute any hydraulic system component.

### Danger

A lowering or falling hydraulic tilt deck trailer can result in death or serious injury.

**NEVER** enter the area under a raised deck.

All service and maintenance must be performed with the tilt deck lowered in the driving position.

- Read and understand the operating procedure before operating the tilt deck.
- Clear the area around the trailer.

## Loading And Unloading The Trailer

---

- Park the tow vehicle and trailer on a firm and level surface both left / right and front / rear. Attempting to unload on a soft or uneven surface may cause the trailer to overturn, which can result in death or serious injury.
- While using the tilt deck controller, position yourself in a safe location clear of the trailer.
- If trailer is equipped with a wireless remote dump control, turn the remote “on” at the remote control module in the battery box.
- Press and hold button (1) to raise the tilt deck. Release the button when the rear of the deck is touching the surface. See figure 5-5.




Figure 5-5 - Remote or Pendent Dump Controller

- Return the controller to the battery box.
- Load the cargo. The operator must be experienced and skilled to perform the loading.
- Press and hold button (2) to lower the tilt deck. See figure 5-5. Release the button when the tilt deck is fully lowered. Place

## Loading And Unloading The Trailer

---

controller in the battery box and turn off wireless remote (if equipped).

- Secure the cargo to the trailer using appropriate straps, chains and tensioning devices. Refer to [www.fmsca.dot.gov](http://www.fmsca.dot.gov) for regulations regarding cargo securement rules.

### WARNING

Shifting cargo can result in loss of control of the trailer, and can lead to death or serious injury.

Tie down all loads with proper sized fasteners, ropes, straps, etc.

# 6 CHECKING THE TRAILER BEFORE AND DURING EACH TOW

---

---

## 6.1 PRE-TOW CHECKLIST

Before towing, double-check all of these items:

- Tires, wheels and lug nuts (see the “Major Hazards” section starting on page 6 of this manual)
- Tire Pressure. Inflate tires on trailer and tow vehicle to the pressure stated on the Certification / VIN label of the vehicle.
- Coupler secured and locked (see the “Coupling Trailer To Tow Vehicle” section starting on page 45 of this manual)
- Safety chains properly rigged to tow vehicle, not to hitch or ball (see the “Coupling to the Tow Vehicle” section starting at Page 47 of this manual)
- Test Tail, Stop, and Turn Lights
- Test trailer brakes.
- Safety breakaway switch cable fastened to tow vehicle, not to safety chains (see the “Coupling to the Tow Vehicle” chapter starting at Page 47 of this manual)
- Cargo properly loaded, balanced and tied down (see the “Loading The Trailer” section starting at page 83 of this manual)
- Tongue weight and weight distribution set-up.
- Ramps latched and secured
- Fire extinguisher
- Flares and reflectors
- Check fuses in battery box. One fuse is for the electric breakaway brake and the other is for the DC power unit.

## 6.2 MAKE REGULAR STOPS

After each 50 miles, or one hour of towing, stop and check the following items:

- Coupler secured

## Checking The Trailer Before And During Each Tow

---

- Safety chains are fastened and not dragging
- Cargo secured
- Cargo door latched and secured

# 7 ACCESSORIES

---

---

This chapter provides some basic information for the safe operation of several accessories. For many accessories, such as generators and LP appliances, the manufacturer of the accessory has also provided instructions. You must read and follow these instructions before using the accessory. If you are uncertain whether you have all of the instructions, call Bri-Mar Manufacturing LLC at 1-800-732-5845 before operating the accessory. The following accessories are described in this section:

- Accessory Battery
- Battery Charger
- DC Hydraulic Power Unit

Many accessories introduce the risk of fire and carbon monoxide poisoning. If you have an accessory on your trailer, make sure you have a fire extinguisher charged and ready before operating the accessory. Check the fire extinguisher at least once a month. If the fire extinguisher is discharged even partially, it must be recharged. Follow the fire extinguisher manufacturer's instructions for recharging the extinguisher after use.

## 7.1 ACCESSORY BATTERY

Your trailer may be outfitted with an accessory battery that operates the DC Power unit or other accessories. A fully charged battery will insure proper operation.

If you do not plan to be using the trailer for an extended period, remove the cables from the battery terminals.

The accessory battery must be kept in a charged condition during storage. The battery could freeze and break if it becomes discharged.

# Accessories

## 7.2 BATTERY CHARGER

Your trailer may be equipped with a battery charger to charge the battery. Caution should be used when charging batteries. Batteries produce explosive gas during normal operation. Do not smoke, create sparks or open flames near battery compartment. Batteries contain sulfuric acid which can cause severe burns and blindness if exposed to skin or eyes. Always use eye and skin protection when working around batteries.

Make sure that the connections to the battery are tight. Connect charger to a 120 volt outlet using a grounded extension cord designed for outdoor use. Plug into a “GFI” ( Ground Fault Interrupted ) receptacle to prevent possible shock.

### WARNING

To reduce the risk of explosion, explosive gases, or injury while using your battery charger, follow the precautions listed below:

Read all instructions and cautions printed on the battery charger and battery.

Connect the charger with a 3 prong (grounded) outdoor power cord to a “GFI” outlet.

Always charge battery in a well ventilated area.

To reduce risk of electrical shock, unplug the charger from the outlet before attempting any maintenance or cleaning.

Do not operate the charger if it has a damaged power cord or plug. Have the cord replaced.

The charger contains an electronic control that safeguards against overcharging the battery. You may observe the following conditions during charging operations:

Light Color	On / Off	Condition
Green	Off	No power. Check wall receptacle for 120 volts.



## Accessories

---

Green	On	AC power is present.
Red	On	Battery charge is approximately 14 volts and charging has stopped.
Red	Off	Battery voltage has dropped one volt and the charging has resumed.

The On/Off cycle of the red light will continue, the red light will stay on for longer periods of time as the battery becomes more fully charged. The battery must be at least 2 volts to start the charging cycle. The green light will be lit even if the battery is not charging. You can verify charging by measuring the battery voltage and noting an increase in voltage.

The charger is ideal for maintaining a battery charge. It is recommended to charge large batteries with a higher capacity charger first and use the trailer charger to maintain the battery after it has been charged.

### **7.3 DC HYDRAULIC POWER UNIT**

A DC hydraulic power unit is used on powered tilt deck trailers. The trailers use a dual acting power up and power down cylinder. The control is located in the battery box in the front of the trailer. Use the pushbutton control to raise and lower the tilt deck.

The hydraulic system is under extreme pressure. Pressure will be in the hydraulic cylinder and lines even when the power unit is not operating. Never disconnect a hydraulic line or fitting while the tilt deck is raised. Lower the tilt deck to the travel position before disconnecting a hydraulic line or fitting. Refer to the service section for additional information on this unit. A manual is also available from Bri-Mar Manufacturing LLC for service information on your power unit.

## Accessories

---

### WARNING

Hydraulic system is under extreme pressure. To reduce the risk of injury, follow the precautions listed below:

Always wear eye protection and protective clothing when working around hydraulic systems.

Remove jewelry and objects that might conduct electricity while working on power units.

Fluid under pressure can pierce the skin and enter the bloodstream causing death or severe injury.

Lower the tilt deck to the travel position before disconnecting a hydraulic line or fitting.

## 8 INSPECTION SERVICE & MAINTENANCE

---

---

### 8.1 INSPECTION, SERVICE & MAINTENANCE SUMMARY CHARTS

You must inspect, maintain and service your trailer regularly to insure safe and reliable operation. If you cannot or are unsure how to perform the items listed here, have your dealer do them. Note: In addition to this manual, also check the relevant component manufacturer's manual.

# Inspection, Service and Maintenance

## Inspection and Service before Each Use

Item	Inspection / Service	Manual Section Reference
<b>Breakaway Brakes</b> > Electric > Surge	<b>Check operation</b>  <b>Check fluid level and operation</b>	<b>Sections 4.2.6 &amp; 4.2.8.4</b>  <b>Section 4.2.7.1 &amp; 8.2.4</b>
<b>Breakaway Battery</b>	<b>Fully charged, connections clean</b>	<b>Sections 4.2.6, 4.2.8.4</b>
<b>Brakes, all types</b>	<b>Check operation</b>	<b>Section 1.2.3</b>
<b>Shoes and Drums</b>	<b>Adjust</b>	<b>Section 1.2.2 8.2.3.2</b>
<b>Coupler and Hitch Ball</b>	<b>Check for cracks, pits, and flats. Replace w/ball &amp; coupler having same trailer GVW Rating.</b>  <b>Grease.</b>  <b>Check locking device &amp; replace.</b>	<b>Section 4.2.2.1</b>  <b>Section 4.2.2.1</b>  <b>Section 8.2.5.1</b>
<b>Ring and Pintle</b>	<b>Check for cracks, pits, and flats. Replace w/ring &amp; pintle having same trailer GVW Rating.</b>  <b>Grease.</b>  <b>Check locking device &amp; replace.</b>	<b>Section 4.2.3.1</b>  <b>Section 4.2.3.1</b>  <b>Section 8.2.5.2</b>
<b>Gooseneck Ball</b>	<b>Check for cracks, pits, and flats. Replace w/ball &amp; coupler having same trailer GVW Rating.</b>  <b>Grease.</b>  <b>Check locking device &amp; replace when worn.</b>	<b>Section 4.2.8.1</b>  <b>Section 4.2.8.1</b>  <b>Section 8.2.5.3</b>
<b>Safety Chains &amp; Hooks</b>	<b>Check for wear and damage</b>	<b>Sections 4.2.4 &amp; 4.2.8.3</b>
<b>Tires</b>	<b>Check tire pressure when cold. Inflate as needed.</b>	<b>Sections 6.1 &amp; 8.2.10</b>
<b>Wheels - Lug Nuts (Bolts) &amp; Hub</b>	<b>Check for tightness</b>  <b>Tighten. For new and</b>	<b>Section 6.1</b>

## Inspection, Service and Maintenance

---

	remounted wheels, check torque after first 10, 25 & 50 miles of driving and after any impact	Sections 1.2.1 & 8.2.14
--	--	-------------------------

Inspection and Service each Month		
<b>Item</b>	<b>Inspection / Service</b>	<b>Manual Section Reference</b>
<b>Lubrication</b>	<b>Lubricate tilt deck pivots</b>	<b>Section 8.2.13</b>

Inspection and Service each 6 Months or 6,000 Miles		
<b>Item</b>	<b>Inspection / Service</b>	<b>Manual Section Reference</b>
<b>Tires</b>	<b>Rotate @ 5,000 miles</b>	<b>Section 8.2.10</b>
<b>Brakes, electric</b> > Magnets > Controller (in tow vehicle)	<b>Check wear and current draw</b> <b>Check power output (amperage) and modulation</b>	<b>Section 8.2.3.5</b> <b>Section 8.2.3.4</b> <b>See Controller Mfr's Manual</b>
<b>Tires</b>	<b>Inspect tread and sidewalls thoroughly.</b> <b>Replace tire when treads are worn, when sidewall has a bulge, or sidewall is worn</b>	<b>Section 8.2.10</b>  <b>Section 8.2.10</b>

# Inspection, Service and Maintenance

Inspection and Service Each Year or 12,000 Miles		
Item	Inspection / Service	Manual Section Reference
<b>Brakes, all types</b> > Shoes and drums	Check for scoring and wear. Replace per manufacturer's specifications	Section 8.2.3.1 See Brake Mfr's Manual
<b>Jack, Drop-leg</b>	Grease gears at top	See Jack Mfr's Manual
<b>Structure</b> > Frame members > Welds	Inspect all frame members, bolts & rivets. Repair or replace damaged, worn or broken parts	Section 8.2.1  Section 8.2.2.2
<b>Wheels</b> > Wheel Bearings > Rims	Check and confirm free running.  Inspect for cracks & dents. Replace as needed.	See Axle Mfr's Manual  Section 8.2.11
<b>Structure</b> > Axle Attachment Bolts	Check BY DEALER	Section 8.2.1

## 8.2 INSPECTION AND SERVICE INSTRUCTIONS

### 8.2.1 Axle Bolts, Frame, Suspension, & Structure

**WARNING**

Worn or broken suspension parts can cause loss of control and injury may result.

Have trailer professionally inspected annually and after any impact.

To perform many of the inspection and maintenance activities, you must jack up the trailer.

When jacking and using jack stands, place them so as to clear wiring, brake lines, and suspension parts (springs, torsion bars, etc.). Place jacks and jack stands under the outer frame rail.

# Inspection, Service and Maintenance

---

## WARNING

Never crawl under your trailer unless it is on firm and level ground and resting on properly placed and secured jack stands.

### **8.2.2 Trailer Structure**

Because the trailer floor receives the most abuse, it will most likely corrode before any other part of the structure.

Using a power washer and a detergent solution, thoroughly wash the trailer.

#### **8.2.2.1 Fasteners and Frame Members**

Inspect all of the fasteners and structural frame members for bending and other damage, cracks, or failure. Repair or replace any damaged fastener and repair the frame member. If you have any questions about the condition or method of repair of fasteners or frame members, get the recommendation of, or have the repair done by, your dealer.

## WARNING

Broken or damaged fasteners or welds can cause injury or damage to trailer and contents.

Inspect for, and repair all damaged parts at least once a year.

#### **8.2.2.2 Welds**

All welds can crack or fail when subjected to heavy loads or movement of cargo that was not properly tied to prevent movement. Any time that you know or suspect that the trailer has been subjected to heavy loads or movement of cargo, immediately inspect the welds and fasteners for damage. To prevent severe damage to your trailer, inspect all of the welds for cracks or failure at least once a year.

## Inspection, Service and Maintenance

---

### WARNING

Broken or damaged fasteners or welds can cause injury or damage to trailer and contents.

Inspect for, and repair all damaged parts at least once a year.

### **8.2.2.3 Slide-Out Ramps**

The slide-out ramps are located on the underside of the trailer, These parts are exposed to road grime, water and possible salt spray. Clean and lubricate the moving parts regularly to keep the slide-out ramps from seizing.

Clean and lubricate the slide-out mechanism at least once per season, and more frequently if your trailer is operated in dusty or salt-spray environments. Clean the locations where the ramp passes through the frame. Grease the sliding track.

### **8.2.3 Trailer Brakes - Electric**

#### **8.2.3.1 Brake Shoes and Drums**

Properly functioning brake shoes and drums are essential to ensure safety. You must have your dealer inspect these components at least once per year, or each 12,000 miles.

The brake shoes must be adjusted after the first 200 miles of use, and each 3,000 miles thereafter. Most axles are fitted with a brake mechanism that will automatically adjust the brake shoes when the trailer is “hard braked” from a rearward direction. Read your axle and brake manual to see how to adjust your brakes. If you do not have this manual, call Bri-Mar Manufacturing LLC at 1-800-732-5845 for a free copy.

#### **8.2.3.2 Manually Adjusting Brake Shoes**

Some braking systems are not automatically adjusted by hard stopping. These brakes require manual adjustment. The following steps apply to adjust most manually adjustable brakes. Read your axle and brake



## Inspection, Service and Maintenance

---

manual to see how to adjust your brakes. If you do not have this manual, call Bri-Mar Manufacturing LLC at 1-800-732-5845 for a free copy.

- Jack up the trailer and secure it on adequate capacity jack stands.
- Be sure the wheel and brake drum rotate freely.
- Remove the adjusting-hole cover from the adjusting slot on the bottom of the brake backing plate.
- With a screwdriver or standard adjusting tool, rotate the starwheel of the adjuster assembly to expand the brake shoes. Adjust the brake shoes out until the pressure of the linings against the drum makes the wheel very difficult to turn. Note: Your trailer maybe equipped with drop spindle axles. See axle manual for your axle type. You will need a modified adjusting tool for adjusting the brakes in these axles. With drop spindle axles, a modified adjusting tool with about an 80 degree angle should be used.
- Rotate the starwheel in the opposite direction until the wheel turns freely with a slight drag.
- Replace the adjusting-hole cover.
- Repeat the above procedure on all brakes.
- Lower the trailer to the ground.

### **8.2.3.3 Brakes, Electric**

Two different types of electric brakes may be present on the trailer: an emergency electric breakaway system, which acts only if the trailer comes loose from the hitch and the breakaway pin is pulled. The other brake is an electric braking system that acts whenever the brakes of the tow vehicle are applied.

#### **Breakaway Brake**

**Breakaway Battery** – Powered tilt deck trailers use the DC power unit battery to supply the power to operate the trailer brakes if the trailer uncouples from the tow vehicle. If the battery is allowed to drain below a 15% level, external charging is required using a commercial battery charger. Be sure to check, maintain and replace the battery according to the battery manufacturer's instructions. Check the fuses in the battery box before each tow.

## Inspection, Service and Maintenance

---

All other flatbed trailers utilized a battery supplied by the breakaway brake manufacturer. This battery supplies the power to operate the trailer brakes if the trailer uncouples from the tow vehicle. Be sure to check, maintain and replace the battery according to the battery manufacturer's instructions.

**Breakaway Switch** - This switch causes the breakaway battery to operate the electric brakes if the trailer uncouples from the tow vehicle.

The pull cable for the pull pin is connected to the tow vehicle, and the switch is connected to the trailer. To check for proper functioning of the switch, battery and brakes, you must pull the pin from the switch and confirm that the brakes apply to each wheel. You can do this by trying to pull the trailer with the tow vehicle, after pulling the pin. The trailer brakes may not lock, but you will notice that a greater force is needed to pull the trailer.

### **WARNING**

If electric breakaway brakes do not operate when trailer is uncoupled from the tow vehicle, death or serious injury can occur.

Check emergency breakaway brake system BEFORE each tow.

### **8.2.3.4 Tow Vehicle Operated Electric Brakes**

The electric brakes that operate in conjunction with the tow vehicle brakes must be “synchronized” so that braking is properly distributed to the tow vehicle brakes and the trailer brakes. For proper operation and synchronization, read and follow the axle/brake and the brake controller manufacturers' instructions. If you do not have these instructions, call Bri-Mar Manufacturing LLC at 1-800-732-5845 for a free copy.

### **8.2.3.5 Magnets for all Electric Brakes**

To make certain an electrically-operated braking system will function properly, you must have your dealer inspect the magnets at least once a year, or each 12,000 miles. See the brake manual for wear and current inspection instructions.

# Inspection, Service and Maintenance

---

## **8.2.4 Trailer Brakes – Surge**

### **8.2.4.1 Hydraulic Surge Brake**

Before each towing, perform the following steps:

- Check that the brake fluid reservoir is three-quarters full of DOT-3 or DOT-4 brake fluid. Check for leaks and repair as required.
- Examine the actuator for wear, bent parts, corroded/seized parts, or other damage. Have the affected components replaced with genuine service parts.
- Check to determine that the actuator mounting bolts are tightened to the manufacturers specification.
- Test the actuator and brake function as described in the information of this manual. Actuator travel over one inch indicates that the brakes need adjustment (or that the actuator has been structurally damaged). Actuator travel is the distance the coupler case assembly moves to the outer case during braking. Adjust the brakes following the instructions given in the brake installation manual. Failure to adjust brakes will result in loss of braking.
- Before storage or after extended use, apply motor oil to the coupler components and the internal rollers to keep them moving freely and to prevent corrosion. Also apply grease to the front roller via the zerk fitting. Grease every 5000 miles or 90 days of use.

See the surge brake manufacturer's manual for other inspection and maintenance activities. If you do not have this manual, call Bri-Mar Manufacturing LLC at 1-800-732-5845 for a copy.

### **8.2.4.2 Master Cylinder Bleeding**

Remove the master cylinder's cap and fill the reservoir to three quarters full with DOT-3 or DOT 4 brake fluid. DO NOT allow brake fluid to contact painted surfaces since it will damage the finish. Wipe up any spills immediately and wash the area with water.

Bleed the brake system either manually or with a pressure bleeder. Pressure bleeding equipment simplifies the process, and is available at your local automotive supply store. Use the instructions provided with the pressure bleeder. If you chose to manually bleed the system, an

## Inspection, Service and Maintenance

---

assistant is required. Use the following steps to manually bleed the brake system:

- Disconnect the trailer from the tow vehicle and jack the trailer's tongue until it is horizontal. Make sure that the wheels are blocked so that the trailer will not roll away.
- Fill the master cylinder with fluid as described above. Loosen the four break-away mounting bolts enough to keep the break-away locks from restricting the lever motion. Rotate the break-away lever forward using small strokes until the bubbling stops inside the master cylinder.
- Install a bleeder hose on the bleeder screw of the farthest wheel cylinder from the actuator. If the trailer has tandem axles, bleed the rear axle first. Submerge the other end of the hose in a glass container of brake fluid, so that air bubbles can be observed.
- Open the bleeder screw and have your assistant stroke (but not release) the break-away lever. Brake fluid and/or air bubbles will flow into the jar. Close the bleeder screw. The helper can then allow the breakaway lever to return to its rest position.

Repeat the process until no more bubbles are released with the stroke. Air trapped in the brake lines will greatly reduce your braking efficiency. Be sure to close the bleeder screw securely when the cylinder is fully bled. Repeat the bleeding operation at each wheel cylinder. During the bleeding process, replenish the master cylinder reservoir with fresh brake fluid so that the level does not fall below half full. This will ensure that no air is drawn into the system.

After all brakes have been bled, refill the master cylinder reservoir to three-quarters full before operating. Retighten the four bolts using a torque wrench to 90-120 inch-pounds of torque. Screw the filler cap back into position and replace the cylinder cover. The filler cap only needs to be finger tight.

### WARNING

Use only fresh brake fluid from a sealed container. DO NOT reuse fluid. After filling and bleeding, refill the actuator. Failure to maintain an adequate fluid level may cause brake failure.

# Inspection, Service and Maintenance

---

## **8.2.5 Trailer Connection to Tow Vehicle**

### **8.2.5.1 Coupler and Ball**

The coupler on the trailer connects to the ball attached to the hitch on the tow vehicle. The coupler, ball and hitch transfer the towing forces between the tow vehicle and the trailer. Before each tow, coat the ball with a thin layer of automotive bearing grease to reduce wear and ensure proper operation; and check the locking device that secures the coupler to the ball for proper operation.

See the coupler manufacturer's manual for other inspection and maintenance activities. If you do not have this manual, call Bri-Mar Manufacturing LLC at 1-800-732-5845 for a free copy.

If you see or feel evidence of wear, such as flat spots, deformations, pitting or corrosion, on the ball or coupler, immediately have your dealer inspect them to determine the proper action to prevent possible failure of the ball and coupler system. All bent or broken coupler parts must be replaced before towing the trailer.

The coupler handle lever must be able to rotate freely and automatically snap into the latched position. Oil the pivot points, sliding surfaces, and spring ends with SAE 30W motor oil. Keep the ball pocket and latch mechanism clean. Dirt or contamination can prevent proper operation of the latching mechanism.

When replacing a ball, the load rating must match or exceed the GVWR of the trailer.

### **8.2.5.2 Ring and Pintle**

The ring on the trailer connects to the pintle attached to the hitch on the tow vehicle. The ring, pintle and hitch transfer the towing forces between the tow vehicle and the trailer. Before each tow, coat the ring with a thin layer of automotive bearing grease to reduce wear and ensure proper operation; and check the locking device that secures the pintle to the ring for proper operation.

## Inspection, Service and Maintenance

---

See the pintle manufacturer's manual for other inspection and maintenance activities. If you do not have this manual, call Bri-Mar Manufacturing LLC at 1-800-732-5845 for a free copy.

If you see or feel evidence of wear, such as flat spots, deformations, pitting or corrosion, on the ring or pintle, immediately have your dealer inspect them to determine the proper action to prevent possible failure of the ring and pintle system. All bent or broken coupler parts must be replaced before towing the trailer.

The pintle handle lever must be able to rotate freely and automatically snap into the latched position. Oil the pivot points, sliding surfaces, and spring ends with SAE 30W motor oil. Keep the ring pocket and latch mechanism clean. Dirt or contamination can prevent proper operation of the latching mechanism.

When replacing a ring, the load rating must match or exceed the GVWR of the trailer.

### **8.2.5.3 Gooseneck**

The gooseneck receiver on the trailer connects to a hitch-mounted ball on the towing vehicle. The receiver, ball and hitch transfer the towing forces between the tow vehicle and the trailer. Before each tow, coat the ball with a thin layer of automotive bearing grease to reduce wear and ensure proper operation; and check the locking device that secures the receiver to the ball for proper operation.

See the gooseneck ball receiver manufacturer's manual for other inspection and maintenance activities. If you do not have a manual for the receiver, call Bri-Mar Manufacturing LLC at 1-800-732-5845 for a free copy.

If you see or can feel evidence of wear, such as flat spots, pitting or corrosion, on the ball or receiver, immediately have your dealer inspect them to determine the proper action to prevent possible failure of the ball and receiver system.

# Inspection, Service and Maintenance

---

When replacing a ball, the load rating must match or exceed the GVWR of the trailer.

## **8.2.5.4 Fifth Wheel Kingpin**

Before each tow, inspect the fifth wheel and kingpin for wear, and coat the contact surface of the fifth wheel plate with water-resistant Lithium-base grease. If you see evidence of wear on the fifth wheel or kingpin, immediately have your dealer inspect them to determine the proper action to prevent failure of the fifth wheel and kingpin system.

See the manual prepared by the manufacturer of the fifth wheel and kingpin for other inspection and maintenance activities. If you do not have this manual, call Bri-Mar Manufacturing LLC at 1-800-732-5845 for a free copy.

## **8.2.6 Landing Leg or Jack**

If a grease fitting is present, you must use a grease gun to lubricate the jack mechanism. Grease the gears in the top of hand-cranked jacks once a year, by removing the top of the jack and pumping or hand packing grease into the gears.

## **8.2.7 Lights and Signals**

Before each tow, check the trailer taillights, stoplights, turn signals and any clearance lights for proper operation.



To avoid collisions, taillights, stoplights and turn signals must work.

## **8.2.8 Accessory Battery**

Powered tilt deck trailers are equipped with an accessory battery that operates the DC Power Unit and the electric breakaway brakes. An accessory battery may be kept charged either by the tow vehicle or by the optional battery charger. See the manual for the accessory battery.

## Inspection, Service and Maintenance

---

Disconnect the accessory battery when you do not plan to be using the trailer for an extended period, such as seasonal storage. Remove the cables from the battery terminals.

The accessory battery must be kept in a charged condition during storage. The battery could freeze and break if it becomes discharged.

### **8.2.9 Accessory DC Power Unit**

A DC hydraulic power unit is used on powered tilt deck trailers. The hydraulic system is under extreme pressure. Pressure will be in the hydraulic cylinder and lines even when the power unit is not operating. Lower the tilt deck to the travel position before disconnecting a hydraulic line or fitting.

In the event of a system leak, hydraulic fluid can be expelled at high velocity piercing the skin and entering the blood stream. Wear eye and skin protection when servicing the hydraulic system. Do not wear jewelry or metal objects when servicing the power unit. Disconnect the ground wire first and then the positive wire from the power unit and the battery to prevent inadvertent operation while servicing the unit. Reconnect the battery in reverse order to prevent tools from contacting the frame and short circuiting the battery.

A manual is available from Bri-Mar Manufacturing LLC for service information on your power unit.



# Inspection, Service and Maintenance

## WARNING

Hydraulic system is under extreme pressure. To reduce the risk of injury, follow the precautions listed below:

Always wear eye protection and protective clothing when working around hydraulic systems.

Remove jewelry and objects that might conduct electricity while working on power units.

Fluid under pressure can pierce the skin and enter the bloodstream causing death or severe injury.

Lower the tilt deck to the driving position before disconnecting a hydraulic line or fitting.

Bri-Mar Manufacturing LLC uses a double acting cylinder. Refer to the proper schematics when servicing your trailer.

### **8.2.9.1 DC Power Unit Maintenance**

Check fluid level prior to using the power unit. The power unit is located inside the battery box at the front of the trailer. The cylinder must be retracted to properly check the fluid level. The reservoir should be filled within ½ inch from the top. Use ATF to replenish fluid if needed. Mobil 424 fluid can also be used but the hydraulic system may operate slower.

Most power units have suction filters which must be cleaned or replaced periodically whenever flow is slow or sluggish.

Check the reservoir for water when servicing the trailer. If water is present, drain the reservoir and replace the oil.

Check electric connections for corrosion and tightness.

### **8.2.9.2 DC Power Unit Troubleshooting**

The double acting system (M-3551) operates the motor in both UP and DOWN operation. Selecting UP energizes the 4 way 2 position valve and the pump. The oil flows from the pump through the check valve, 4 way

## Inspection, Service and Maintenance

---

2 position valve, flow control valve and the 2 way 2 position valve to the cylinder piston side. The rod side is connected through the 4 way 2 position valve directly to the tank.

Selecting DOWN energizes the 2 way 2 position valve and the pump. The oil flows from the pump through the check valve and the 4 way 2 position valve to the cylinder rod side. The piston side oil flows through the 2 way 2 position valve, flow control valve and the 4 way 2 position valve to the tank.

The flow control valve controls the decent speed of the body to prevent overrunning the pump.

If the pump will not operate, check the level of charge in the battery and also for blown fuses. If these check out, contact your dealer for assistance.

### **8.2.10 Tires**

Trailer tires may be worn out even though they still have plenty of tread left. This is because trailer tires have to carry a lot of weight all the time, even when not in use. It is actually better for the tire to be rolling down the road than to be idle. During use, the tire releases lubricants that are beneficial to tire life. Using the trailer tires often also helps prevent flat spots from developing. The main cause of tire failure is improper inflation.

Before each tow and at least once a month thereafter, be sure to check the tire pressure to make sure it is at the level indicated on the VIN/Certification Label. Tire pressure must be checked while the tire is cold. Do not check the tire pressure immediately after towing the trailer. Allow at least three hours for a tire to cool, if the trailer has been towed for as much as one mile.

Wheel and tire manufacturers recommend adjusting the air pressure to the maximum pounds per square inch (PSI) listed on the sidewall of the tire when the trailer is fully loaded. If the tires are inflated to less than the

## Inspection, Service and Maintenance

---

maximum inflation level, the load carrying capacity of the tire could be dramatically affected. Refer to the owner's manual or talk to your dealer or vehicle manufacturer if you have any questions regarding proper inflation practices.

The tires can lose air over a period of time. In fact, tires can lose 1 to 3 PSI per month. This is because molecules of air, under pressure, weave their way from the inside of the tire, through the rubber, to the outside. A drop in tire pressure could cause the tire to become overloaded, leading to excessive heat build up. If a trailer tire is under-inflated, even for a short period of time, the tire could suffer internal damage.

High speed towing in hot conditions degrades trailer tires significantly. As heat builds up during driving, the tire's internal structure starts to breakdown, compromising the strength of the tire. It is recommended to drive at moderate speeds.

Replace the tire before towing the trailer if the tire treads have less than 2/32 inch depth or the telltale bands are visible. A bubble, cut or bulge in a side wall can result in a tire blowout. Inspect both side walls of each tire for any bubble, cut or bulge; and replace a damaged tire before towing the trailer.

A bubble, cut or bulge in a side wall can result in a tire blowout. Inspect both side walls of each tire for any bubble, cut or bulge; and replace a damaged tire before towing the trailer.

Statistics indicate the average life of a trailer tire is five years under normal use and maintenance conditions. After three years, replacing the trailer tires with new ones should be considered, even if the tires have adequate tread depth. After five years, trailer tires are considered worn out and should be replaced, even if they have had minimal or no use.

If you are storing your trailer for an extended period, make sure the tires are fully inflated to the maximum rated pressure and that you store them in a cool, dry place, such as a garage. Use tire covers to protect the trailer tires from the harsh effects of the sun.

## Inspection, Service and Maintenance

---

### WARNING

Worn, damaged or under-inflated tires can cause loss of control, injury and damage.

Check tires before each tow.

### **8.2.11 Wheel Rims**

If the trailer has been struck, or impacted, on or near the wheels, or if the trailer has struck a curb, inspect the rims for damage (i.e. being out of round); and replace any damaged wheel. Inspect the wheels for damage every year, even if no obvious impact has occurred.

### **8.2.12 Wheel Bearings**

Refer to the axle manufacturer's manual regarding service intervals for the axle components. If you do not have a manual for the axle, call Bri-Mar Manufacturing LLC at 1-800-732-5845 for a free copy.

### **8.2.13 Lubrication Points**

**DO NOT** perform maintenance under a raised tilt deck. Lower the tilt deck to the travel position before performing service or maintenance.

Pump grease into the fittings on each end of the cylinder. Fitting are accessible from under the trailer while the tilt deck is lowered in the driving position.

### **8.2.14 Lug Nuts (Bolts)**

Lug nuts are prone to loosen right after a wheel is mounted to a hub. When driving on a remounted wheel, check to see if the lug nuts are tight after the first 10, 25 and 50 miles of driving and before each tow thereafter.

## Inspection, Service and Maintenance

### WARNING

Lug nuts are prone to loosen after being first assembled. Death or serious injury can result.

Check lug nuts for tightness on a new trailer, and after re-mounting a wheel at 10, 25 and 50 miles.

### WARNING

Metal creep between the wheel rim and lug nuts (bolts) may cause rim to loosen.

Death or injury can occur if wheel comes off.

Tighten lug nuts (bolts) before each tow.

- Tighten the lug nuts to the proper tightness to prevent wheels from coming loose. Refer to the steps that follow and the axle manufacturer's information. Use a calibrated torque wrench to tighten the lug nuts. Over-tightening may result in breaking the studs or permanently deforming the mounting stud holes in the wheels.
- Remove all excess paint, oil and grease from mounting surfaces.
- Start all lug nuts by hand to prevent cross threading.
- Tighten lug nuts in the sequence shown in figure 8-1.
- Tighten lug nuts in stages as shown in figure 8-2.
- Check and retorque after the first 10, 25 and 50 miles of driving and before each tow thereafter.




Figure 8-1 - Wheel Torque Sequence

## Inspection, Service and Maintenance

---


Steel Wheel Torque Requirements			
Wheel Size	1 <sup>st</sup> Stage	2 <sup>nd</sup> Stage	3 <sup>rd</sup> Stage
14 inch	20-25 lb ft	50-60 lb ft	90-120 lb ft
15 inch	20-25 lb ft	50-60 lb ft	90-120 lb ft
16 inch	20-25 lb ft	50-60 lb ft	90-120 lb ft

Figure 8-2 – Wheel Torque Requirements

# 9 ELECTRICAL DRAWINGS

## CONNECTOR & WIRE ID LEGEND

- ←← MATED TERMINAL CONNECTION
- ↳ SOCKET TERMINAL
- PIN TERMINAL
- ↳ □ SOCKET TERMINAL W/PLUG
- □ PIN TERMINAL W/PLUG




### Wire Gauge Conversion

- 0.8 mm<sup>2</sup> - 18 Awg
- 1.0 mm<sup>2</sup> - 16 Awg
- 2.0 mm<sup>2</sup> - 14 Awg
- 3.0 mm<sup>2</sup> - 12 Awg
- 5.0 mm<sup>2</sup> - 10 Awg

### Color Aabbreviations


- WE - White
- YW - Yellow
- BK - Black
- BN - Brown
- BE - Blue
- GN - Green

## 7 WAY CONNECTOR




TRAILER TO  
TOW VEHICLE  
CONNECTOR

TO TRAILER  
HARNESS




## 6 WAY CONNECTOR



TRAILER TO  
TOW VEHICLE  
CONNECTOR

TO TRAILER  
HARNESS






# Electrical Drawings

REV	DESCRIPTION	DRAWN	DATE	APP'D

NOTES:  
 1. UNLESS OTHERWISE SPECIFIED ALL DIMENSIONS ARE IN INCHES  $\pm 1/100$  TOL

- CONNECTOR & WIRE ID. LEGEND**
- ← WIRE TERMINAL CONNECTION
  - PIN TERMINAL CONNECTION
  - PIN TERMINAL CONNECTION
  - SOCKET TERMINAL W/VALUE
  - PIN TERMINAL W/VALUE
- Wire Gauge Conversion**
- |        |                              |
|--------|------------------------------|
| 18 AWG | 1.0 mm <sup>2</sup> - 18 AWG |
| 16 AWG | 1.3 mm <sup>2</sup> - 16 AWG |
| 14 AWG | 2.0 mm <sup>2</sup> - 14 AWG |
| 12 AWG | 3.0 mm <sup>2</sup> - 12 AWG |
| 10 AWG | 5.0 mm <sup>2</sup> - 10 AWG |
- Color Abbreviations**
- |             |
|-------------|
| WH - White  |
| YV - Yellow |
| BL - Black  |
| BN - Brown  |
| GN - Green  |
- WIRE GAUGE - WIRE COLOR**
- CONNECTOR ID NUMBER - QUANTITY
- RESISTOR NUMBER - RESISTANCE

- CONN 6 WAY W/P: 12010975**
- A) 3.0 WE GROUND
  - B) 3.0 BE ELECTRIC BRAKE
  - C) 3.0 BF - 12VDC POWER
  - D) 2.0 BK - 12VDC POWER
  - E) 2.0 YW - LT TURN SIGNAL
  - F) 2.0 GN - RT TURN SIGNAL
- CONN 7 WAY W/CABLE: CN-6CTC-8FT**
- TERM 16/14 GA- 120124582
  - SEAL 14 GA- 12010293
  - TERM 12 GA- 12014587
  - SEAL 12 GA- 12015193




**SIMILAR TO:**

**PROPRIETARY NOTICE**  
 THIS DOCUMENT IS THE SOLE PROPERTY OF BRI-MAR MANUFACTURING, LLC. IT IS PROVIDED TO YOU UNDER A LICENSE TO COPY THIS DOCUMENT FOR YOUR INFORMATION AND USE ONLY. IT IS NOT TO BE REPRODUCED, COPIED, OR TRANSMITTED IN ANY FORM OR BY ANY MEANS, ELECTRONIC OR MECHANICAL, WITHOUT THE WRITTEN PERMISSION OF BRI-MAR MANUFACTURING, LLC.

BRI-MAR Manufacturing, LLC	
ENGINEERING DRAWING	
TITLE TRAILER CABLE, 8FT	
THIRD ANGLE PROJECTION	DATE 9/15/08
DRAWN BY SAM	DATE 9/15/08
CHECKED BY SAM	DATE 9/15/08
APPROVED BY SAM	DATE 9/15/08
RELEASED	DATE 9/15/08
SCALE: NONE	MODEL: BRI-MAR
SHEET: 1 OF 1	REV



# Electrical Drawings



NOTES:  
 1. UNLESS OTHERWISE SPECIFIED ALL DIMENSIONS ARE IN INCHES - +1/-0" TOL.

**CONNECTOR & WIRE ID LEGEND**

WIRE TERMINAL CONNECTION  
 SOCKET TERMINAL  
 SOCKET TERMINAL W/SLUG  
 WIRE END RETIE

WIRE COLOR

**Wire Gauge Conversion**

18 AWG	0.8 mm	-10 Amp
16 AWG	1.0 mm	-15 Amp
14 AWG	1.6 mm	-20 Amp
12 AWG	2.5 mm	-25 Amp
10 AWG	3.2 mm	-35 Amp

**Color Abbreviations**

WE	- White
BL	- Black
SK	- Black
RD	- Red
GN	- Green

CONN 6 WAY W/P. 12010975  
 TERM 16/14 GA- 12124382  
 SEAL 14 GA- 12010253

72"

68"

60"

CABLE 6 CONDUCTOR  
 6 X 14 GA  
 CN-LIP-048


A) 2.0 WE GROUND  
 B) 2.0 BK ELECTRIC BRAKE  
 C) 2.0 BK 12 TURN SIGNAL  
 D) 2.0 BK 14 GA  
 E) 2.0 BK 11 TURN SIGNAL  
 F) 2.0 GN RT TURN SIGNAL

TO TRUCK TO TOW VEHICLE CONNECTOR

A	2.0 WE - GROUND
B	2.0 BK - ELECTRIC BRAKE
C	2.0 BK - 12 TURN SIGNAL
D	2.0 BK - 14 GA
E	2.0 BK - 11 TURN SIGNAL
F	2.0 GN - RT TURN SIGNAL

TO TRAILER HARNESS

A	2.0 WE - GROUND
B	2.0 BK - ELECTRIC BRAKE
C	2.0 BK - 12 TURN SIGNAL
D	2.0 BK - 14 GA
E	2.0 BK - 11 TURN SIGNAL
F	2.0 GN - RT TURN SIGNAL



SIMILAR TO: 110-047

**PROPRIETARY NOTICE**

THIS DRAWING IS THE PROPERTY OF BRI-MAR MANUFACTURING, LLC. IT IS TO BE USED ONLY FOR THE PROJECT AND NOT BE REPRODUCED OR COPIED IN ANY MANNER WITHOUT THE WRITTEN PERMISSION OF BRI-MAR MANUFACTURING, LLC. ANY REPRODUCTION OR USE OF THIS DRAWING FOR ANY OTHER PROJECT WITHOUT THE WRITTEN PERMISSION OF BRI-MAR MANUFACTURING, LLC IS STRICTLY PROHIBITED.

REV	DESCRIPTION	DRAWN	DATE
1	ISSUED FOR LEASING & R & D REVISION	ACH	12/14/16 JAC

BRI-MAR Manufacturing, LLC	
ENGINEERING DRAWING	
TITLE	
TRAILER CABLE, 6FT	
SCALE	MODEL
1:1	110-048-C
SHEET	OF
1	1