



Operation & Safety Manual

*Original Instructions
Keep this manual with machine at all times.*

Model G5-18A

SN 0160091004 to Present including
0160088263 & 0160088264 and excluding
0160091013 thru 0160091021

31211321

August 27, 2018 - Rev A



An Oshkosh Corporation Company



WARNING

Operating, servicing and maintaining this vehicle or equipment can expose you to chemicals including engine exhaust, carbon monoxide, phthalates, and lead, which are known to the State of California to cause cancer and birth defects or other reproductive harm. To minimize exposure, avoid breathing exhaust, do not idle the engine except as necessary, service your vehicle or equipment in a well-ventilated area and wear gloves or wash your hands frequently when servicing. For more information go to www.P65Warnings.ca.gov.

REVISION LOG

August 27, 2018 - A - Original Issue of Manual.

Read This First

This manual is a very important tool! Keep it with the machine at all times.

The purpose of this manual is to provide owners, users, operators, lessors, and lessees with the precautions and operating procedures essential for the safe and proper machine operation for its intended purpose.

Due to continuous product improvements, JLG Industries, Inc. reserves the right to make specification changes without prior notification. Contact JLG Industries, Inc. for updated information.

Operator Qualifications

The operator of the machine must not operate the machine until this manual has been read, training is accomplished and operation of the machine has been completed under the supervision of an experienced and qualified operator. Operation within the U.S.A. requires training per OSHA 1910.178.

Operators of this equipment must possess a valid, applicable driver's license, be in good physical and mental condition, have normal reflexes and reaction time, good vision and depth perception and normal hearing. Operator must not be using medication which could impair abilities nor be under the influence of alcohol or any other intoxicant during the work shift.

In addition, the operator must read, understand and comply with instructions contained in the following material furnished with the telehandler:

- This Operation and Safety Manual
- Telehandler Safety Manual (ANSI only)
- All instructional decals and plates
- Any optional equipment instructions furnished

The operator must also read, understand and comply with all applicable Employer, Industry and Governmental rules, standards and regulations.

Modifications

Modifications to this machine may affect compliance with Industry Standards and/or Governmental Regulations. Any modification must be approved by JLG.

This product must comply with all safety related bulletins. Contact JLG Industries, Inc. or the local authorized JLG representative for information regarding safety-related bulletins which may have been issued for this product.

JLG Industries, Inc. sends safety related bulletins to the owner of record of this machine. Contact JLG Industries, Inc. to ensure that the current owner records are updated and accurate.

JLG Industries, Inc. must be notified immediately in all instances where JLG products have been involved in an accident involving bodily injury or death of personnel or when damage has occurred to personal property or the JLG product.

FOR:

- Accident Reporting and Product Safety Publications
- Current Owner Updates
- Questions Regarding Product Applications and Safety
- Standards and Regulations Compliance Information
- Questions Regarding Product Modifications

CONTACT:

Product Safety and Reliability Department
JLG Industries, Inc.
13224 Fountainhead Plaza
Hagerstown, MD 21742
USA

or Your Local JLG Office

In USA:

Toll Free: 1-877-JLG-SAFE (1-877-554-7233)

Outside USA:

Phone: +1-717-485-6591

E-mail:

ProductSafety@JLG.com

Read This First

Other Publications Available

Service Manual.....	31211325
Parts Manual	31211319

Note: The following standards may be referenced in this manual:

ANSI is compliant to ANSI/ITSDF B56.6

AUS is compliant to AS 1418.19

CE is compliant to EN1459

Refer to the machine Serial Number Plate to identify the applicable compliance standard.

Machine Configuration

Two configurations of each machine are included in this manual. Determine if machine is equipped with Ultra Low Sulfur Fuel Decal (1) as indicated below.

- If equipped with the Ultra Low Sulfur decal, all specific references to this machine configuration will be referred to as Ultra Low Sulfur (**ULS**) from this point forward.
- If **not** equipped with the Ultra Low Sulfur decal, all specific references to this machine configuration will be referred to as Low Sulfur (**LS**) from this point forward.




TABLE OF CONTENTS

Revision Log

Read This First

Operator Qualifications	b
Modifications.....	b
Other Publications Available	d
Machine Configuration.....	d

Table of Contents

Section 1 - General Safety Practices

1.1 Hazard Classification System	1-1
Safety Alert System and Safety Signal Words.....	1-1
1.2 General Precautions	1-1
1.3 Operation Safety.....	1-2
Electrical Hazards.....	1-2
Tip Over Hazard.....	1-4
Travel Hazard.....	1-7
Load Falling Hazard	1-8
Lifting Personnel.....	1-9
Driving Hazards on Slopes.....	1-10
Pinch Points and Crush Hazards.....	1-11
Fall Hazard.....	1-13
Chemical Hazards	1-14
1.4 ClearSky (if equipped).....	1-15
Federal Communications Commission (FCC)	
Information for Users.....	1-15

Section 2 - Pre-Operation and Inspection

2.1 Preparation, Inspection and Maintenance.....	2-1
2.2 Pre-Operation Check and Inspection.....	2-2
2.3 Safety Decals	2-4
ANSI (if equipped).....	2-4
ISO (if equipped)	2-7
2.4 Walk-Around Inspection	2-10
2.5 Warm-Up and Operational Checks	2-14
Warm-Up Check	2-14
Operational Check.....	2-14
2.6 Operator Cab.....	2-15
2.7 Windows	2-16
Cab Door Window (if equipped)	2-16
Rear Window	2-17

Table of Contents

Section 3 - Controls and Indicators

3.1	General.....	3-1
3.2	Controls	3-2
	Park Brake.....	3-4
	Parking Procedure.....	3-5
	Ignition	3-6
	Transmission Control Lever	3-7
	Load Stability Indicator - LSI (if equipped)	3-8
	LSI Override Switch (if equipped)	3-10
	Steering Column Adjuster (if equipped)	3-11
	Instrument Panel	3-12
	Joystick	3-14
	Right Hand Console.....	3-16
	Accessory Control Lever (if equipped).....	3-18
	Reversing Fan (if equipped).....	3-19
3.3	Steer Modes	3-20
	Steer Mode Change	3-20
3.4	Operator Seat	3-21
	Adjustments	3-21
	Seat Belt	3-22
3.5	Boom Angle and Extension Indicators	3-23
3.6	Reverse Systems (if equipped)	3-24
	Reverse Sensing System.....	3-24
	Reversing Camera.....	3-25

Section 4 - Operation

4.1	Engine.....	4-1
	Starting the Engine	4-1
	Cold Weather Starting.....	4-2
	Battery Boosted Starting	4-3
	Normal Engine Operation.....	4-4
	Shut-Down Procedure	4-4
4.2	Operating with a Non-Suspended Load	4-5
	Lift Load Safely.....	4-5
	Before Picking Up a Load	4-5
	Transporting a Load.....	4-6
	Leveling Procedure	4-6
	Placing a Load	4-7
	Disengaging a Load	4-7
4.3	Operating with a Suspended Load	4-8
	Lift Load Safely.....	4-8
	Picking Up a Suspended Load.....	4-8
	Transporting a Suspended Load	4-9
	Leveling Procedure	4-9
	Placing a Suspended Load	4-10
	Disengaging a Suspended Load	4-10
4.4	Loading and Securing for Transport	4-11
	Tiedown.....	4-11
	Lifting	4-12

Table of Contents

Section 5 - Attachments and Hitches

5.1	Approved Attachments	5-1
	Coupler Mounted Attachments	5-1
	JLG Supplied Fork Mounted Attachments	5-1
	Non-OEM Fork Mounted Attachments	5-1
5.2	Unapproved Attachments	5-2
5.3	Fork Mounted Attachments	5-4
	General Requirements	5-4
	Non-OEM Attachments	5-5
5.4	Equivalent Load	5-6
	Load Centers Beyond 24 Inches	5-6
	Fork Mounted Attachments Equivalent Load	5-7
5.5	JLG Supplied Attachments	5-8
5.6	Telehandler/Attachment/Fork Capacity	5-9
5.7	Use of the Capacity Chart	5-10
	Capacity Indicator Locations	5-10
	Sample Capacity Chart	5-11
	Example	5-12
5.8	Attachment Installation	5-13
	Standard Quick Attach	5-13
	Universal Quick Attach (UQC)	5-17
5.9	Hydraulic Operated Attachment	5-20
5.10	Adjusting/Moving Forks	5-21
5.11	Attachment Operation	5-22
	Carriage with Forks	5-23
	Side Tilt Carriage	5-24
	Side Shift Carriage	5-26
	Bucket	5-28
	Grapple Bucket	5-30
	Fork Mounted Hook	5-32
5.12	Hitches	5-33
	Retrieval Hitch	5-33
	Adjustable Auto Hitch	5-34
	Pin Hitch - CUNA C	5-35
	EEC Manual Pin Hitch	5-36

Section 6 - Emergency Procedures

6.1	Towing a Disabled Product	6-1
	Moving Short Distances	6-1
	Moving Longer Distances	6-1
6.2	Emergency Lowering of Boom	6-2
6.3	Emergency Exit from Enclosed Cab	6-3
	Inside Cab	6-3
	Outside Cab (if equipped)	6-3

Section 7 - Lubrication and Maintenance

7.1	Introduction	7-1
	Clothing and Safety Gear	7-1
7.2	General Maintenance Instructions	7-2
7.3	Maintenance Schedules	7-3
	Every 10 Hours	7-3
	First 50 Hours.....	7-3
	Every 50 Hours	7-4
	First 250 Hours	7-4
	Every 250 Hours.....	7-4
	Every 500 Hours.....	7-5
	Every 1000 Hours	7-5
	Every 1500 Hours	7-5
7.4	Lubrication Schedules	7-6
	250 Hour Lubrication Schedule	7-6
7.5	Operator Maintenance Instructions	7-8
	Fuel System	7-8
	Engine Oil.....	7-10
	Hydraulic Oil	7-11
	Tires.....	7-12
	Air Intake System	7-14
	Engine Cooling System.....	7-16
	Battery.....	7-17
	Brake System	7-18
	Windshield Washer System (if equipped)	7-19

Section 8 - Additional Checks

8.1	General	8-1
8.2	Load Stability Indicator System (if equipped)	8-1
8.3	Reverse Sensing System (if equipped).....	8-2
8.4	Air Shutoff Valve (ASOV) (if equipped)	8-3

Section 9 - Specifications

9.1	Product Specifications	9-1
	Fluids	9-1
	Capacities.....	9-3
	Tires.....	9-4
	Performance	9-5
	Dimensions	9-6
	Machine Towing Capacity	9-7

Index**Inspection, Maintenance and Repair Log**

Table of Contents

SECTION 1 - GENERAL SAFETY PRACTICES

1.1 HAZARD CLASSIFICATION SYSTEM

Safety Alert System and Safety Signal Words



DANGER

DANGER indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.



WARNING

WARNING indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.



CAUTION

CAUTION indicates a potentiality hazardous situation which, if not avoided, may result in minor or moderate injury.

1.2 GENERAL PRECAUTIONS



WARNING

Before operation, read and understand this manual. Failure to comply with the safety precautions listed in this manual could result in machine damage, property damage, personal injury or death.



- Hydraulic cylinders are subject to thermal expansion and contraction. This may result in changes to the boom and/or attachment position while the machine is stationary. Factors affecting thermal movement can include the length of time machine is stationary, hydraulic oil temperature, ambient air temperature and boom and/or attachment position.
- Precautions to avoid all hazards in the work area must be taken by the user before and during operation of the machine.

Section 1- General Safety Practices

1.3 OPERATION SAFETY

Note: The manufacturer has no direct control over machine application and operation. Therefore, safety issues listed in this manual are non-exhaustive. The user and operator are responsible for conforming with good safety practices.

Electrical Hazards



- This machine is not insulated and does not provide protection from contact or being near electrical current.
- Always check for power lines before raising the boom.
- Maintain distance from electrical lines, apparatus, or any energized (exposed or insulated) parts according to the Minimum Approach Distance (MAD).

Voltage Range (Phase to Phase)	Minimum Approach Distance (MAD)
0 to 50 KV	10 ft (3 m)
Over 50KV to 200 KV	15 ft (5 m)
Over 200 KV to 350 KV	20 ft (6 m)
Over 350 KV to 500 KV	25 ft (8 m)
Over 500 KV to 750 KV	35 ft (11 m)
Over 750 KV to 1000 KV	45 ft (14 m)

Note: This requirement shall apply except where employer, local or governmental regulations are more stringent.

- Allow for machine movement and electrical line swaying.
- Maintain a clearance of at least 10 ft (3m) between any part of the machine and its occupants, their tools and their equipment from any electrical line or apparatus carrying up to 50,000 volts. One foot additional clearance is required for every additional 30,000 volts or less.

Section 1- General Safety Practices

- The minimum approach distance may be reduced if insulating barriers are installed to prevent contact, and the barriers are rated for the voltage of the line being guarded. These barriers shall not be part of (or attached to) the machine. The minimum approach distance shall be reduced to a distance within the designed working dimensions of the insulating barrier. This determination shall be made by a qualified person in accordance with the employer, local, or governmental requirements for work practices near energized equipment.



DANGER


Do not maneuver machine or personnel inside prohibited zone (MAD). Assume all electrical parts and wiring are energized unless known otherwise.

Section 1- General Safety Practices


Tip Over Hazard

General


- For additional load requirements, refer to the appropriate capacity chart.




- Never use an attachment without the appropriate original equipment manufacturer (OEM) approved capacity chart installed on the telehandler.
- Understand how to properly use the capacity charts located in cab.
- DO NOT** exceed rated lift capacity.
- Be sure that the ground conditions are able to support the machine.
- Be aware of wind conditions. Wind may cause load swing and dangerous side loads.
- Keep the machine a minimum of 2 ft (0,6 m) from holes, drop-offs, obstructions, debris, concealed holes and other potential hazards at ground level.



- DO NOT** raise boom unless frame is level (0 degrees), unless otherwise noted on capacity chart.



- DO NOT** level machine with boom/attachment above 4 ft (1,2 m). (AUS - **DO NOT** level machine with load more than 11.8 in (300 mm) above ground surface.)



- **MAINTAIN proper tire pressure** at all times. If proper tire pressures are not maintained, this machine could tip over.
- Refer to manufacturer's specifications for proper fill ratio and pressure requirements for tires equipped with ballast.



- Always wear seat belt.
- Keep head, arms, hands, legs and all other body parts inside operator's cab at all times.




If telehandler starts to tip over:

- **DO NOT JUMP**
- **BRACE YOURSELF** and **STAY WITH THE MACHINE**
- **KEEP YOUR SEAT BELT FASTENED**
- **HOLD ON FIRMLY**
- **LEAN AWAY FROM THE POINT OF IMPACT**

Section 1- General Safety Practices


Non-Suspended Load



OD0901

- **DO NOT** drive with boom raised.

Suspended Load



OW0150


- Tether suspended loads to restrict movement.
- Weight of all rigging (slings, etc.) must be included as part of load.
- **DO NOT** attempt to use telehandler frame-leveling to compensate for load swing.
- Keep heavy part of load closest to attachment.
- Never drag the load; lift vertically.

When driving with a suspended load:


- Start, travel, turn and stop slowly to prevent load from swinging.
- **DO NOT** extend boom.
- **DO NOT** raise the load more than 300 mm (11.8 in) above ground surface or the boom more than 45°.
- **DO NOT** exceed walking speed.

Travel Hazard


2-WHEEL FRONT STEER



4-WHEEL CIRCLE STEER



4-WHEEL CRAB STEER




OAL2030

- Steering characteristics differ between steer modes. Identify the steer mode settings of the telehandler being operated.
- **DO NOT** change steer modes while traveling. Steer modes must be changed while telehandler is stationary.
- Visually verify proper wheel alignment after each steer mode change.
- Ensure that adequate clearance is provided for both rear tail swing and front fork swing.
- Look out for and avoid other personnel, machinery and vehicles in the area. Use a spotter if you DO NOT have a clear view.
- Before moving be sure of a clear path and sound horn.
- When driving, retract boom and keep boom/attachment as low as possible while maintaining visibility of mirrors and maximum visibility of path of travel.
- Always look in the direction of travel.
- Always check boom clearances carefully before driving underneath overhead obstructions. Position attachment/load to clear obstacles.
- When driving in high speed, use only front wheel steer (if steering modes are selectable).
- Telehandlers equipped with solid or foam filled tires should not be used in applications requiring excessive roading or driving extended distances. In the event an application requires excessive roading or driving expanded distances, it is recommended to use telehandlers not equipped with solid or foam filled tires.

Section 1- General Safety Practices


Load Falling Hazard



OW0130

- Never suspend load from forks or other parts of carriage weldment. Use only approved lift points.
- **DO NOT** burn or drill holes in fork(s).
- Forks must be centered under load and spaced apart as far as possible.

Lifting Personnel



OW0171

- When lifting personnel, **USE ONLY** an approved personnel work platform, with proper capacity chart displayed in the cab.




OD0921

- **DO NOT** drive machine from cab when personnel are in platform.

Section 1- General Safety Practices

Driving Hazards on Slopes




To maintain sufficient traction and braking capabilities, travel on slopes as follows:

- When unloaded, drive with forks pointed downhill.
- When loaded, drive with the forks pointed uphill.
- For additional travel requirements, refer to the appropriate capacity chart.
- To avoid overspeeding the engine and drivetrain when driving down slopes, downshift to a lower gear before going downhill and use the service brake as necessary to maintain a slow speed. **DO NOT shift into neutral and coast downhill.**
- Avoid excessively steep slopes or unstable surfaces. To avoid tip over **DO NOT** drive across excessively steep slopes under *any* circumstances.
- Avoid turning on a slope. Never engage “inching” or shift to “Neutral” when going downhill.
- **DO NOT** park on a slope.

Pinch Points and Crush Hazards

Stay clear of pinch points and rotating parts on the telehandler.



OW0210

- Stay clear of moving parts while engine is running.



OW0220

- Keep clear of steering tires and frame or other objects.



OW0230

- Keep clear from under boom.

Section 1- General Safety Practices



OW0240

- Keep clear of boom holes.




OW0250

- Keep arms and hands clear of attachment tilt cylinder.



OW0260

- Keep hands and fingers clear of carriage and forks.



OW0960

- Keep others away while operating.

Fall Hazard



- Enter using the proper hand holds and steps provided. Always maintain 3-point contact when mounting or dismounting. Never grab control levers or steering wheel when mounting or dismounting the machine.
- **DO NOT** get off the machine until the shutdown procedure on page 4-4 has been performed.



- **DO NOT** carry riders. Riders could fall off machine causing death or serious injury.

Section 1- General Safety Practices

Chemical Hazards

Exhaust Fumes

- **DO NOT** operate machine in an enclosed area without proper ventilation.
- **DO NOT** operate the machine in hazardous environments unless approved for that purpose by JLG and site owner. Sparks from the electrical system and the engine exhaust can cause an explosion.

Flammable Fuel



OW0300

- **DO NOT** fill the fuel tank or service the fuel system near an open flame, sparks or smoking materials. Engine fuel is flammable and can cause a fire and/or explosion.

Hydraulic Fluid



OW0950

- **DO NOT** attempt to repair or tighten any hydraulic hoses or fittings while the engine is running or when the hydraulic system is under pressure.
- Stop engine and relieve trapped pressure. Fluid in the hydraulic system is under enough pressure that it can penetrate the skin.
- **DO NOT** use your hand to check for leaks. Use a piece of cardboard or paper to search for leaks. Wear gloves to protect hands from spraying fluid.

1.4 CLEARSKY (IF EQUIPPED)

Federal Communications Commission (FCC) Information for Users

FCC Statement Regarding Interference

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Section 1- General Safety Practices

Notice Regarding Radio Frequency Radiation Exposure

Do not operate your unit when a person is within eight inches (20 centimeters) of the antenna. A person or object within eight inches (20 centimeters) of the antenna could impair call quality and may cause the unit to operate at a higher power level than necessary, as well as expose that person to RF energy in excess of that established by the FCC RF Exposure Guidelines.

Important: The unit must be installed in a manner that provides a minimum separation distance of eight inches (20 centimeters) or more between the antenna and persons and just not be co-located or operate in conjunction with any other antenna or transmitter in order to satisfy FCC RF exposure requirements for mobile transmitting devices.

Important: To comply with the FCC RF exposure limits and to satisfy the categorical exclusion requirements for mobile transmitters, the requirements described in the following section, "Antenna Installation", must be met.

Antenna Installation

A minimum separation distance of eight inches (20 centimeters) must be maintained between the antenna and all persons.

The combined cable loss and antenna gain must not exceed +7.5 dBi (850 band). The combined cable loss and antenna gain must not exceed +2.5 dBi and total system output must not exceed 2.0W EIRP in the PCS (1900) band in order to comply with the EIRP limit of 24.232 (b). OEM installers must be provided with antenna installation instruction and transmitter operating conditions for satisfying RF exposure compliance.

SECTION 2 - PRE-OPERATION AND INSPECTION

2.1 PREPARATION, INSPECTION AND MAINTENANCE

The following table covers the periodic machine inspections and maintenance required. Consult local regulations for further requirements for telehandlers. The frequency of inspections and maintenance must be increased as necessary when the machine is used in a harsh or hostile environment, if the machine is used with increased frequency, or if the machine is used in a severe manner.

Inspection and Maintenance				
Type	Frequency	Primary Responsibility	Service Qualification	Reference
Pre-Operation Inspection	Beginning of each work shift or at each change of operator.	User or Operator	User or Operator	Operation & Safety Manual
Pre-Delivery Inspection (see note)	Before each sale, lease or rental delivery.	Owner, Dealer or User	Qualified Mechanic	Service Manual and applicable Inspection form.
Preventative Maintenance	At intervals as specified in the Service Manual and/or the Maintenance Charts located on the machine.	Owner, Dealer or User	Qualified Mechanic	Service Manual and Maintenance Charts

Note: *Inspection forms are available.*

Section 2 - Pre-Operation and Inspection

2.2 PRE-OPERATION CHECK AND INSPECTION

Note: Complete all required maintenance before operating unit.




WARNING


FALL HAZARD. Use extreme caution when checking items beyond your normal reach. Use an approved ladder.

The pre-operation check & inspection, performed at beginning of each work shift or at each change of operator, should include the following:

1. **Cleanliness** - Check all surfaces for leakage (oil, fuel or battery fluid) or foreign objects. Report any leakage to the proper maintenance personnel.
2. **Structure** - Inspect the machine structure for dents, damage, weld or parent metal cracks or other discrepancies.



PARENT METAL CRACK



WELD CRACK

3. **Safety Decals** - Ensure all safety decals are legible and in place. Clean or replace as required. See page 2-4 for details.
4. **Operation and Safety Manuals** - Operation & Safety Manual and AEM Safety Manual (ANSI only) are located in cab manual holder.
5. **Walk-Around Inspection** - See page 2-10 for details.
6. **Fluid Levels** - Check fluids, including fuel, brake fluid, hydraulic oil, engine oil and coolant. When adding fluids, refer to Section 7 - Lubrication and Maintenance and Section 9 - Specifications to determine proper type and intervals. Before removing filler caps or fill plugs, wipe all dirt and grease away from the ports. If dirt enters these ports, it can severely reduce component life.
7. **Attachments/Accessories** - Ensure correct capacity charts are installed on the telehandler. If provided, reference the Operation & Safety Manual of each attachment or accessory installed for specific inspection, operation and maintenance instructions.

Section 2 - Pre-Operation and Inspection

- Operational Check** - Once the walk-around inspection is complete, perform a warm-up and operational check (see page 2-13) of all systems in an area free of overhead and ground level obstructions. See Section 3 - Controls and Indicators for more specific operating instructions.



WARNING


If telehandler does not operate properly, immediately bring machine to a stop, lower boom and attachment to ground and stop the engine. Determine cause and correct before continued use.

Section 2 - Pre-Operation and Inspection

2.3 SAFETY DECALS



Ensure all **DANGER, WARNING, CAUTION** and instructional decals and proper capacity charts are legible and in place. Clean and replace as required.

ANSI (if equipped)




OAH2233

Section 2 - Pre-Operation and Inspection




OAH2243

Section 2 - Pre-Operation and Inspection




Section 2 - Pre-Operation and Inspection

ISO (if equipped)




OAH2253

Section 2 - Pre-Operation and Inspection




Section 2 - Pre-Operation and Inspection



Section 2 - Pre-Operation and Inspection

2.4 WALK-AROUND INSPECTION



Begin your walk-around inspection at item 1, as noted below. Continue to your right (counterclockwise when viewed from top) checking each item in sequence.

INSPECTION NOTE: On all components, make sure there are no loose or missing parts, that they are securely fastened and no visible leaks or excessive wear exists in addition to any other criteria mentioned. Inspect all structural members including attachment for cracks, excessive corrosion and other damage.

1. **Boom Sections and Lift, Tilt, Extend/Retract, Compensating Cylinders -**

- Check front, top, side and rear wear pads for presence of grease.
- Pivot pins secure; hydraulic hoses undamaged, not leaking.

2. **Battery Compartment -** Cables tight, no visible damage or corrosion. Cover properly secured.

Section 2 - Pre-Operation and Inspection

- 3. Front Axle** - Steer cylinders undamaged, not leaking; pivot pins secure; hydraulic hoses undamaged, not leaking.
- 4. Front Lights (if equipped)** - Clean and undamaged.
- 5. Wheel/Tire Assembly** - Properly inflated and secured; no loose or missing lug nuts. Inspect for worn tread, cuts, tears or other discrepancies.
- 6. Mirror** - Clean and undamaged.
- 7. Cab and Electrical** -
 - General appearance; no visible damage.
 - Frame level indicator(s) and window glass undamaged and clean.
 - Gauges, switches, joystick, foot controls and horn operational.
 - Check seat belt for damage, replace belt if frayed or cut webbing, damaged buckles or loose mounting hardware.
- 8. Boom Sensor (if equipped)** - See Inspection Note.
- 9. Wheel/Tire Assembly** - Properly inflated and secured; no loose or missing lug nuts. Inspect for worn tread, cuts, tears or other discrepancies.
- 10. Rear Axle** - Steer cylinders undamaged, not leaking; pivot pins secure; hydraulic hoses undamaged, not leaking.
- 11. Rear Lights (if equipped)** - Clean and undamaged.
- 12. Wheel Chock (if equipped)** - See inspection note.
- 13. Main Control Valve** - See inspection note.
- 14. Reversing Camera (if equipped)** - See inspection note.
- 15. Mirror (if equipped)** - Clean and undamaged.
- 16. Reversing System (if equipped)** - See inspection note.
- 17. Rear Lights (if equipped)** - Clean and undamaged.
- 18. LSI Sensor (if equipped)** - See inspection note.
- 19. Wheel/Tire Assembly** - Properly inflated and secured; no loose or missing lug nuts. Inspect for worn tread, cuts, tears or other discrepancies.
- 20. Air Pre-Cleaner (if equipped)** - Check and clean as required.
- 21. Engine Compartment** -
 - Drive belts, check condition and replace as required.
 - Engine mounts - See inspection note.
 - Engine cover properly secured.
 - Air Shutoff Valve (ASOV) (if equipped) - See inspection note.
- 22. Mirror** - Clean and undamaged.

Section 2 - Pre-Operation and Inspection

- 23. Wheel/Tire Assembly** - Properly inflated and secured; no loose or missing lug nuts. Inspect for worn tread, cuts, tears or other discrepancies.
- 24. Front Lights (if equipped)** - Clean and undamaged.
- 25. Attachment** - Properly installed, see "*Attachment Installation*" on page 5-13.

This Page Intentionally Left Blank

Section 2 - Pre-Operation and Inspection

2.5 WARM-UP AND OPERATIONAL CHECKS

Warm-Up Check

During warm-up period, check:

1. Heater, defroster and windshield wiper (if equipped).
2. Check all lighting systems (if equipped) for proper operation.
3. Adjust mirror(s) for maximum visibility.



WARNING

CUT/CRUSH/BURN HAZARD. Keep engine cover closed while engine is running.

Operational Check

When engine warms, perform an operational check:

1. Service brake and parking brake operation.
2. Forward and reverse travel.
3. Steering in both directions with engine at low idle (steering lock to lock will not be reached). Check in each steering mode.
4. Horn and back-up alarm. Must be audible from inside operators cab with engine running.
5. All joystick functions - operate smoothly and correctly.
6. Perform any additional checks described in Section 8.

2.6 OPERATOR CAB

The telehandler is equipped with an open or enclosed ROPS/FOPS cab.



WARNING

Never operate telehandler unless the overhead guard, cab structure and right side glass or screen are in good condition. Any modification to this machine must be approved by JLG to assure compliance with ROPS/FOPS certification for this cab/machine configuration. If the overhead guard or cab structure is damaged, the **CAB CANNOT BE REPAIRED**. It must be **REPLACED**.



WARNING


Never drill, cut, and/or weld to cab. Any modification to this machine must be approved by JLG to assure compliance with machine configuration. If unauthorized drilling, cutting and/or welding is present, the cab must be **REPLACED**.

Section 2 - Pre-Operation and Inspection

2.7 WINDOWS

Keep all windows and mirrors clean and unobstructed.


Cab Door Window (if equipped)



OAL1670

- Cab door (1) must be closed during operation.
- During operation the cab door window (2) must either be latched open or closed.
- Open the cab door window using lever (3) and secure it in the latch.
- Rotate knob (4) inside the cab or outside the cab to unlatch the window.

Rear Window



- Lift lever (5) and push to open rear window (6).
- Lift lever and pull to close.

This Page Intentionally Left Blank


SECTION 3 - CONTROLS AND INDICATORS

3.1 GENERAL

This section provides the necessary information needed to understand control functions.

Section 3 - Controls and Indicators

3.2 CONTROLS



OAH2132

1. **Park Brake Lever (if equipped):** See page 3-4.
2. **Accelerator Pedal:** Pressing down the pedal increases engine and hydraulic speed.
3. **Ignition Switch:** Key activated. See page 3-6.
4. **Service Brake Pedal:** The further the pedal is depressed, the slower the travel speed.
5. **Tilt Steering Column (if equipped):** See page 3-11.
6. **Quick Attach Switch (if equipped):** Used in conjunction with the joystick to hydraulically lock or unlock an attachment.
7. **Transmission Control Lever:** See page 3-7.
8. **Park Brake Switch (if equipped):** See page 3-4.
LSI Override Switch (if equipped): See page 3-10.
9. **Instrument Panel:** See page 3-12.


Section 3 - Controls and Indicators

- 10. Steering Wheel:** Turning the steering wheel to the left or right steers the machine in the corresponding direction. Three steering modes are available. See "Steer Modes" on page 3-20.
- 11. Horn Button:** Depress button to sound horn.
- 12. Frame Level Indicator:** Enables operator to determine the left to right level condition of the telehandler.
- 13. Accessory Control Lever (if equipped):** See page 3-18.
- 14. LSI Indicator (if equipped):** See page 3-8.
- 15. Power Outlet:** 12V receptacle.
- 16. Joystick:** See page 3-14.
- 17. Right Hand Console:** See page 3-16.
- 18. Air Shutoff Valve (ASOV) Indicator Lamp (if equipped):** Indicates when the ASOV valve has been actuated.
- 19. Air Shutoff Valve (ASOV) Test Switch (if equipped):** See page 8-3.
- 20. Reversing Camera Monitor (if equipped):** See page 3-25.

Section 3 - Controls and Indicators

Park Brake

Park Brake Switch (if equipped)



Park brake switch (1) controls the application and release of the park brake. Indicator light on instrument panel illuminates to indicate brake is applied.

- Depress top of switch to engage park brake. With park brake applied, transmission will not engage forward or reverse.
- Depress bottom of switch to disengage park brake.



WARNING


MACHINE ROLL-AWAY HAZARD. Always move park brake switch to "ON" position, lower boom to ground and stop engine before leaving cab.



WARNING

CRUSH HAZARD. Turning engine off applies the park brake. Applying park brake or turning engine off while traveling will cause unit to stop abruptly and could cause load loss. To stop the machine in an emergency, either apply the park brake or turn off engine.

Park Brake Lever (if equipped)



Park brake lever (2) controls the application and release of the park brake. Indicator light on instrument panel illuminates to indicate brake is applied.

- Pull lever up to engage park brake. With park brake applied, transmission will not engage forward or reverse.
- Lift detent ring and push lever down to disengage park brake.



WARNING

MACHINE ROLL-AWAY HAZARD. Always move park brake lever to "ON" position, lower boom to ground and stop engine before leaving cab.



WARNING


CRUSH HAZARD. Turning engine off applies the park brake. Applying park brake or turning engine off while traveling will cause unit to stop abruptly and could cause load loss. To stop the machine in an emergency, either apply the park brake or turn off engine.

Parking Procedure

1. Using service brake, stop telehandler in an appropriate parking area.
2. Follow "Shut-Down Procedure" on page 4-4.

Section 3 - Controls and Indicators


Ignition



OAL1282

- Position **P**: Not active, reserved for future use.
- Position **0**: Engine off.
- Position **1**: Voltage available for all electrical functions. Hold in position until engine preheat indicator on instrument panel goes out. Prohibits rotating switch to position 2 in the event the engine does not start. Rotate key to position 0 then back to position 2 to re-engage starter.
- Position **2**: Engine start.
- Not active, reserved for future use.

Transmission Control Lever



OAL1292

Transmission control lever (1) engages forward or reverse travel.

- Lift and push lever forward for forward travel; lift and pull lever rearward for reverse travel. Move lever to centered position for 'Neutral'.
- When traveling in REVERSE, the back-up alarm will automatically sound.
- Drive in reverse and turn only at slow rates of speed.
- Do not increase engine speed with the transmission in forward or reverse and the service brake depressed in an attempt to get quicker hydraulic performances. This could cause unexpected machine movement.



WARNING

TIP OVER/CRUSH HAZARD. Bring telehandler to a complete stop before shifting transmission control lever. A sudden change in direction of travel could reduce stability and/or cause load to shift or fall.


Section 3 - Controls and Indicators

Load Stability Indicator - LSI (if equipped)



WARNING

TIP OVER HAZARD. The LSI considers only longitudinal stability limitations, observe all operating parameters. Failure to follow operating parameters of the telehandler could damage the equipment and/or cause tip over.



The LSI (9) provides visual and audible indication of forward stability limitations when machine is static on firm, level surface.

- Green LED (10) will illuminate when LSI power is on.
- When approaching forward stability limitations LEDs progressively illuminate, green (11), then orange (12) and finally red (13).
- If the red LED illuminates the warning buzzer also sounds.

The LSI has two modes:

Active Mode

- As the telehandler reaches forward stability limitations and the red LED (13) illuminates, the automatic function cut-out is activated. All boom functions are disabled except for boom retract and boom lift. Retract boom to re-enable functions.
- In some instances the LSI system may slow down or stop boom functions if operated close to forward stability limitations. When LEDs begin to flash, certain functions can not be operated. Retract boom and/or return the joystick to neutral position for a short period to allow system to reset and LEDs to stop flashing before proceeding with operation.

Passive Mode

- The orange LED (15) illuminates when the following occurs:
 - The park brake is not applied and transmission control lever is in the forward or reverse position.
- When approaching forward stability limitations, visual and audible indication is provided and the automatic function cut-out and/or slow down feature is disabled.
- Travel in accordance with the requirements set forth in Section 1- General Safety Practices.
- Test LSI (14) at the beginning of each work shift. See Section 8 - Additional Checks.
- When placing a load, ensure axles are not fully steered in either direction.




WARNING

TIP OVER HAZARD. If the green, orange and red LEDs flash and warning buzzer sounds, retract and lower boom immediately. Determine cause and correct before continued use.

Section 3 - Controls and Indicators

LSI Override Switch (if equipped)



OAL1332

The LSI override switch (1) momentarily disables the automatic function cut-out.


- Depress and hold top of switch up to 30 seconds while operating joystick to momentarily disable the automatic function cut-out.
- Release switch to re-enable the automatic function cut-out.



WARNING

TIP OVER HAZARD. Exceeding lift capacity of the telehandler could damage the equipment and/or cause tip over.

Steering Column Adjuster (if equipped)



OAL1342

The steering column adjustment lever (1) controls the steering column position.

- Follow “*Shut-Down Procedure*” on page 4-4.
- Turn lever counterclockwise to unlock.
- Place steering column in the desired position.
- Turn lever clockwise to lock steering wheel.




WARNING

TIP OVER/CRUSH HAZARD. Bring telehandler to a complete stop and shutdown engine before adjusting steering column. A sudden change in direction of travel could reduce stability and/or cause load to shift or fall.

Section 3 - Controls and Indicators

Instrument Panel



NOTICE

EQUIPMENT DAMAGE. When a red indicator illuminates (except park brake), immediately bring machine to a stop, lower boom and attachment to ground and stop the engine. Determine cause and correct before continued use.

1. **Turn Signal Indicator (if equipped):** Illuminates when turn signal is active.
2. **High Beam Indicator (if equipped):** Illuminates when high beam lights are on.
3. **Check Engine Indicator:** Illuminates when maintenance is required. See Service Manual for details.
4. **Low Fuel Indicator:** Illuminates when fuel level is low.
5. **Fuel Gauge:** Indicates amount of fuel in fuel tank.
6. **Engine Warning Indicator:** Illuminates when engine is in a critical state. Determine cause and correct before continued use.
7. **Engine Pre-Heat Indicator:** Illuminates with ignition key in position P. Light goes out when start temperature has been reached.
8. **Steer Mode Indicators:** Illuminates active steering mode.
9. **System Distress Indicator:** Illuminates when an issue with the fuel level or machine system is present. Flashes when an issue with the machine charge system is present.
10. **Park Brake Indicator:** Illuminates when park brake is applied.

Display Screen


- 11. *Speed*:** Telehandler travel speed displayed in miles per hour (mph) or kilometers per hour (kph).
- 12. *Engine Coolant Temperature and Fault Codes*:**
 - a. Engine Coolant Temperature - Normally shown. Displays engine coolant temperature.
 - b. Fault Codes - Replaces the engine coolant temperature. Displays fault codes of engine and machine systems.
- 13. *Engine Speed, Battery Voltage and Operating Hours*:** Display rotates showing the three items.
 - a. Engine Speed - Displays engine speed in revolutions per minute (rpm).
 - b. Battery Voltage - Displays voltage supplied by battery.
 - c. Operating Hours - Displays total hours of telehandler operation.

Section 3 - Controls and Indicators

Joystick

Refer to lift/loader joystick pattern switch (see page 3-17) on right hand console to verify control pattern before operating.

Lift Joystick Pattern



The joystick (1) controls the boom, attachment tilt and auxiliary hydraulic functions.

Boom Functions

- Move the joystick back to lift boom; move joystick forward to lower boom; move joystick right to extend boom; move joystick left to retract boom.
- The speed of boom functions depends upon the amount of joystick travel in corresponding direction. Increasing engine speed will also increase function speed.
- For two simultaneous boom functions, move the joystick between quadrants. For example; moving the joystick forward and to the left will lower and retract boom simultaneously.

Attachment Function

Tilt control is enabled by the left button (2).

- While depressing button move joystick right to tilt down; move joystick left to tilt up.

Auxiliary Hydraulic Functions


The right button (3) enables function of attachments that require hydraulic supply for operation. See Section 5 - Attachments and Hitches for approved attachments and control instructions.



WARNING

TIP OVER/CRUSH HAZARD. Rapid, jerky operation of controls will cause rapid, jerky movement of the load. Such movements could cause the load to shift or fall or could cause the machine to tip over.

Loader Joystick Pattern



The joystick (1) controls the boom, attachment tilt and auxiliary hydraulic functions.

Boom Functions

- Move the joystick back to lift boom; move joystick forward to lower boom
- Extend/retract is enabled by the left button (2). While depressing button move joystick right to extend boom; move joystick left to retract boom.
- The speed of boom functions depends upon the amount of joystick travel in corresponding direction. Increasing engine speed will also increase function speed.
- For two simultaneous boom functions, move the joystick between quadrants. For example; moving the joystick forward and to the left will lower boom and tilt attachment up simultaneously.

Attachment Function

Tilt control is enabled by the joystick.

- Move joystick right to tilt down; move joystick left to tilt up.

Auxiliary Hydraulic Functions

The right button (3) enables function of attachments that require hydraulic supply for operation. See Section 5 - Attachments and Hitches for approved attachments and control instructions.




WARNING

TIP OVER/CRUSH HAZARD. Rapid, jerky operation of controls will cause rapid, jerky movement of the load. Such movements could cause the load to shift or fall or could cause the machine to tip over.

Section 3 - Controls and Indicators

Right Hand Console



1. **Steer Select Switch:** Three position switch. Three steer modes available: 4-Wheel Circle Steer, 2-Wheel Front Steer and 4-Wheel Crab Steer. See page 3-20.
2. **Boom Work Light Switch (if equipped):** On/Off switch.
3. **Front Work Light Switch (if equipped):** On/Off switch.
4. **Rear Work Light Switch (if equipped):** On/Off switch.

Note: Accessory control lever (if equipped) must be on to enable work light switches.

5. **Front Wiper Switch (if equipped):** Three position switch. Depress right side of switch for fast speed; middle position for slow speed; left side to turn off.
6. **Front Windshield Washer Switch (if equipped):** Depress right side of switch and hold to activate washer fluid.
7. **Skylight and Rear Wiper Switch (if equipped):** Three position switch. Move switch to middle position to turn wipers on; depress and hold right side of switch to activate washer fluid; depress left side of button to turn off.
8. **Reversing Fan Switch (if equipped):** See page 3-19.
9. **Auxiliary Hydraulic Pressure Relief Switch:** Relieves auxiliary hydraulic circuit pressure. See page 5-19.
10. **Beacon Light Switch (if equipped):** On/Off switch.

- 11. Front/Rear Auxiliary Hydraulic Switch (if equipped):** Depress front of switch to enable front auxiliary hydraulics. Depress back of switch to enable rear auxiliary hydraulics.
- 12. Hazard Light Switch (if equipped):** On/Off switch.
- 13. Lift/Loader Joystick Pattern Switch:** Depress left side of switch to activate lift joystick pattern. Depress right side of switch to activate loader joystick pattern.


Heater and Air Conditioning Controls (if equipped)

- 14. Fan Speed Switch (if equipped):** Four position rotary switch.
- 15. Air Conditioning Switch (if equipped):** On/Off switch.
- 16. Temperature Control Switch (if equipped):** Adjustable rotary switch.
- 17. Air Louver (if equipped):** Four individually adjustable air louvers.

Section 3 - Controls and Indicators

Accessory Control Lever (if equipped)

The accessory control lever (1) enables the work lights and operates the turn signals, parking lights and headlights.




Turn Signals

- Push the lever forward (2) to activate the left turn signal.
- Pull the lever back (3) to activate the right turn signal.
- The lever must be manually returned to the center position to deactivate either turn signal. The lever will not cancel automatically after a turn.

Parking Lights, Headlights and Work Lights

- Turn the twist grip (4) of the lever counterclockwise to the first position (5) to turn on the parking lights and enable the work light switches (8).
- Turn the twist grip to the second position (6) to turn on the headlights.
- Raise/lower the lever to switch between low and high beam.
- Turn the twist grip clockwise to the OFF position (7) to turn all lights off.

Reversing Fan (if equipped)



The reversing fan enables the operator to clear debris from the engine cover grill (2). Two modes of operation are available at any engine speed.

1. **Timed** - Depress right side of switch (1) to activate. Fan will reverse automatically every 20 minutes for a duration of 5 seconds. Depress left side of switch to deactivate.
2. **Manual** - With switch (1) already activated, depress right side of switch again to immediately activate a fan reversal cycle.


Note: It is recommended to operate the reversing fan to remove debris prior to opening the engine cover.

Section 3 - Controls and Indicators

3.3 STEER MODES


Three steer modes are available for operator use.

2-Wheel Front Steer




OAL2030

4-Wheel Circle Steer





4-Wheel Crab Steer





Note: 2-Wheel Front Steer mode is required for travel on public roads.

Steer Mode Change



OAL2060

1. Bring machine to a stop using service brake while either circle steer mode (1) or crab steer mode (3) is selected.




OAM2400

2. Turn the steering wheel until the left rear wheel (4) is aligned with the side of the machine.
3. Select front steer mode (2).
4. Turn the steering wheel until the left front wheel (5) is aligned with the side of the machine.
5. Wheels are now aligned. Select desired steer mode.

3.4 OPERATOR SEAT

Adjustments

Prior to starting engine adjust seat for position and comfort.



- 1. Suspension:** Use knob to adjust suspension to the appropriate setting. Turn clockwise to increase stiffness. Turn counterclockwise to reduce stiffness.
- 2. Fore/Aft:** Pull up on handle to move seat fore and aft.
- 3. Seat Belt:** Always fasten seat belt during operation. If required, a 3 in (76 mm) seat belt is available.

Section 3 - Controls and Indicators


Seat Belt



Fasten seat belt as follows:

1. Grasp both free ends of the belt making certain that belt webbing is not twisted or entangled.
2. With back straight in the seat, couple the retractable end (male end) of the belt into the receptacle (buckle) end of the belt.
3. With belt buckle positioned as low on the body as possible, pull the retractable end of the belt away from the buckle until it is tight across the lap.
4. To release belt latch, depress red button on the buckle and pull free end from buckle.

3.5 BOOM ANGLE AND EXTENSION INDICATORS



- The boom angle indicator (1) is located on the left side of the boom. Use this indicator to determine the boom angle when using the capacity chart (see *"Use of the Capacity Chart"* on page 5-10).
- Boom extension indicators (2) are located on the left side of the boom. Use these indicators to determine boom extension when using the capacity chart (see *"Use of the Capacity Chart"* on page 5-10).

Section 3 - Controls and Indicators

3.6 REVERSE SYSTEMS (IF EQUIPPED)



WARNING

CRUSH HAZARD. Running into persons or objects can cause death, serious injury, or damage to property and equipment. Always check mirrors and area behind vehicle before and when backing up. Reverse systems are for supplementary use only.

Reverse Sensing System

The reverse sensing system provides audible indication of objects to rear of unit while in reverse gear.

- Alarm sounds signaling machine is placed in reverse gear.

Note: *Reverse Sensing System detects objects larger than 36 square inches (232.25 square centimeters) area and is functional when machine is moving in reverse direction.*

- No alarm when detection zone is clear of objects.
- Pulsing alarm sounds when an object is in range of Reverse Sensing System. Alarm increases in frequency as object becomes closer.
- If alarm sounds at a frequency of eight pulses per second (8 Hz) an object is detected within 5 feet (1.5 m). Stop reverse direction of machine by applying service brake. Perform “*Shut-Down Procedure*” on page 4-4. Check and clear area behind machine of objects before proceeding in a reverse direction.

Reversing Camera

The reversing camera provides an additional view of the area directly behind the telehandler. The view displays on the reversing camera monitor when the telehandler is running and transmission is in reverse.



OY4070

The screen provides a graphic overlay indicating approximate distances of objects at rear of telehandler.

- **Red Line:** Approximately 5 ft (1,52 m).
- **Yellow Line:** Approximately 15 ft (4,57 m).

NOTICE

EQUIPMENT MALFUNCTION. Always keep camera lens clean. Camera may not operate normally at extremely high or low temperatures.

This Page Intentionally Left Blank

SECTION 4 - OPERATION

4.1 ENGINE

Starting the Engine

This machine can be operated under normal conditions in temperatures of 0°F to 104°F (-20°C to 40°C). Consult JLG for operation outside this range or under abnormal conditions.

If equipped for cold weather, -20°F to 0°F (-30°C to -20°C), see page 4-2 for hydraulic warm-up procedure.

1. Make sure all controls are in "Neutral" and all electrical components (lights, heater, defroster, etc.) are turned off. Apply park brake.
2. Turn the ignition switch to position 1 and wait until engine pre-heat indicator goes out.
3. Turn ignition switch to position 2 to engage starting motor. Release key immediately when engine starts. If engine fails to start within 20 seconds, release key and allow starting motor to cool for two minutes before trying again.
4. After engine starts, observe indicators. If indicators remain on for more than five seconds, stop engine and determine cause before restarting engine.
5. Warm up engine at approximately 1/2 throttle.

Note: Engine will not start unless transmission control lever is in "Neutral" and park brake is applied.



WARNING

ENGINE EXPLOSION. Do not spray ether into air intake for cold weather starting.



WARNING

UNEXPECTED MOVEMENT HAZARD. Always ensure that transmission control lever is in neutral and the service brake is applied before releasing park brake. Releasing park brake in either forward or reverse could cause the machine to move abruptly, causing an accident.

Section 4 - Operation

Cold Weather Starting

If equipped with cold weather engine components, the machine can be operated in temperatures down to -20°F (-30°C).

1. Follow start-up procedure on page 4-1 and allow engine to idle 10 minutes.
2. Operate each boom function a minimum of ten complete cycles.
3. While in 4-wheel circle steer mode, turn steering wheel completely left and right a minimum of ten complete cycles.
4. Disengage and engage the park brake a minimum of ten complete cycles.
5. Verify all joystick functions operate correctly and smoothly.
6. Staying under 1800 rpm, drive machine slowly for two minutes.
7. Machine is ready for operation.

Battery Boosted Starting



OW0530

If battery-boost starting (jump-start) is necessary, proceed as follows:

- Never allow vehicles to touch.
- Ensure booster vehicle engine is running.
- Connect the positive (+) jumper cable to positive (+) post of discharged battery.
- Connect the opposite end of positive (+) jumper cable to positive (+) post of booster battery.
- Connect the negative (-) jumper cable to negative (-) post on booster battery.
- Connect opposite end of negative (-) jumper cable to ground point on machine away from discharged battery.
- Follow standard starting procedures.
- Remove cables in reverse order after machine has started.



WARNING

BATTERY EXPLOSION HAZARD. Never jump start or charge a frozen battery as it could explode. Keep sparks, flames and lighted smoking materials away from the battery. Lead acid batteries generate explosive gases when charging. Wear safety glasses.

Section 4 - Operation

Normal Engine Operation

- Observe instrument panel frequently to be sure all systems are functioning properly.
- **Be alert for unusual noises or vibration.** When an unusual condition is noticed, park machine in safe position and perform shut-down procedure. Report condition to your supervisor or maintenance personnel.
- **Avoid prolonged idling.** If the engine is not being used, turn it off.
- When operating a machine at high altitudes, a decrease in machine performance may occur due to a decrease in air density. When operating a machine at high temperatures, a decrease in machine performance and an increase in engine coolant temperature may occur. Contact JLG for operation under abnormal conditions.

Shut-Down Procedure

When parking the telehandler, park in a safe location on flat level ground and away from other equipment and/or traffic lanes.

1. Apply the park brake.
2. Shift the transmission to "Neutral."
3. Lower forks or attachment to the ground.
4. Operate engine at low idle for 3 to 5 minutes. **DO NOT over rev engine.**
5. Shut off engine and remove ignition key.
6. Exit telehandler properly
7. Turn off electrical master switch (if equipped).
8. Block wheels (if necessary).

4.2 OPERATING WITH A NON-SUSPENDED LOAD

Lift Load Safely

- You must know the weight and load center of every load you lift. If you are not sure of the weight and load center, check with your supervisor or with the supplier of the material.



WARNING

TIP OVER HAZARD. Exceeding lift capacity of the telehandler could damage the equipment and/or cause tip over.

- Know the rated load capacities (see Section 5) of the telehandler to determine the operating range in which you can safely lift, transport and place a load.

Before Picking Up a Load

- Note the conditions of the terrain. Adjust travel speed and reduce amount of load if conditions warrant.
- Avoid lifting double-tiered loads.
- Make sure load is clear of any adjacent obstacles.
- Adjust spacing of forks so they engage the pallet or load at maximum width. See "Adjusting/Moving Forks" on page 5-21.
- Approach load slowly and squarely with fork tips straight and level. **NEVER** attempt to lift a load with just one fork.
- **NEVER** operate telehandler without a proper and legible capacity chart in the operator cab for the telehandler/attachment combination you are using.

Section 4 - Operation

Transporting a Load



- After engaging the load and resting it against the backrest, tilt the load back to position it for travel. Travel in accordance with the requirements set forth in Section 1- General Safety Practices and Section 5 - Attachments and Hitches.
- Maintain a slow speed when transporting a load.

Leveling Procedure

1. Position machine in best location to lift or place load.
2. Apply parking brake and move transmission control lever to NEUTRAL.
3. Observe level indicator to determine whether machine must be leveled prior to lifting load.
4. Move boom/attachment to 4 ft (1,2 m) off ground.

Important things to remember:

- Never raise the boom/attachment more than 4 ft (1,2 m) above ground unless telehandler is level.
- The combination of side tilt and load could cause the telehandler to tip over.

Placing a Load

Before placing any load be sure that:

- The landing point can safely support the weight of the load.
- The landing point is level; front to back and side to side.
- Use the capacity chart to determine safe boom extension range. See *“Use of the Capacity Chart”* on page 5-10.
- Align forks at the level load is to be placed, then extend boom slowly until load is just above area where it is to be placed.
- Lower the boom until the load rests in position and the forks are free to retract.

Disengaging a Load

Once the load has been placed safely at the landing point, proceed as follows:

1. With the forks free from the weight of the load, the boom can be retracted and/or the telehandler can be backed away from under the load if surface will not change level condition of telehandler.
2. Lower the carriage.
3. The telehandler can now be driven from the landing location to continue work.

Section 4 - Operation

4.3 OPERATING WITH A SUSPENDED LOAD

Lift Load Safely

- You must know the weight and load center of every load you lift. If you are not sure of the weight and load center, check with your supervisor or with the supplier of the material.



WARNING


TIP OVER HAZARD. Exceeding lift capacity of the telehandler could damage the equipment and/or cause tip over.

- Know the rated load capacities (refer to Section 5) of the telehandler to determine the operating range in which you can safely lift, transport and place a load.

Picking Up a Suspended Load

- Note the conditions of the terrain. Adjust travel speed and reduce amount of load if conditions warrant.
- Avoid lifting double-tiered loads.
- Make sure load is clear of any adjacent obstacles.
- **NEVER** operate telehandler without a proper and legible capacity chart in the operator cab for the telehandler/attachment combination you are using.
- Only use approved lifting devices rated for the lifting of the load.
- Identify the proper lifting points of the load, taking into consideration the center of gravity and load stability.
- Ensure to always properly tether loads to restrict movement.
- Refer to See “Use of the Capacity Chart” on page 5-10. for proper lifting guidelines in addition to the appropriate capacity chart in the operator cab.

Transporting a Suspended Load



OZ3160



OW0130

- Travel in accordance with the requirements set forth in Section 1- General Safety Practices and Section 5 - Attachments and Hitches.
- For additional requirements, refer to the appropriate capacity chart in the operator cab.

Important things to remember:

- Ensure the boom is fully retracted.
- Never raise the load more than 11.8 in (300 mm) above ground surface or the boom more than 45°.
- The combination of frame leveling and load could cause the telehandler to tip over.
- The guide persons and operator must remain in constant communication (verbal or hand) and be in visual contact with the operator at all times.
- Never place the guide persons between the suspended load and the telehandler.
- Only transport the load at walking speed, 0.9 mph (0.4 m/s), or less.

Leveling Procedure

1. Position machine in best location to lift or place load.
2. Apply parking brake and move transmission control lever to NEUTRAL.
3. Observe level indicator to determine whether machine must be leveled prior to lifting load.
4. Move boom so load is no more than 11.8 in (300 mm) above ground surface and boom/or boom is raised no more than 45°.

Section 4 - Operation

Placing a Suspended Load


Before placing any load be sure that:

- The landing point can safely support the weight of the load.
- The landing point is level; front to back and side to side.
- Use the capacity chart to determine safe boom extension range. See *"Use of the Capacity Chart"* on page 5-10.
- Align load at the level load is to be placed, then position boom slowly until load is just above area where it is to be placed.
- Ensure that the guide persons and operator remain in constant communication (verbal or hand) when placing the load.

Disengaging a Suspended Load

- Never place the guide persons between the suspended load and the telehandler.
- Once at the destination of the load, ensure to bring the telehandler to a complete stop and apply the park brake prior to disengagement of the lifting devices and tethers.

4.4 LOADING AND SECURING FOR TRANSPORT



Tiedown

1. Using a spotter, load the telehandler with boom as low as possible.
2. Once loaded, apply parking brake and lower boom until boom or attachment is resting on deck. Move all controls to "Neutral," stop engine and remove ignition key.
3. Secure machine to deck by passing chains through the designated tie down points as shown in the figure.
4. Do not tie down front of boom.

Note: User assumes all responsibility for choosing proper method of transportation and tie-down devices, making sure equipment used is capable of supporting weight of vehicle being transported and that all manufacturer's instructions and warnings, regulations and safety rules of their employer, Department of Transportation and/or any other local, state or federal/provincial laws are followed.



WARNING

TELEHANDLER SLIDE HAZARD. Before loading telehandler for transport, make sure deck, ramps and telehandler wheels are free of mud, snow and ice. Failure to do so could cause telehandler to slide.

Section 4 - Operation

Lifting

- When lifting machine, it is very important that the lifting device and equipment is attached only to designated lifting points.
- Make adjustments to the lifting device and equipment to ensure the machine will be level when elevated. The machine must remain level at all times while being lifted.
- Ensure that the lifting device and equipment is adequately rated and suitable for the intended purpose. See Section 9 - Specifications for machine weight or weigh machine.
- Remove all loose items from machine prior to lifting.
- Lift machine with smooth, even motion. Set machine down gently. Avoid quick or sudden motions that could cause shock loads to machine and/or lifting devices.

SECTION 5 - ATTACHMENTS AND HITCHES

5.1 APPROVED ATTACHMENTS

Coupler Mounted Attachments

To determine if an attachment is approved for use on specific telehandler you are using, perform following prior to installation.

- The attachment type, weight and dimensions must be equal to or less than the data shown on a capacity chart located in the operator cab.
- The model on the capacity chart must match the model telehandler being used.
- Hydraulically powered attachments must only be used on machines equipped with auxiliary hydraulics.
- Hydraulically powered attachments that require auxiliary electrics must only be used on machines equipped with auxiliary hydraulics and electrics.
- The attachment is clearly labeled in accordance with ANSI/ITSDF B56.6

If any of the above conditions are not met, do not use attachment. Telehandler may not be equipped with proper capacity chart or attachment may not be approved for the model telehandler being used. Contact JLG or a local distributor for further information.

JLG Supplied Fork Mounted Attachments

To determine if an attachment is approved for use on specific telehandler you are using, perform following prior to installation.

- The machine is authorized for use with JLG supplied fork mounted attachments.
- The model on the capacity chart must match the model telehandler being used.
- Hydraulically powered attachments must only be used on machines equipped with auxiliary hydraulics.
- Hydraulically powered attachments that require auxiliary electrics must only be used on machines equipped with auxiliary hydraulics and electrics.

If any of the above conditions are not met, do not use attachment. Telehandler may not be equipped with proper capacity chart or attachment may not be approved for the model telehandler being used. Contact JLG or a local distributor for further information.

For requirements regarding fork mounted attachments, see *"Fork Mounted Attachments"* on page 5-4.

Non-OEM Fork Mounted Attachments

JLG authorizes the use of non-OEM fork mounted attachments provided the criteria and instructions are followed. See *"Fork Mounted Attachments"* on page 5-4.

Section 5 - Attachments and Hitches

5.2 UNAPPROVED ATTACHMENTS

Do not use unapproved attachments for the following reasons:

- Range and capacity limitations for “will fit,” homemade, altered, or other non-approved attachments cannot be established.
- An overextended or overloaded telehandler can tip over with little or no warning and cause serious injury or death to the operator and/or those working nearby.
- The ability of a non-approved attachment to perform its intended function safely cannot be assured.



WARNING

Use only approved attachments. Attachments which have not been approved for use with your telehandler could cause machine damage or an accident.

This Page Intentionally Left Blank

Section 5 - Attachments and Hitches

5.3 FORK MOUNTED ATTACHMENTS

General Requirements

- Certain fork mounted attachments have a dedicated capacity chart. The attachment type, weight and dimensions must be equal to or less than the data shown on a capacity chart located in the operator cab. If it does not have a dedicated capacity chart, utilize the applicable carriage capacity chart on which the fork mounted attachment is attached.
- Fork mounted attachments are to be used on telehandlers with a standard carriage or side tilt carriage with pallet or lumber forks only.
- All fork mounted attachments must ensure secure connection with pins behind the heel of the forks. Do not secure using chains, straps or clamps directly to the forks, fork carriage, load bar and/or the boom.
- The forks of the carriage must support 2/3 of the load length for any load applied.
- The weight of the fork mounted attachment, rigging and the associated load is to be included in the total load being lifted. Refer to the capacity chart for the carriage in use.
- The capacity chart for the applicable carriage is established with a 24-inch load center, and the load center of the attachment and load must equal 24 inches to utilize the existing load chart capacities.
- When the load center of a combined attachment and/or load exceeds 24 inches, the equivalent load must be calculated to use with the carriage capacity chart. See *"Fork Mounted Attachments Equivalent Load"* on page 5-7.

Note: *When lifting loads, ensure that the center of gravity (CG) of the load being lifted is centered (right to left) between the forks.*

Non-OEM Attachments

User of non-OEM attachments is responsible for:

- Design
- Fabrication
- Workmanship
- Structural Integrity
- Maximum Capacity
- Fit and Function
- Overall Quality
- Any operation and safety instructions specific to the attachment
- The attachment is clearly labeled in accordance with ANSI/ITSDF B56.6
- Ensure that the attachment and use of the attachment complies with this and all other applicable standards

Section 5 - Attachments and Hitches

5.4 EQUIVALENT LOAD

Load Centers Beyond 24 Inches

Carriage and fork capacity charts provided by JLG are validated based on load centers of 24 inches. When the load center for the application being performed exceeds 24 inches, the Equivalent Load must be calculated to use with the carriage capacity chart.

Utilizing Equivalent Load Calculation is applicable for all carriage and fork arrangements. The forks of the JLG carriage must support 2/3 of the load length for any load applied.

Equivalent Load Calculation

The Equivalent Load is determined with the calculation below. The Equivalent Load is the value applied to the respective carriage capacity chart to determine the appropriate use zone(s).

$$\frac{\text{Weight of Attachment Load (lb)} \times \text{CG Distance of Load (in)}^1}{24 \text{ in}} = \text{Equivalent Load}$$

¹Center of Gravity (CG) Distance is measured horizontally from the front surface of the fork.

Example

- Weight of load = 5,000 pounds
- Center of gravity of load = 36 inches

The Equivalent Load for this example is:

$$\frac{5,000 \times 36}{24} = 7,500 \text{ pounds}$$

This value is cross-checked to the capacity of the forks to ensure the forks are rated to equally share this load. The user then utilizes the carriage capacity chart to determine where 7,500 lb can be safely moved and placed within the machine operating limits.

Fork Mounted Attachments Equivalent Load

Equivalent Load Calculation

The Equivalent Load is determined with the calculation below. The Equivalent Load is the value applied to the respective carriage capacity chart to determine the appropriate use zone(s).

$$\begin{aligned} & (\text{Weight of Attachment (lb)} \times \text{CG Distance of Attachment (in)}^1) \\ & + (\text{Weight of Attachment Load (lb)} \times \text{CG Distance of Load (in)}^1) \div 24 \text{ in} = \text{Equivalent Load} \end{aligned}$$

¹Center of Gravity (CG) Distance is measured horizontally from the front surface of the fork.

Example

- Weight of attachment = 500 pounds
- Center of gravity of attachment = 36 inches
- Weight of load = 1,000 pounds
- Center of gravity of load = 45 inches

The Equivalent Load for this example is:

$$\begin{aligned} 500 \times 36 &= 18,000 \\ 1,000 \times 45 &= 45,000 \\ \frac{18,000 + 45,000}{24} &= 2,625 \text{ pounds} \end{aligned}$$

This value is cross-checked to the capacity of the forks to ensure the forks are rated to equally share this load. The user then utilizes the carriage capacity chart to determine where 2,625 lb can be safely moved and placed within the machine operating limits.



WARNING


This calculation does not apply to Personnel Work Platforms. Refer to Telehandler Personnel Work Platform Operation & Safety Manual for additional information.

Section 5 - Attachments and Hitches

5.5 JLG SUPPLIED ATTACHMENTS

Attachment	Part Number	Quick Coupler	
		STD	UQC
Carriage, 50 in (1270 mm)	1001104435	X	
Carriage, 48 in (1220 mm)	1001113038		X
Side Tilt Carriage, 48 in (1220 mm)	1001102331	X	
	1001104009		X
Side Shift Carriage, 48 in (1220 mm)	1001104025		X
Fork, Pallet 2x4x48 in (50x100x1220 mm)	1001099458	X	X
Fork, Lumber 1.5x6x60 in (38x150x1525 mm)	1001099457	X	X
Fork, Block 2x2x48 in (50x50x1220 mm)	2340037	X	X
Bucket, Light Material 1.0 yd ³ (0,8 m ³)	1001102324	X	
Bucket, Light Material 1.7 yd ³ (1,3 m ³)	1001102323	X	
Bucket, Grapple 1.0 yd ³ (0,8 m ³)	1001102327	X	
Fork Mounted Hook	1001097205	X	X
Universal Quick Coupler Adapter	1001102332	X	

5.6 TELEHANDLER/ATTACHMENT/FORK CAPACITY



Prior to installing the attachment verify it is approved and the telehandler is equipped with the proper capacity chart. See *“Approved Attachments”* on page 5-1.

To determine the maximum capacity of the telehandler and attachment, use the **smallest** of the following capacities:

- Capacity stamped on the attachment identification plate (1).
- Fork capacities and load centers are stamped on the side of each fork (2) (if equipped). This rating specifies the maximum load capacity that the individual fork can safely carry at the maximum load center (3). Total attachment capacity is multiplied by the number of forks on the attachment (if equipped), up to the maximum capacity of the attachment.
- Maximum capacity as indicated on the proper capacity chart. See *“JLG Supplied Attachments”* on page 5-8.
- When the load rating of the telehandler differs from the capacity of the forks or attachment, the lower value becomes the overall load capacity.

Use the proper capacity chart to determine maximum capacity at various machine configurations. Lifting and placing a load may require use of more than one capacity chart based on machine configuration.

Other than block forks, all forks should be used in matched pairs, block forks used in matched sets.



WARNING

Never use an attachment without the appropriate JLG approved capacity chart installed on the telehandler.

Section 5 - Attachments and Hitches


5.7 USE OF THE CAPACITY CHART

To properly use the capacity chart (see page 5-11), the operator must first determine and/or have the following:

1. An approved attachment. See “JLG Supplied Attachments” on page 5-8.
2. The proper Capacity Chart(s).
3. Weight of the load being lifted.
4. Load placement information:
 - a. HEIGHT where the load is to be placed.
 - b. DISTANCE from the front tires of the telehandler to where the load is to be placed.
5. On the capacity chart, find the line for the height and follow it over to the distance.
6. The number in the load zone where the two cross is the maximum capacity for this lift. If the two cross at a division between zones, the smaller number must be used.

The number in the load zone must be equal to or greater than the weight of the load to be lifted. Determine the limits of the load zone on the capacity chart and keep within these limits.

Capacity Indicator Locations




Sample Capacity Chart

This Capacity Chart may be used with this model ONLY. The telehandler model is indicated on the boom or chassis. Model XXXX is used for demonstration purposes only.

Attachment type, weight and dimensions must be equal to or less than the data shown.

Quick Attach Type
Blank = Standard Quick Attach
UQC = Universal Quick Attach



Boom Angle

Boom Extension Indicator (arc)

Load zones indicate the maximum weight that may be safely lifted.

Load center must be equal to or less than value shown.

Note: This is a sample capacity chart **only!** **DO NOT** use this chart, use the one located in your operator cab.

! WARNING

TIP OVER HAZARD. All loads shown on rated capacity chart are based on machine being on firm ground with frame level (see page 4-6); the forks being positioned evenly on carriage; the load being centered on forks; proper size tires being properly inflated; and the telehandler being in good operating condition.

Section 5 - Attachments and Hitches


Example

A contractor owns a model xxxxx telehandler with a fork carriage. He knows this attachment may be used with his model since:

- The attachment style, weight, dimensions and load center match the attachment data on the capacity chart.
- The capacity chart is clearly marked for model xxxxx and corresponds with machine configuration being used.

Below are examples with various conditions the contractor may encounter and whether or not the load may be lifted.


	Load Weight	Distance	Height	OK to Lift
1	2500 lb (1134 kg)	6 ft (1,8 m)	4 ft (1,2 m)	Yes
2	2000 lb (907 kg)	9,5 ft (2,9 m)	8 ft (2,4 m)	NO
3	3000 lb (1361 kg)	4 ft (1,2 m)	9 ft (2,7 m)	Yes
4	5250 lb (2381 kg)	2 ft (0,6 m)	16 ft (4,9 m)	NO



Note: This is a sample capacity chart **only!** **DO NOT** use this chart, use the one located in your operator cab.

5.8 ATTACHMENT INSTALLATION

Standard Quick Attach



1. **Attachment**
2. **Attachment Pin Recess**
3. **Attachment Pin**
4. **Lock Pin**
5. **Retainer Pin** (mechanical quick attach)
6. **Quick Attach** (attachment tilt control in cab, see page 3-14 or 3-15)



WARNING


CRUSH HAZARD. Always be certain that carriage or attachment is properly positioned on boom and is secured by lock pin and retainer pin. Failure to ensure proper installation could permit carriage/attachment/load to disengage.

Section 5 - Attachments and Hitches


Mechanical Quick Attach

This installation procedure is designed for one-person operation. Prior to exiting cab, perform "Shut-Down Procedure" on page 4-4.


1. Tilt quick attach forward to provide clearance.
Check to be sure lock pin and retainer pin are out.




2. Align attachment pin with recess in attachment.
Raise boom slightly to engage attachment pin in recess.



3. Tilt quick attach back to engage attachment.



4. Insert lock pin and secure with retainer pin.




5. If attachment is equipped, connect auxiliary hydraulic hoses. See "Hydraulic Operated Attachment" on page 5-20.

Section 5 - Attachments and Hitches


Hydraulic Quick Attach

This installation procedure is designed for one-person operation.


1. Tilt quick attach forward to provide clearance.




2. Align attachment pin with recess in attachment. Raise boom slightly to engage attachment pin in recess.




3. Check to be sure lock pin is disengaged. Tilt quick attach back to engage attachment.



4. Press and hold switch (1) and button (2), at the same time move the joystick right to engage or left to disengage the quick attach.




5. Raise boom to eye level and visually check that the quick attach pin protrudes through the hole. If the pin does not protrude through the hole, place the attachment on the ground and return to step 2.



6. If attachment is equipped, connect auxiliary hydraulic hoses. See "Hydraulic Operated Attachment" on page 5-20.

This Page Intentionally Left Blank

Universal Quick Attach (UQC)



1. **Attachment**
2. **Attachment Recess**
3. **Engaging Edge**
4. **Lock Pin**
5. **Lock Pin Handle** (mechanical quick attach)
6. **Universal Quick Attach** (attachment tilt control in cab, see page 3-14 or 3-15)



WARNING


CRUSH HAZARD. Always be certain that carriage or attachment is properly positioned on boom and is secured by lock pin. Failure to ensure proper installation could permit carriage/attachment/load to disengage.

Section 5 - Attachments and Hitches


Mechanical Quick Attach

This installation procedure is designed for one-person operation. Prior to exiting cab, perform "Shut-Down Procedure" on page 4-4.


1. Tilt quick attach forward to provide clearance.
Check to be sure lock pin handles and pins are pulled up.




2. Align engaging edge with recess in attachment.
Raise boom slightly to engage edge in recess.



3. Tilt quick attach back to engage attachment.



4. Lower lock pin handles to engage lock pins.




5. If attachment is equipped, connect auxiliary hydraulic hoses. See "Hydraulic Operated Attachment" on page 5-20.


Hydraulic Quick Attach

This installation procedure is designed for one-person operation.


1. Tilt quick attach forward to provide clearance.




2. Align engaging edge with recess in attachment.
Raise boom slightly to engage edge in recess.



3. Check to be sure lock pins are disengaged. Tilt quick attach back to engage attachment.




4. Press and hold switch (1) and button (2), at the same time move the joystick right to engage or left to disengage the lock pins.



5. Raise boom to eye level and visually check that the lock pins protrude through the attachment holes. If the pins do not protrude through the holes, place the attachment on the ground and return to step 2.
6. If attachment is equipped, connect auxiliary hydraulic hoses. See "Hydraulic Operated Attachment" on page 5-20.

Section 5 - Attachments and Hitches

5.9 HYDRAULIC OPERATED ATTACHMENT



1. Install attachment (see page 5-13 or 5-17).
2. Press and hold auxiliary hydraulic pressure relief switch (1) for two seconds to relieve pressure at both auxiliary fittings (2).
3. Perform "Shut-Down Procedure" on page 4-4.
4. Connect attachment hoses to both auxiliary fittings.

5.10 ADJUSTING/MOVING FORKS

Carriages may have different locations where forks can be positioned. Two different methods can be used for repositioning, depending upon the carriage structure.

Note: Apply a light coating of appropriate lubricant to ease sliding of forks or fork bar.

To slide forks:

1. Ensure attachment is properly installed. See "Attachment Installation" on page 5-13 or "Universal Quick Attach (UQC)" on page 5-17.
2. If equipped, loosen fork locking bolt.
3. Elevate attachment to approximately 5 ft (1,5 m) and tilt carriage forward until fork heel is free from attachment.
4. Stand at the side of the carriage. To slide fork toward the center of the carriage, push the fork near the fork eye. To slide fork toward the edge of the carriage, pull the fork near the fork eye. To avoid pinching, do not place fingers or thumb between the fork and carriage structure.
5. If equipped, tighten fork locking bolt.

If removing fork bar is necessary:

1. Rest forks on ground.
2. If equipped, loosen fork locking bolt.
3. Remove fork bar.
4. Reposition forks.
5. Reinstall the fork bar and fork bar retaining mechanism(s).
6. If equipped, tighten fork locking bolt.

Section 5 - Attachments and Hitches

5.11 ATTACHMENT OPERATION

- Capacities and range limits for the telehandler change depending on the attachment in use.
- Separate attachment instructions must be kept in manual holder in cab with this Operation & Safety Manual. An additional copy must be kept with the attachment if it is equipped with a manual holder.

Note: Operations described within this section reference the Lift joystick pattern. Refer to page 3-15 if using Loader joystick pattern.


NOTICE

EQUIPMENT DAMAGE. Some attachments may contact the front tires or machine structure when the boom is retracted and the attachment is rotated. Improper use of attachment may result in attachment or machine structural damage.

NOTICE


EQUIPMENT DAMAGE. Avoid contact with any structure or object when lifting a load. Maintain clearance around boom structure and load. Failure to maintain clearance may result in attachment or machine structural damage.

Carriage with Forks



Use Carriage Attachment Capacity Chart

To determine maximum capacity, refer to "Telehandler/Attachment/Fork Capacity" on page 5-9.



The joystick (1) controls lift/lower and the extend/retract movement of the boom.

The tilt button (2) enables fork tilt.

- While pressing and holding button move joystick left to tilt up.
- While pressing and holding button move joystick right to tilt down.

Installation Procedure:


- Refer to "Attachment Installation" on page 5-13.

Equipment Damage Precautions:

- Do not use forks as a lever to pry material. Excessive prying forces could damage forks or machine structure.
- Do not attempt to lift loads that are attached or connected to another object.

Section 5 - Attachments and Hitches


Side Tilt Carriage



OAL1550

Use Side Tilt Carriage Attachment Capacity Chart

To determine maximum capacity, refer to "Telehandler/Attachment/Fork Capacity" on page 5-9.




OAL1601

The joystick (1) controls lift/lower and the extend/retract movement of the boom.

The tilt button (2) enables fork tilt.

- While pressing and holding button move joystick left to tilt up.
- While pressing and holding button move joystick right to tilt down.



OAL1950

To Side Tilt:

The auxiliary hydraulic button (3) enables carriage side tilt.

- While depressing button move joystick right to side tilt right.
- While depressing button move joystick left to side tilt left.

Installation Procedure:

- Refer to "Attachment Installation" on page 5-13.



WARNING


CRUSH HAZARD. Do not use side tilt to push or pull objects or load. Failure to comply could cause object or load to fall.

Equipment Damage Precautions:

- Do not use forks as a lever to pry material. Excessive prying forces could damage forks or machine structure.
- Do not attempt to lift loads that are attached or connected to another object.

Section 5 - Attachments and Hitches


Side Shift Carriage



OAL1540

Use Side Shift Carriage Attachment Capacity Chart

To determine maximum capacity, refer to "Telehandler/Attachment/Fork Capacity" on page 5-9.




OAL1601

The joystick (1) controls lift/lower and the extend/retract movement of the boom.

The tilt button (2) enables fork tilt.

- While pressing and holding button move joystick left to tilt up.
- While pressing and holding button move joystick right to tilt down.



OAL2210

To Side Shift:

The auxiliary hydraulic button (3) enables carriage side shift.

- While depressing button move joystick right to side shift right.
- While depressing button move joystick left to side shift left.

Installation Procedure:

- Refer to "Attachment Installation" on page 5-13.



WARNING


CRUSH HAZARD. Do not use side shift to push or pull objects or load. Failure to comply could cause object or load to fall.

Equipment Damage Precautions:

- Do not use forks as a lever to pry material. Excessive prying forces could damage forks or machine structure.
- Do not attempt to lift loads that are attached or connected to another object.

Section 5 - Attachments and Hitches


Bucket



OZ0730

Use Appropriate Bucket Capacity Chart

To determine maximum capacity, refer to "Telehandler/Attachment/Fork Capacity" on page 5-9.



OAL1611

The joystick (1) controls lift/lower and the extend/retract movement of the boom.

The tilt button (2) enables bucket tilt.

- While pressing and holding button move joystick left to tilt up.
- While pressing and holding button move joystick right to tilt down.

Installation Procedure:

- Refer to "Attachment Installation" on page 5-13.

Operation:


- Raise or lower boom to appropriate height for loading material from stockpile.
- Align telehandler with face of stockpile and drive slowly and smoothly into pile to load bucket.
- Tilt bucket up far enough to retain load and back away from pile.
- Travel in accordance with requirements set forth in Section 1- General Safety Practices.
- Tilt bucket down to dump load.

Equipment Damage Precautions:

- Except for lifting or dumping a load, the boom must be fully retracted for all bucket operations.
- Do not corner-load bucket. Distribute material evenly within the bucket. Bucket capacity charts are for evenly distributed loads only.
- Do not use bucket as a lever to pry material. Excessive prying forces could damage bucket or machine structure.
- Do not attempt to load material which is hard or frozen. This could cause severe damage to quick attach or machine structure.
- Do not use bucket for "back dragging." This could cause severe damage to quick attach.

Section 5 - Attachments and Hitches


Grapple Bucket



OZ1450

Use Grapple Bucket Capacity Chart

To determine maximum capacity, refer to "Telehandler/Attachment/Fork Capacity" on page 5-9.




OAL1611

The joystick (1) controls lift/lower and the extend/retract movement of the boom.

The tilt button (2) enables bucket tilt.

- While pressing and holding button move joystick left to tilt up.
- While pressing and holding button move joystick right to tilt down.



OAL1970

To open/close grapple:

The auxiliary hydraulic button (3) enables open/close movement of the grapple.

- While depressing button move joystick right to close grapple.
- While depressing button move joystick left to open grapple.

Installation Procedure:

- Refer to "Attachment Installation" on page 5-13.

Operation:


- Raise or lower boom to appropriate height and open grapple for loading material from stockpile.
- Align telehandler with face of stockpile and drive slowly and smoothly into pile to load bucket.
- Tilt bucket up far enough to retain load, close grapple, and back away from pile.
- Travel in accordance with requirements set forth in Section 1- General Safety Practices.
- Open grapple and tilt bucket down to dump load.

Equipment Damage Precautions:

- Except for lifting or dumping a load, the boom must be fully retracted for all bucket operations.
- Do not corner-load bucket. Distribute material evenly within the bucket. Bucket capacity charts are for evenly distributed loads only.
- Do not use bucket as a lever to pry material. Excessive prying forces could damage bucket or machine structure.
- Do not attempt to load material which is hard or frozen. This could cause severe damage to quick attach or machine structure.
- Do not use bucket for "back dragging." This could cause severe damage to quick attach.

Section 5 - Attachments and Hitches


Fork Mounted Hook



Use Appropriate Carriage Capacity Chart

To determine maximum capacity, refer to "Telehandler/Attachment/Fork Capacity" on page 5-9.

Suspend loads in accordance with requirements set forth in Section 1- General Safety Practices.



OAL1961

The joystick (1) controls lift/lower and the extend/retract movement of the boom.

The tilt button (2) enables fork mounted hook tilt.

- While pressing and holding button move joystick left to tilt up.
- While pressing and holding button move joystick right to tilt down.

Installation Procedure:

- Ensure carriage is properly installed. Refer to "Attachment Installation" on page 5-13.
- Secure the fork mounted hook to the forks by sliding the fork mounted hook onto the parent forks and install the retaining pin behind the vertical shank of the fork.

Operation:

- Pallet or lumber forks of an appropriate load rating must be used. Do not use with cubing or block forks.
- Weight of fork mounted hook and rigging must be included as part of total load being lifted.
- Do not use fork mounted hook with attachments capable of rotating (i.e. side tilt and swing carriages) without disabling the rotation features.


5.12 HITCHES

Machines may be equipped with various types of hitches. If not previously installed, secure hitch to machine with hardware supplied with installation.

Maximum towing capacity shall be the smallest of the telehandler and hitch capacities. Refer to page 9-7 for details.

Note: Ensure hitch is in lowest position when towing trailer. Speed and/or load may need reduced if traveling on ground which is not level.

Retrieval Hitch



Connecting for retrieval:

1. Remove safety pin (1) and pull pin (2) from hitch (3).
2. Place pin through hitch and retrieval device. Secure pin with safety pin.

Note: Retrieval devices are not intended for trailer towing applications.


Section 5 - Attachments and Hitches

Adjustable Auto Hitch

Hitch Capacities

Maximum combined weight of trailer and load 13 225 lb (6000 kg)

Maximum vertical load at hitch interface 2250 lb (1020 kg)



Connecting trailer for towing:

1. Rotate lever (1) until pin (2) fully retracts.
2. Align hitch mouth (3) and tow eye of trailer.
3. Reverse machine toward trailer.
4. After the tow eye contacts trigger (4), the pin and lever will be released.
5. If equipped, connect trailer harness to trailer plug (5).
6. If equipped, connect trailer hydraulics to rear auxiliary fittings.

Adjusting Hitch Height:


1. Remove safety pins (6).
2. While supporting hitch, remove pins (7).
3. Move hitch to desired height.
4. Replace pins and secure with safety pins.

Pin Hitch - CUNA C

Hitch Capacities

Maximum combined weight of trailer and load 13 225 lb (6000 kg)

Maximum vertical load at hitch interface 3305 lb (1500 kg)



Connecting trailer for towing:

1. Remove safety pin (1) and pull pin (2) from hitch (3).
2. Align machine and tow eye of trailer.
3. Place pin through hitch and tow eye. Secure pin with safety pin.


Section 5 - Attachments and Hitches

EEC Manual Pin Hitch

Hitch Capacities

Maximum combined weight of trailer and load26 450 lb (12 000 kg)

Maximum vertical load at hitch interface5500 lb (2500 kg)



Connecting trailer for towing:

1. Remove safety pin (1) and pull pin (2) from hitch (3).
2. Align machine and tow eye of trailer.
3. Place pin through hitch and tow eye. Secure pin with safety pin.

SECTION 6 - EMERGENCY PROCEDURES

6.1 TOWING A DISABLED PRODUCT

The following information assumes the telehandler cannot be moved under its own power.

- Before moving the telehandler, read all of the following information to understand options available. Then select the appropriate method.
- Machine mounted retrieval devices provide suitable means to attach a tow rope, chain or tow bar only in the event the telehandler becomes stuck or disabled.
- Retrieval devices are not intended for on-road trailer towing applications.
- The steering system permits manual steering if engine or power assist feature fails; however, **steering will be slow and will require much greater force.**
- **DO NOT** attempt to tow a telehandler that is loaded or the boom/attachment is raised above 4 ft (1,2 m).

Moving Short Distances

- If it is only necessary to move telehandler a short distance, less than 100 ft (30 m), it is permissible to use a vehicle of sufficient capacity to tow the unit with no previous preparation. Drive wheels will not roll.

Moving Longer Distances

- See Service Manual for details.
- Dependant on local regulations the appropriate machine Service Manual should be kept in the cab at all times.

Contact your local Authorized Distributor for specific instructions if neither of these methods are applicable.

Section 6 - Emergency Procedures

6.2 EMERGENCY LOWERING OF BOOM


In the event of total loss of engine power or hydraulic pump failure with an elevated load, the situation must be properly evaluated and dealt with on an individual basis. **Contact JLG Industries or the local Authorized Distributor for specific instructions.**

Secure the telehandler using the following procedures:

1. Clear the area around telehandler of all personnel.
2. Engage the parking brake. Place the transmission control lever in "NEUTRAL".
3. Block all four wheels.
4. Section off a large area under the boom to restrict any personnel from entering this area.
5. See Service Manual for information.

6.3 EMERGENCY EXIT FROM ENCLOSED CAB


Inside Cab



In an emergency the rear window can be used to exit the telehandler.

- Remove the latch pin (1). The window is then free to swing open.

Outside Cab (if equipped)




- Remove the knob (2) securing window. The window is then free to swing open.

This Page Intentionally Left Blank

SECTION 7 - LUBRICATION AND MAINTENANCE

7.1 INTRODUCTION

This section is intended as information to assist the operator to perform maintenance tasks only. Service the product in accordance with the maintenance schedule on the following pages.



The Lubrication (1) and Maintenance (2) Charts contain instructions that must be followed to keep this product in good operating condition. The Operation & Safety Manual and Service Manual contain more detailed service information with specific instructions.

Clothing and Safety Gear

- Wear all the protective clothing and personal safety devices issued to you or called for by job conditions.
- **DO NOT** wear loose clothing or jewelry that can get caught on controls or moving parts.

Section 7 - Lubrication and Maintenance

7.2 GENERAL MAINTENANCE INSTRUCTIONS

Prior to performing any service or maintenance on the telehandler, follow the shut-down procedure on page 4-4 unless otherwise instructed. Ensure telehandler is level, for proper fluid readings.

- Clean lubrication fittings before lubricating.
- After greasing telehandler, cycle all functions several times to distribute lubricants. Perform this maintenance procedure without attachment installed.
- Apply a light coating of engine oil to all linkage pivot points.
- Intervals shown are for normal usage and conditions. Adjust intervals for abnormal usage and conditions.
- Check all lubricant levels when lubricant is cool. For ease of filling hydraulic reservoir, use a funnel with a hose or flexible tube for best results.



WARNING

CUT/CRUSH/BURN HAZARD. Do not perform service or maintenance on the machine with the engine running.

7.3 MAINTENANCE SCHEDULES

Every 10 Hours




OC0880

Check Fuel Level



OC0910

Check Engine Oil
Level




OC0920

Check Hydraulic
Oil Level



OC0890


Check Tire
Condition and
Pressure



OC0980

Additional Checks
(see Section 8)

First 50 Hours



OC0990

Check Wheel Lug
Nut Torque

Section 7 - Lubrication and Maintenance

Every 50 Hours



OC0960

Drain Fuel/Water Separator




OC0970

Check Engine Coolant Level



OC0950

Check Air Filter




OC1150

Check Battery



OC0900


Check Brake Fluid Level



OC1020


Check Washer Fluid Level (if equipped)

First 250 Hours




OC1040

Change Axle Differential Oil



OC1050


Change Wheel End Oil



OF0630


Change Front Axle Drop Box Oil

Every 250 Hours




OC1110

Check Axle Differential Oil Level



OC1130

Check Wheel End Oil Levels



OF0700

Check Drop Box Oil



OC1160

Check Fan Belt




OC1090

Check Boom Wear Pads



OY4010

Check Enclosed Cab Air Filter (if equipped)




OC1010

Lubrication Schedule

Section 7 - Lubrication and Maintenance

Every 500 Hours



OC1140

Change Engine Oil
and Filter




OY4020

Change Air Filter
Elements



OC1220

Change Fuel Filter
(if equipped for LS)



OF0650


Check LSI
Calibration (if
equipped)



OC0990


Check Wheel Lug
Nut Torque

Every 1000 Hours




OC1040

Change Axle
Differential Oil




OC1050

Change Wheel End
Oil



OF0630

Change Front Axle
Drop Box Oil



OC1230

Change Hydraulic
Fluid and Filters



OY4030

Check Hydraulic
Tank Cap



OY4040

Change
Transmission Filter



OC1220

Change Fuel Filter
(if equipped for
ULS)

Every 1500 Hours




OC1240

Change Engine
Coolant

Section 7 - Lubrication and Maintenance

7.4 LUBRICATION SCHEDULES

250 Hour Lubrication Schedule



OAL1980

This Page Intentionally Left Blank

Section 7 - Lubrication and Maintenance



7.5 OPERATOR MAINTENANCE INSTRUCTIONS

Fuel System

A. Fuel Level Check

10 
OW0970


OW0990



OAH2141

1. Check fuel gauge (1) located on instrument panel in cab.
2. If fuel is low, proceed to fuel source and perform "Shut-Down Procedure" on page 4-4.
3. Turn fuel tank cap (2) and remove from filler neck.
4. Add diesel fuel as needed.
5. Replace fuel tank cap.


Note: Replenish diesel fuel at end of each work shift to minimize condensation.

NOTICE

EQUIPMENT DAMAGE. Do not allow machine to run out of fuel during operation. See Engine Operation & Maintenance Manual for details prior to servicing.

B. Drain Fuel/Water Separator

50 
OW0980



1. Perform "Shut-Down Procedure" on page 4-4.
2. Open the engine cover.
3. Loosen drain cock (3) on underside of fuel filter (4) and allow all water to drain into a glass until clear fuel is visible. Tighten drain cock.
4. Close and secure the engine cover.


Section 7 - Lubrication and Maintenance

Engine Oil

A. Engine Oil Level Check

10 
OW0970


OW1020




OAH2200

1. Perform "Shut-Down Procedure" on page 4-4.
2. Open the engine cover.
3. Remove dipstick (1) and check oil mark. The oil should be between the full (2) and add (3) marks within the crosshatched area of the dipstick.
4. Replace dipstick.
5. If oil is low, remove oil fill cap (4) and add motor oil to bring oil up to the full mark in the crosshatch area.
6. Replace oil fill cap.
7. Close and secure the engine cover.

Hydraulic Oil

A. Hydraulic Oil Level Check

10 
OW0970



1. Perform "Shut-Down Procedure" on page 4-4.
2. Check level of hydraulic oil at the sight gauge (5) on the frame. The oil level should be visible in the gauge window.
3. If hydraulic oil is low, remove oil fill cap (6) from filler neck. Add hydraulic fluid to bring oil up to the upper mark on the sight gauge.
4. Replace hydraulic oil fill cap.

Section 7 - Lubrication and Maintenance

Tires

A. Tire Air Pressure Check



1. Perform "Shut-Down Procedure" on page 4-4.
2. Remove valve stem cap.
3. Check tire pressure.
4. Add air if required. See page 9-4 for tire pressures.
5. Replace valve stem cap.

B. Tire Damage

For pneumatic tires, when any cut, rip or tear is discovered that exposes sidewall or tread area cords in the tire, measures be taken to remove the product from service immediately. Arrangements must be made for replacement of the tire or tire assembly.

For polyurethane foam filled tires, when any of the following are discovered, measures must be taken to remove the product from service immediately. Arrangements must be made for replacement of the tire or tire assembly.

- A smooth even cut through the cord piles which exceeds 3 in (7,5 cm) in total length.
- Any tears or rips (ragged edges) in the cord plies which exceeds 1 in (2,5 cm) in any direction
- Any punctures which exceed 1 in (2,5 cm) in diameter.

If a tire is damaged but within the above noted criteria, the tire must be inspected daily to ensure the damage has not propagated beyond the allowable criteria.

C. Tire and Wheel Replacement

It is recommended that a replacement tire to be the same size, ply, inflation medium and brand as originally installed. Refer to the appropriate parts manual for ordering information. If not using an approved replacement tire, replacement tires must have the following characteristics:

- Equal or greater ply/load rating and size of original.
- Tire tread contact width equal or greater than original.
- Wheel diameter, width and offset dimensions equal to the original.
- Approved for application by tire manufacturer (including inflation pressure and maximum tire load).

Due to size variations between tire brands, when selecting and installing a replacement tire ensure both tires on the axle are the same.

Section 7 - Lubrication and Maintenance


The rims installed have been designed for stability requirements which consist of track width, tire pressure and load capacity. Size changes such as rim width, center piece location, larger or smaller diameter, etc., without written factory recommendations, may result in unsafe condition regarding stability.

D. Wheel Installation

Torque lug nuts after first 50 hours and after each wheel installation.

Note: If machine is equipped with directional tire assemblies, wheel and tire assemblies must be installed with directional tread pattern "arrows" facing in direction of forward travel.

1. Start all nuts by hand to prevent cross threading. DO NOT use a lubricant on threads or nuts.



2. Tighten lug nuts in an alternating pattern as indicated in figure. See page 9-4 for torque value.



WARNING


TIP OVER HAZARD. Lug nuts must be installed and maintained at the proper torque to prevent loose wheels, broken studs and possible separation of wheel from the axle.

Section 7 - Lubrication and Maintenance

Air Intake System

A. Air Filter Check

50 
OW0980



1. Perform "Shut-Down Procedure" on page 4-4.
2. If equipped, locate precleaner bowl (1) on engine cover, remove cover from precleaner canister.
3. Remove dust from precleaner bowl.
4. Replace precleaner bowl and secure cover.
5. Open the engine cover.
6. Locate air cleaner (2) and remove dust from vacuumator valve (3) by squeezing bottom of valve to allow loose particles to fall out.
7. Close and secure engine cover.

NOTICE

EQUIPMENT DAMAGE. Only remove air cleaner cover to service elements. Excessive access to check elements can lead to premature element and/or engine failure.

B. Element Change

1. Perform "Shut-Down Procedure" on page 4-4.
2. Open engine cover.
3. Unlock air cleaner cover (4) and remove from air cleaner.
4. Remove outer primary element (5). Inspect element for damage then discard.
5. Thoroughly clean interior of air cleaner canister and vacuator valve.
6. Replace inner safety element (6) every third primary element change or if primary element was found to be damaged. If replacing inner safety element at this time, carefully slide element out and replace with new element.
7. Slide new primary element over inner safety element making sure sealing edge is flush with base of air cleaner.
8. Position air cleaner cover in place and lock into position.
9. Close and secure engine cover.

Note: Elements should never be washed or reused. Always install new elements.

NOTICE


EQUIPMENT DAMAGE. Primary and safety elements are required to be replaced if used in an application longer than two years regardless of hours of operation.

Section 7 - Lubrication and Maintenance

Engine Cooling System

A. Engine Coolant Level Check

50 
OW0980





1. Perform "Shut-Down Procedure" on page 4-4.
2. Open the engine cover.
3. Check coolant level in surge tank (1). When coolant is hot, the tank should be 1/2 to 3/4 full. When coolant is cool, bottle should be 1/4 to 1/2 full.
4. If coolant is low, allow fluid to cool.
5. Remove surge tank cap (2) slowly. Add coolant as required.
6. Replace overflow bottle cap.
7. Close and secure the engine cover.

Battery

A. Battery Check

50 
OW0980



1. Perform "Shut-Down Procedure" on page 4-4.
2. Remove the battery cover.
3. Wearing eye protection, visually inspect the battery (3). Check terminals for corrosion. Replace battery if it has a cracked, melted or damaged case.
4. Replace and secure the battery cover.


Section 7 - Lubrication and Maintenance

Brake System

A. Brake Fluid Level Check

50 
OW0980


OD1380




1. Perform "Shut-Down Procedure" on page 4-4.
2. The brake fluid level should be visible in the reservoir (1).
3. If brake fluid level is low, add hydraulic fluid as needed.

Note: All other work on the brake system must be performed by qualified personnel.

Windshield Washer System (if equipped)

A. Windshield Washer Fluid Level Check

50 
OW0980



1. Perform “*Shut-Down Procedure*” on page 4-4.
2. The windshield washer fluid should be visible in the reservoir (2).
3. If washer fluid level is low, add fluid as needed.

This Page Intentionally Left Blank

SECTION 8 - ADDITIONAL CHECKS

8.1 GENERAL

If any of the following test results cannot be achieved, the system is not functioning properly and the machine must be removed from service and repaired before continued operation.

8.2 LOAD STABILITY INDICATOR SYSTEM (IF EQUIPPED)

A. Load Stability Indicator System Test

10 
OW0970



The Load Stability Indicator (LSI) is intended to continuously monitor the forward stability of the telehandler. To check this feature, perform the following:

1. **Fully retract and level boom, with no load. Do not raise the boom during this test.**
2. Ensure machine is level.
3. Press the system check button on the LSI display. This will cause all LEDs to flash on and an audible warning to sound. This indicates that the system is functioning properly.

Section 8 - Additional Checks

8.3 REVERSE SENSING SYSTEM (IF EQUIPPED)

A. Reverse Sensing System Check



Reverse Sensing System provides audible indication of objects to rear of unit while in reverse gear.

1. Clear all people and/or obstacles behind machine before performing Reverse Sensing System check.
2. Start machine and depress and hold brake. Place machine in reverse gear.
3. Verify alarm sounds upon system start up.

Note: Reverse Sensing System detects objects of size more than 36 square inches (232.25 square centimeters) area and is functional when machine is moving in reverse direction.

Note: The use of a construction cone or similar object must be used to test the Reverse Sensing System.



WARNING

CRUSH HAZARD. Do not use a person to test the reverse sensing system.

4. Verify operation with no objects in detection zone. No audible alarm.
5. Verify operation when object is in range of approximately 9 to 15 ft (2.7 to 4.5 m). Produces pulsing audible alarm at a frequency of one per second (1 Hz).
6. Verify operation when object is in range of approximately 7 to 9 ft (2.1 to 2.7 m). Produces pulsing audible alarm. Produces pulsing audible alarm at a frequency of two per second (2 Hz).
7. Verify operation when object is range of approximately 5 to 7 ft (1.5 to 2.1 m). Produces pulsing audible alarm at a frequency of four per second (4 Hz).
8. Verify operation when object is under approximately 5 ft (1.5 m) from machine. Produces pulsing audible alarm at a frequency of eight per second (8 Hz).

8.4 AIR SHUTOFF VALVE (ASOV) (IF EQUIPPED)

A. Air Shutoff Valve Test



Air Shutoff Valve (ASOV) is an overspeed protection device mounted to the engine's air intake system. When the valve is actuated, it obstructs airflow intake and stops the engine. Weekly tests are recommended to ensure the valve remains in good working condition.

1. Start the engine, running at idle.
2. Open the red switch guard of ASOV test switch, then activate toggle to test mode (see page 3-2).
3. Rev the engine in neutral until the valve actuates at the test RPM of 1500. Once valve actuates, engine will stop.
4. Turn ignition to OFF.
5. Visually inspect valve to ensure it appears in good condition.
6. Reset valve by rotating valve handle to the Open position.

Note: *The handle cannot be turned unless the machine is off. Ensure the ignition is moved to the OFF position.*



WARNING

Do not use ASOV as an alternative to shutting down machine properly.

This Page Intentionally Left Blank

SECTION 9 - SPECIFICATIONS

9.1 PRODUCT SPECIFICATIONS

Fluids

If Equipped for ULS

Compartment or System	Type and Classification	Viscosities	Ambient Temperature Range			
			°F		°C	
			Min	Max	Min	Max
Engine Crankcase	Deutz DQC III-10 LA or Deutz DQC IV-10 LA	SAE 0W-40	-40	104	-40	40
		SAE 0W-30	-40	86	-40	30
		SAE 5W-30	-22	86	-30	30
		SAE 5W-40	-22	86	-30	30
		SAE 10W-30	-4	86	-20	30
		SAE 10W-40	-4	114	-20	45
		SAE 15W-40	6	114	-14	45
		SAE 20W-50	24	122	-5	50
Axle Differential and Wheel End	API GL5 with LS Additives	75W-90 LS	-40	115	-40	46
		80W-90 LS or 85W-90 LS	-4	115	-20	46
Hydraulic System	Mobilfluid 424	10W-30	6	115	-15	46
	Exxon Univis HVI		-40	100	-40	40
Brake System	Mobilfluid 424	10W-30	6	115	-15	46
Boom Wear Pad Grease	Mystik Tetrimoly	NLGI Grade 2	-4	104	-20	40
Grease Fittings	Extreme Pressure Grease	NLGI Grade 2 EP with Moly Additive or NLGI Grade 3 EP with Moly Additive	5	122	-15	50
Engine Coolant	Ethylene Glycol and Water	50/50 Mix	Standard			
		60/40 Mix	Cold Weather			
Fuel	EN590 ASTM D 975 Grade 1-D ASTM D 975 Grade 2-D (Maximum B5 Biodiesel)	Ultra Low Sulfur (S ≤ 15 mg/kg)				
Air Conditioning	Refrigerant R-134-a	Tetrafluoroethane				

Section 9 - Specifications

If Equipped for LS

Compartment or System	Type and Classification	Viscosities	Ambient Temperature Range			
			°F		°C	
			Min	Max	Min	Max
Engine Crankcase	Deutz DQC II-10, Deutz DQC III-10 or Deutz DQC IV-10	SAE 0W-40	-40	104	-40	40
		SAE 0W-30	-40	86	-40	30
		SAE 5W-30	-22	86	-30	30
		SAE 5W-40	-22	86	-30	30
		SAE 10W-30	-4	86	-20	30
		SAE 10W-40	-4	114	-20	45
		SAE 15W-40	6	114	-14	45
Axle Differential and Wheel End	API GL5 with LS Additives	75W-90 LS	-40	115	-40	46
		80W-90 LS or 85W-90 LS	-4	115	-20	46
Hydraulic System	Mobilfluid 424	10W-30	6	115	-15	46
	Exxon Unavis HVI		-40	100	-40	40
Brake System	Mobilfluid 424	10W-30	6	115	-15	46
Boom Wear Pad Grease	Mystik Tetrimoly	NLGI Grade 2	-4	104	-20	40
Grease Fittings	Extreme Pressure Grease	NLGI Grade 2 EP with Moly Additive or NLGI Grade 3 EP with Moly Additive	5	122	-15	50
Engine Coolant	Ethylene Glycol and Water	50/50 Mix	Standard			
		60/40 Mix	Cold Weather			
Fuel	EN590 ASTM D 975 Grade 1-D ASTM D 975 Grade 2-D (Maximum B5 Biodiesel)	Low Sulfur (S ≤ 500mg/kg)				
Air Conditioning	Refrigerant R-134-a	Tetrafluoroethane				

Capacities

Engine Crankcase Oil

Capacity with Filter Change.....9.6 qt (9,1 L)

Fuel Tank

Capacity 20 gal (76 L)

Cooling System

System Capacity 14 qt (13,2 L)

Hydraulic System

System Capacity27 gal (103 L)

Reservoir Capacity to Full Mark 19 gal (73 L)

Auxiliary Hydraulic Circuit Max Flow 18.7 gpm (71 lpm)

Brake System

System Capacity0.7 qt (0,7 L)

Axles

Differential Housing Capacity4.4 qt (4,2 L)

Wheel End Capacity 30.4 oz (0,9 L)

Front Axle Drop Box 23.7 oz (0,7 L)

Air Conditioning System (if equipped)

System Capacity 2.5 lb (1134 g)

Section 9 - Specifications

Tires

12.00 x 16.5, Bias - 12 Ply

Pneumatic 80 psi (5,5 bar)

Foam Approx 225 lb (102 kg)

14.00 x 17.5, Bias - 14 Ply

Pneumatic 70 psi (4,8 bar)

Foam Approx 250 lb (113 kg)

10.50 x 18.0, Bias - 16 Ply

Pneumatic 87 psi (6,0 bar)

Wheel Lug Nut

Torque 220 lb-ft (300 Nm)

Performance

Maximum Lift Capacity.....	5500 lb (2494 kg)
Maximum Lift Height	18.2 ft (5,5 m)
Capacity at Maximum Height	
Standard Quick Attach	4400 lb (1996 kg)
Universal Quick Attach.....	3000 lb (1360 kg)
Maximum Forward Reach	11 ft (3,4 m)
Capacity at Maximum Forward Reach	
Standard Quick Attach	1850 lb (839 kg)
Universal Quick Attach.....	1700 lb (771 kg)
Reach at Maximum Height.....	2 ft (0,6 m)
Maximum Travel Speed (see note)	17 mph (27 kph)
Maximum Travel Grade (boom in travel position)	
Gradeability	45%
Side Slope.....	8.75%

Note: Refer to machine specific documents and/or plates for local governmental requirements and/or restrictions.

Section 9 - Specifications

Dimensions

Overall Height	75.6 in (1920 mm)
Overall Width	71.5 in (1816 mm)
Track Width	58.5 in (1486 mm)
Wheelbase	90.0 in (2286 mm)
Length at Front Wheels	129.9 in (3299 mm)
Overall Length (less Attachment)	144.2 in (3663 mm)
Ground Clearance	10.8 in (274 mm)
Outside Turning Radius	126.0 in (3200 mm)
Turning Radius at Forks	169.0 in (4293 mm)
Maximum Operating Weight (no attachment)	12 500 lb (5670 kg)
Distribution of Maximum Operating Weight (no attachment, boom level and fully retracted)	
Front Axle	5270 lb (2390 kg)
Rear Axle	7230 lb (3280 kg)
Maximum Ground Bearing Pressure	
12.00 x 16.5	
Air Filled	148 lb/in ² (10,4 kg/cm ²)
Foam Filled	172 lb/in ² (12,1 kg/cm ²)
14.00 x 17.5	
Air Filled	125 lb/in ² (8,8 kg/cm ²)
Foam Filled	151 lb/in ² (10,6 kg/cm ²)
10.50 x 18.0	
Air Filled	235 lb/in ² (16,5 kg/cm ²)
33 x 12-20	Not Available at Publication

Machine Towing Capacity

Note: Refer to machine specific documents and/or plates for local governmental requirements and/or restrictions.

Off-Road	6600 lb (3000 kg)
On-Road	0 lb (0 kg)

This Page Intentionally Left Blank

A	D
Accessory Control Lever..... 3-18	Decals
Additional Checks 8-1	ANSI..... 2-4
Adjusting/Moving Forks 5-21	ISO..... 2-7
Air Conditioning System..... 9-3	Dimensions..... 9-6
Air Shutoff Valve Test..... 8-3	Disengaging a Load..... 4-7
Approved Attachments..... 5-1	Disengaging a Suspended Load 4-10
Attachment Installation	Driving Hazards on Slopes 1-10
Standard Quick Attach 5-13	
Universal Quick Attach 5-17	E
Attachment Operation 5-22	Electrical Hazards 1-2
Attachments	Emergency Exit from Enclosed Cab 6-3
JLG Supplied 5-8	Emergency Lowering of Boom 6-2
Auto Hitch, Adjustable 5-34	Emergency Procedures 6-1
Axles 9-3	Engine
B	Normal Operation 4-4
Battery 7-17	Starting 4-1
Boom Indicator	Engine Coolant Level 7-16
Angle..... 3-23	Engine Crankcase Oil..... 9-3
Extension..... 3-23	Engine Oil Level 7-10
Brake Fluid Level..... 7-18	F
Brake System..... 9-3	Fall Hazard 1-13
Bucket..... 5-28	Fluids..... 9-1
C	Fork Mounted Hook 5-32
Capacities 9-3	Fuel Level 7-8
Capacity 5-9	Fuel Tank 9-3
Capacity Chart	Fuel/Water Separator..... 7-9
Example..... 5-12	G
Sample (ANSI & CE)..... 5-11	General Maintenance..... 7-2
Capacity Indicator Locations..... 5-10	Grapple Bucket..... 5-30
Carriage w/Forks..... 5-23	H
Chemical Hazards..... 1-14	Hazard Classification System 1-1
Cooling System 9-3	Hitches..... 5-33
	Hydraulic Oil Level 7-11
	Hydraulic Operated Attachment 5-20
	Hydraulic System..... 9-3

Index

I
Ignition.....3-6
Instrument Panel.....3-12

J
Joystick
Lift Joystick Pattern3-14
Loader Joystick Pattern.....3-15

L
Leveling Procedure.....4-6, 4-9
Lifting Personnel 1-9
Load Falling Hazard..... 1-8
LSI.....3-8
Test.....8-1
LSI Override Switch.....3-10
Lubrication and Maintenance 7-1
Lubrication Schedule
250 Hour.....7-6

M
Maintenance Schedule
Every 10 Hours 7-3
Every 1000 Hours 7-5
Every 1500 Hours 7-5
Every 250 Hours..... 7-4
Every 50 Hours 7-4
Every 500 Hours..... 7-5
First 250 Hours 7-4
First 50 Hours..... 7-3

O
Operating with a Non-Suspended
Load 4-5
Operating with a Suspended Load 4-8
Operation 4-1
Operational Check2-14
Operator Cab2-15
Operator Maintenance Instructions 7-8
Operator Seat3-21

P
Park Brake 3-4
Parking Procedure 3-5
Performance 9-5
Picking Up a Suspended Load..... 4-8
Pin Hitch
CUNA C5-35
EEC Manual5-36
Pinch Points and Crush Hazards.....1-11
Placing a Load 4-7
Placing a Suspended Load.....4-10
Pre-Operation Check and Inspection 2-2

R
Retrieval Hitch5-33
Reverse Sensing System3-24
Check.....8-2
Reverse Systems3-24
Right Hand Console3-16

S
Safety Decals..... 2-4
Safety Practices 1-1
Safety Signal Words..... 1-1
Seat Belt.....3-22
Shut-Down Procedure..... 4-4
Side Shift Carriage.....5-26
Side Tilt Carriage5-24
Specifications 9-1
Steer Modes3-20
Steering Column Adjuster3-11

T

Tip Over Hazard.....	1-4
Tires	7-12, 9-4
Air Pressure.....	7-12
Damage	7-12
Replacement.....	7-12
Towing.....	6-1
Capacity	9-7
Transmission Control Lever	3-7
Transport	
Lifting.....	4-12
Tiedown.....	4-11
Transporting a Load	4-6
Transporting a Suspended Load.....	4-9
Travel Hazard	1-7

W

Walk-Around Inspection	2-10
Warm-Up	2-14
Wheel Lug Nut	9-4
Wheel Replacement	7-12
Windows.....	2-16
Windshield Washer Fluid Level	7-19



An Oshkosh Corporation Company

TRANSFER OF OWNERSHIP

To Product Owner:

If you now own but ARE NOT the original purchaser of the product covered by this manual, we would like to know who you are. For the purpose of receiving safety-related bulletins, it is very important to keep JLG Industries, Inc. updated with the current ownership of all JLG products. JLG maintains owner information for each JLG product and uses this information in cases where owner notification is necessary.

Please use this form to provide JLG with updated information with regard to the current ownership of JLG products. Please return completed form to the JLG Product Safety & Reliability Department via facsimile or mail to address as specified below.

**Thank You,
Product Safety & Reliability Department
JLG Industries, Inc.
13224 Fountainhead Plaza
Hagerstown, MD 21742
USA
Telephone: +1-717-485-6591
Fax: +1-301-745-3713**

NOTE: Leased or rented units should not be included on this form.

Mfg. Model: _____

Serial Number: _____

Previous Owner: _____

Address: _____

Country: _____ **Telephone:** _____

Date of Transfer: _____

Current Owner: _____

Address: _____












Country: _____ **Telephone:** _____

Who in your organization should we notify?

Name: _____

Title: _____

Hand Signals

 <p>OY1090</p> <p>EMERGENCY STOP - With both arms extended laterally, hands open downward, move arms back and forth.</p>	 <p>OY1100</p> <p>STOP - With either arm extended laterally, hand open downward, move arm back and forth.</p>	 <p>OY1110</p> <p>STOP ENGINE - Draw thumb or forefinger across throat.</p>
 <p>OY1120</p> <p>RAISE BOOM - With either arm extended horizontally, fingers closed, point thumb upward.</p>	 <p>OY1130</p> <p>LOWER BOOM - With either arm extended horizontally, fingers closed, point thumb downward.</p>	 <p>OY1140</p> <p>MOVE SLOWLY - Place one hand motionless in front of hand giving motion signal. (Raise load slowly shown)</p>
 <p>OY1150</p> <p>EXTEND BOOM - With both hands clenched, point thumbs outward.</p>	 <p>OY1160</p> <p>RETRACT BOOM - With both hands clenched, point thumbs inward.</p>	 <p>OY1170</p> <p>THIS FAR TO GO - With hands raised and open inward, move hands laterally, indicating distance to go.</p>
 <p>OY1180</p> <p>TILT FORKS UP - With one arm held at side, extend other arm upward at about 45 degrees.</p>	 <p>OY1190</p> <p>TILT FORKS DOWN - With one arm held at side, extend other arm downward at about 45 degrees.</p>	

Special Signals - When signals for auxiliary equipment functions or conditions not covered are required, they shall be agreed upon in advance by the operator and signalman.



31211321



An Oshkosh Corporation Company

Corporate Office
JLG Industries, Inc.
1 JLG Drive
McConnellsburg, PA 17233-9533 USA
☎ (717) 485-5161 (Corporate)
☎ (877) 554-5438 (Customer Support)
☎ (717) 485-6417

Visit our website for JLG Worldwide Locations.
www.jlg.com