



# Service Manual



## X4 Series Engine Driven Model 4355X4

p/n 4355X-000000 4355X-00P000

p/n 4355X-000020 4355X-00P020

# Table of Contents

Specifications .....	1
Final Assembly .....	3
Gun & Wand Assembly .....	4
Trigger Gun .....	5
General Assembly .....	6
(4355X-000000).....	6
(4355X-000020).....	7
Assembly, Control Panel .....	8
Electrial Schematic - ES-01680A.....	9
Assembly, Control Panel - Temp Control .....	10
Electrial Schematic - ES-01680B.....	11
Float Tank Assembly.....	12
Float Valve.....	13
Float Tank Assembly - before 2015.....	14
Float Valve.....	15
Water Pump.....	16
Pump Maintenance.....	17
Valve Service, Removal, Installation.....	18
Packing Service .....	19
Plunger Service.....	20
Head Installation - Torgue Sequence.....	21
Pump.....	22
Specifications .....	22
Exploded View .....	23
Unloader Assembly .....	25
Specifications .....	26
Parts List .....	27
Maintenance - Exploded View .....	28
Trouble Shooting .....	29
Pre-Cleaner Assembly .....	30
(4355X-000000).....	30
(4355X-000020).....	31
Oil Burner .....	32
Fuel Filter .....	33
Specifications, Trouble Shooting.....	33
Maintenance Schedule.....	34
Burner Maintenance .....	35
Fuel Filter, Adjustment Air Band , Fuel Pressure .....	35
Burner Breakdown .....	38
Burner Parts List .....	39
Troubleshooting .....	40
Pump.....	40
Burner.....	42
Water Heater.....	44
Water Heater.....	45
Warranty .....	46
Evaporative Emission Control Warranty Statement.....	47

# Specifications

## PERFORMANCE

<b>Discharge Volume</b>	3.7 gal/m / 14.0 L/m
<b>Pump Head Pressure</b>	3500 psi / 242 bar
<b>Combustion Smoke/Bacharach Scale</b>	#1 OR #2 SMOKE
<b>Carbon Monoxide Allowed</b>	0.01%
<b>Draft/Stack Installation</b>	0.2" – 0.04" WC READING
<b>Heat Input</b>	235,200 Btu/h / 59,270 kcal/h
<b>Combustion Smoke/Bacharach Scale</b>	#1 OR #2 SMOKE

## GENERAL

<b>Minimum Inlet Water Pressure</b>	<i>over 65 psi may require water inlet regulator</i> 10 psi / 0.68 bar
<b>Weight</b>	690 lbs / 313 Kg
<b>Engine Fuel Tank Capacity</b>	8gal / 30.3 Ltr
<b>Dimensions</b>	43 ½" Long x 41 High x 41" Wide
<b>Pump</b>	Triplex, Oil Bath Crankcase, Solid Ceramic Plungers
<b>Spray Tip</b>	(#4.0 - 40°) p/n JA0-40040-2
<b>Steam Impact Nozzle (optional)</b>	#42 Orifice p/n J05-00342
<b>Belt</b>	p/n R02-00241
<b>Coil</b>	
Standard	14" OD x 1/2" ID x 126' Schedule 80
Coil Back Pressure (New)	5 psi / 0.34 bar
Coil Back Pressure Requiring Descaling	50 psi / 3.40 bar
<b>Discharge Hose Assembly</b>	3/8" x 50', Quick Coupled 4000Psi

## Trigger Gun & Wand

- Trigger Gun	p/n J06-00158-B p/n J06-00158
- Trigger Wand	¼ x 42", Quick Couplers, Vented Handles p/n J06-00104EZ

## Pump Engine

p/n	F05-00488
Make	Honda GX390
Horsepower	13 hp / 9.7 kw
Fuel	Gasoline
Engine Starting	Electric
Engine Air Filter	p/n F05-000462-10
Engine Air Pre-Cleaner	None
Engine Oil Filter	None
Fuel Tank Capacity	6.4 Qt / 6.5 L
Oil Capacity	1.16 Qtl / 6.5 L
Engine Oil Alert	Yes


## BURNER

Burner Part Number	V00-173140
Burner Type	Pressure Atomizing
Voltage	12VDC
Horsepower	1/8 HP
Fuel Type	Kerosene, #1 or #2 Diesel
Fuel Pressure	125 PSI / 9 BAR

<b>Burner Nozzle</b>	2.25 Gallon per Hour 80 Degree B p/n V2.25 80DB
----------------------	--

<b>Fuel Consumption</b>	2.52 Gal/Hr / 9.5 L/Hr
-------------------------	------------------------


# Final Assembly



**ASSEMBLY, FINAL**  
**p/n: 4355X-000000**  
**11/18/2008**


ITEM NO.	PART NUMBER	PART DESCRIPTION	QTY.
1	2122-00210	ASSEMBLY, COIL TOP	1
2	3305X-00150	WELDMENT,PULLEY-SHIELD	1
3	3401-00710	ASS'Y, HOSE - 3/8 X 50 2 WIRE 5000PSI	1
4	4355X-00603	ASSEMBLY CLEANER	1
5	AB18-00807PB	HANGER, GUN	1
6	D02-00001E	DECAL, SERIAL NO	1
7	F04-00451	GROMMET, RUBBER	4
8	F05-00210-2	STRAP,BATTERY-BOX	1
9	H04-19011	SCREW, SELF TAP	5
10	H06-25003	NUT, HEX	3
11	H09-12500	RIVET, POP	2
12	J00-15040-2	TIP, SPRAY - #1504	1
13	J06-00158-B	ASSEMBLY, GUN & WAND - 42"	1
14	Y02-00061	GAUGE, GAS - CAP	1
15	Z01-00014	CAP, VINYL	2

# Gun & Wand Assembly




**ASSEMBLY, GUN & WAND - 42"**  
 p/n: J06-00158-B  
 6/2/2009

ITEM NO.	PART NUMBER	PART DESCRIPTION	QTY.
1	J06-00104E	ASSEMBLY, WAND - 42"	1
2	J06-00158	GUN, TRIGGER	1
3	W04-24225-A	COUPLER, 1/4F X 1/4FNPT	1



2102-00710 PART LIST		
ITEM	PART NUMBER	PART DESCRIPTION
1	W04-31231-B	Coupler, 3/8M X 3/8FNPT
2	K02-03150E5	Assembly, Hose - 3/8 X 50'



4120-00902P PART LIST		
ITEM	PART NUMBER	PART DESCRIPTION
1	C04-00131	Screen, Chemical
2	Z01-08413-2	Hose, Poly Braid - 84"

# Trigger Gun

## BREAKDOWN, GUN - TRIGGER

EXPLODED VIEW - P/N J06-00158

### SPECIFICATIONS

MAXIMUM VOLUME.....10.0 GPM / 37.9 LPM  
 MAXIMUM PRESSURE.....5000 PSI / 344.7 BAR  
 RATED TEMPERATURE.....300 F / 150 C  
 WEIGHT.....1.8 LBS. / 0.8 KG  
 INLET.....3/8" NPT FEMALE  
 OUTLET.....1/4" NPT FEMALE

YG3500


### REPAIR INSTRUCTIONS

1. Remove screws from handles and remove handle housings.
2. With 18mm socket remove retainer being careful to catch the spring and ball as they fall out of the housing.
3. Remove and replace parts with those found in the kit.
4. Assembly in reverse order.


**WARNING:**  
 DO NOT USE ACID CONCENTRATES THROUGH THE GUN

**WARNING:**  
 Never secure trigger gun in an open position (trigger pulled back) by means other than the operator's hand. Bodily harm may occur if the operator loses control of the trigger gun.

**CAUTION:**  
 Always engage trigger safety latch when not in use.




KIT, REPAIR PART - NUMBER J06-99158C



### PART LISTS

ITEM	PART NUMBER	PART DESCRIPTION	QTY.
1	C07-01300-08	O-RING - 1/16CS X 5/16ID	1
2	C07-01425	FILTER, WATER	1
3	J06-00121-07	O-RING - 3/32 CS X 1/8 ID	1
4	J06-00121-15	BALL, SS 5/16	1
5	J06-00132-19	SCREW, SELF TAP - 3.5MM X 18MM	7
6	J06-00158-01	FITTING, DISCHARGE - 1/4 FNPT	1
7	J06-00158-02	PIN, TRIGGER - 5MM X 27.5MM	1
8	J06-00158-03	CAM	1
9	J06-00158-04	TRIGGER	1
10	J06-00158-05	LATCH, SAFETY	1
11	J06-00158-06	FITTING, INLET - 3/8 FNPT	1
12	J06-00158-08A	SEAT, VALVE	1
13	J06-00158-09	WASHER, FLAT	1
14	J06-00158-10	WASHER, FLAT - BRASS	1
15	J06-00158-11	HOUSING, VALVE	1
16	J06-00158-12A	RETAINER, VALVE	1
17	J06-00158-13	SPRING, COMPRESSION	1
18	J06-00158-14	PIN, VALVE - 4MM X 44MM	1
19	J06-99158A	HOUSING, HANDLE	1

# General Assembly (4355X-000000)




## ASSEMBLY CLEANER 4355X-00603 11/18/2008

ITEM NO.	PART NUMBER	PART DESCRIPTION	QTY.
1	4305X-01121	ASSEMBLY, TANK - FLOAT	1
2	4355X-00304	ASSEMBLY, JUNCTION BOX	1
3	4355X-00501	ASSEMBLY, PUMP	1
4	4355X-00515	ASSEMBLY, UNLOADER	1
5	4355X-00657	PRE CLEANER ASSEMBLY	1
6	AS14-00616-NPB	BRACKET, BRAKE	1
7	D430M-10176R	HANDLE, BRAKE	1
8	E10-00021-58	TEE, STREE - 3/8"	1
9	H03-31311	BOLT, J-5/16-18UNC x 3 1/2"	1
10	H04-19011	SCREW, SELF TAP	3
11	H04-25002	SCREW, CAP	8
12	H04-25035	SCREW, SET - 1/4-20UNC x 1"	2
13	H04-31313	SCREW, CAP - 5/16-18UNC X 1"	5
14	H06-25003	NUT, HEX	14
15	H06-25006	NUT, TINNEMAN - 5/16"	2
16	H06-31300	NUT, LOCK - 5/16"	7
17	H06-31309	NUT, LOCK	1
18	H06-37500	NUT, LOCK-3/8-16UNC HEX	4
19	I3305-00193A	WELDMENT, BATTERY BOX	1
20	I4355-00125	TANK, FUEL - PLASTIC, 8 GAL	1
21	K02-03216A2	ASSEMBLY, HOSE	1
22	K02-03222A2	ASSEMBLY, HOSE - 3/8 x 22**	1
23	K23	HOSE, FUEL - 1/4 X 2.5'	2
24	K33-01300	HOSE, WATER - 3/8 X 13"	1
25	K60-02800	HOSE, WATER - 5/8 X 29"	1
26	R03-00741	PULLEY, DBL V-2BK41H	1
27	R04-00006	BUSHING, PULLEY	1
28	W02-00031	CLAMP, HOSE	2
29	W02-00032	CLAMP, HOSE	2
30	W02-00033	CLAMP, HOSE	6
31	W02-10031	BARB, HOSE	2
32	W04-34155-A	COUPLER, 3/8F X 1/2MNPT	1
33	Y01-00123	ACCUMULATOR	1
34	Y02-00061	GAUGE, GAS - CAP	1
35	Z01-01113-2	HOSE, POLYBRAID - 1/4 x 11'	1




# (4355X-000020)



## ASSEMBLY CLEANER 4355X-07603A 11/18/2008

ITEM NO.	PART NUMBER	PART DESCRIPTION	QTY.
1	4305X-01121	ASSEMBLY, TANK - FLOAT	1
2	4355X-00304	ASSEMBLY, JUNCTION BOX	1
3	4355X-00501	ASSEMBLY, PUMP	1
4	4355X-00515	ASSEMBLY, UNLOADER	1
5	4355X-05657	PRE CLEANER ASSEMBLY	1
6	AS14-00616-NPB	BRACKET, BRAKE	1
7	D430M-10176R	HANDLE, BRAKE	1
8	E10-00021-58	TEE, STREE - 3/8	1
9	H03-31311	BOLT, J-5/16-18UNC x 3 1/2	1
10	H04-19011	SCREW, SELF TAP	3
11	H04-25002	SCREW, CAP	8
12	H04-25035	SCREW, SET - 1/4-20UNC x 1	2
13	H04-31313	SCREW, CAP - 5/16-18UNC X 1	5
14	H06-25003	NUT, HEX	14
15	H06-25006	NUT, TINNEMAN - 5/16	2
16	H06-31300	NUT, LOCK - 5/16"	7
17	H06-31309	NUT, LOCK	1
18	H06-37500	NUT, LOCK-3/8-16UNC HEX	4
19	I3305-00193A	WELDMENT, BATTERY BOX	1
20	I4355-00125	TANK, FUEL - PLASTIC, 8 GAL	1
21	K02-03216A2	ASSEMBLY, HOSE	1
22	K02-03222A2	ASSEMBLY, HOSE - 3/8 x 22"	1
23	K23	HOSE, FUEL - 1/4 X 2.5'	2
24	K33-01300	HOSE, WATER - 3/8 X 13'	1
25	K60-02800	HOSE, WATER - 5/8 X 29'	1
26	R03-00741	PULLEY, DBL V-2BK41H	1
27	R04-00006	BUSHING, PULLEY	1
28	W02-00031	CLAMP, HOSE	2
29	W02-00032	CLAMP, HOSE	2
30	W02-00033	CLAMP, HOSE	6
31	W02-10031	BARB, HOSE	2
32	W04-34155-A	COUPLER, 3/8F X 1/2MNPT	1
33	Y01-00123	ACCUMULATOR	1
34	Y02-00061	GAUGE, GAS - CAP	1
35	Z01-01113-2	HOSE, POLYBRAID - 1/4 x 11	1

# Assembly, Control Panel




**ASSEMBLY, JUNCTION BOX**  
 p/n: 4355X-00304C  
 12/16/2009

ITEM NO.	PART NUMBER	PART DESCRIPTION	QTY.
1	AS16-01068PB	COVER-J-BOX	1
2	F04-00310	CONNECTOR, CONDUIT	3
3	F04-00615	TERM, SPLICE	2
4	F04-00616	TERM, INSULATOR	2
5	F04-00616-1	TERM, SPLICE 18-6 WIRE	2
6	F04-00616-2	INSULATOR, SPLICE - 18-6	2
7	F04-00618	INSULATED SPADE	7
8	F04-00693	SWITCH, ROCKER - 12V	1
9	F04-05053	CORD, ELEC - 16/5500W X 50'	1
10	F05-00168A	MODULE, RECTIFIER	1
11	FA5-00063	RELAY, AUTOMOTIVE	1
12	H04-13805	SCREW, MACHINE	2
13	H04-25000	SCREW, CAP	1
14	H06-25003	NUT, HEX	1
15	I4405-00310	WELDMENT, J-BOX	1

# Electrical Schematic - ES-01680A

- NOTES:**
- 1.) 20 AMP FUSE ON WAYNE BURNER ONLY.
  - 2.) RED WIRE (SHOWN HERE OPPOSITE CAD CELL), IS NOT IN ANY WAYNE BURNER BUT, IN SOME BECKETT BURNERS, THE YELLOW WIRE (SHOWN HERE OPPOSITE CAD CELL) IS BLUE IN BECKETT BURNERS, AND THE OTHER RED WIRE (FROM IGNITER/TIMER IS WHITE IN BECKETT BURNERS.

**\*\* NOTE:**  
THE RELAY SPADE TERMINAL NUMBERS SHOWN IN THIS DRAWING ARE NOT VISIBLE ON THE RELAY. THEREFORE, TO MAKE CORRECT WIRE CONNECTIONS, POSITION RELAY SO SPADES CAN BE SEEN EXACTLY AS SHOWN HERE (3 VERTICAL, 2 HORIZONTAL), THEN MAKE WIRE CONNECTIONS AS SHOWN.




**ELECTRICAL SCHEMATIC**  
PART NUMBER  
**ES-01680A**



DATE: 07-25-08  
DRAWN BY: LCL

WHITE	YELLOW
BLACK	GREEN
RED	PINK
BROWN	ORANGE
BLUE	BLUE


# Assembly, Control Panel - Temp Control



**ASSEMBLY, WIRING**  
 p/n: 4355X-00304A  
 7/30/2012

ITEM NO.	PART NUMBER	PART DESCRIPTION	QTY.
1	4355E-00310	WELDMENT, JUNCTION BOX	1
2	AS16-01055-PB	COVER, JUNCTION BOX	1
3	F04-00310	CONNECTOR, CONDUIT	1
4	F04-00411	BUSHING, STRAIN RELIEF	2
5	F04-00604	TERMINAL, FORK	1
6	F04-00610	TERM, FORK	4
7	F04-00615	TERM, SPLICE	4
8	F04-00616	TERM, INSULATOR	4
9	F04-00618	INSULATED SPADE	8
10	F04-00693	SWITCH, ROCKER - 12V	1
11	F04-00830	THERMOSTAT, ADJUSTABLE	1
12	F04-02433	CORD, ELEC - 14/4SO X 24"	1
13	FA5-00063	RELAY, AUTOMOTIVE	1

# Electrical Schematic - ES-01680B




**TITLE / DESCRIPTION**  
**ELECTRICAL SCHEMATIC**

**PART NUMBER**  
**ES-01680B**



**DATE:** 07-25-08  
**DRAWN BY:** LCL


# Float Tank Assembly



**ASSEMBLY, FLOAT-TANK**  
 p/n: 4305X-01121  
 3/8/2017

ITEM NO.	PART NUMBER	PART DESCRIPTION	QTY.
1	2120-04120B	TANK, FLOAT	1
2	4120-10540	ASSEMBLY, RESTRICTOR	1
3	C03-00631	FLOAT VALVE	1
4	C04-00120	FILTER, SOAP SCREEN	1
5	C05-00264	ADAPTER, SWIVEL	1
6	C05-00270-1	NUT, GARDEN HOSE	1
7	C05-00271	WASHER, GARDEN HOSE	1
8	E06-00028	COUPLING, FULL-HP	1
9	E09-00002-P	PLUG, PIPE - NYLON	1
10	W02-10057-8	BARB, HOSE	1

# Float Valve



**VALVE, FLOAT - P/N C03-00631**  
8/8/2008


## PARTS LIST

ITEM NO.	PART NUMBER	PART DESCRIPTION	QTY.
1	C03-00625-10	SCREW, WING - 10-32UNF	1
2	C03-00628	FLOAT, PLASTIC	1
3	C03-00631-01	NUT, HEX - 3/8FNPT	1
4	C03-00631-02	WASHER, FLAT - RUBBER	1
5	C03-00631-03	NIPPLE, BRASS - 3/8NPT	1
6	C03-00631-04	SEAT, VALVE-NYLON	1
7	C03-00631-05	HOUSING, VALVE	1
8	C03-00631-06	PISTON	1
9	C03-00631-07	ROD, PISTON-5/16CS X 1 1/4 PLASTIC	1
10	C03-00631-08	GUIDE, PISTON	1
11	C03-00631-10	SCREW, CAP	1
12	C03-00631-11	ARM, FLOAT	1
13	C03-00631-14	NUT, HEX - BRASS	1
14	C03-00631-16	LEVER - BRASS	1
15	C03-00631-17	KEY, COTTER	1
16	C03-00631-18	NIPPLE, TOE	1
17	C03-0631-09	NUT, RETAINER	1
18	H05-18700	WASHER, FLAT	1

## SPECIFICATIONS

MAXIMUM VOLUME.....7 GPM / 26 LPM  
 MAXIMUM PRESSURE.....140 PSI / 10 BAR  
 MAXIMUM TEMPERATURE .....140° F/60° C  
 PORT SIZE - INLET.....3/8" NPT  
 DIMENSIONS...11.4 X 4.1 X 2.8 IN / 290 X 104 X 71MM  
 WEIGHT.....0.6 LB / 0.3 KG  
 HOUSING MATERIAL .....BRASS  
 O-RING MATERIAL.....BUNA-N

# Float Tank Assembly - before 2015




**ASSEMBLY, TANK - FLOAT**  
**P/N 4305X-01121**  
**8/21/2008**

ITEM NO.	PART NUMBER	PART DESCRIPTION	QTY.
1	4120-01120	TANK, FLOAT	1
2	4120-10540	ASSEMBLY, RESTRICTOR	1
3	AR14-00300	ROD, THREAD 1/4-20UNC X 3	1
4	C03-00620-Q	VALVE, FLOAT	1
5	C03-00622-B	BALL, FLOAT-PLASTIC	1
6	C04-00120	FILTER, SOAP SCREEN	1
7	C05-00270-1	NUT, GARDEN HOSE	1
8	C05-00271	WASHER, GARDEN HOSE	1
9	C05-00272	ADAPTER, GARDEN HOSE	1
10	E06-00008-2	COUPLING, FULL	1
11	E09-00002-P	PLUG, PIPE - NYLON	1
12	W02-10057-8	BARB, HOSE	1



# Float Valve


Only Replaceable Part  
Is The plunger With Seals  
Float Ball and Stem Found  
In The Assembly Where  
Float Valve Used.



**VALVE, FLOAT**  
p/n C03-00620-Q

ITEM NO.	PART NUMBER	PART DESCRIPTION	QTY.
1	-----	HOUING-VALVE	1
2	-----	ARM,PLUNGER	1
3	-----	NUT,WING	1
4	-----	ARM,BALL	1
5	C03-99620-Q	PLUNGER	1
6	-----	LINK,PLUNGER	1
7	-----	ARM,PLUNGER	1
8	-----	WASHER, FIBER	1
9	-----	NUT, HEX	1

# Water Pump



**ASSEMBLY, PUMP**  
**4355X-00501**  
**10/30/2008**

ITEM NO.	Part Number	PART DESCRIPTION	QTY.
1	4355EB-00513	MOUNT, PUMP	1
2	C03-00307	VALVE, METERING	1
3	C03-00810	VALVE, AIR	1
4	E04-00001-58	BUSHING, PIPE	1
5	E04-00005-48	BUSHING, PIPE	1
6	E04-00016-58	BUSHING, 3/8 - 1/4	1
7	E07-00001-4	CROSS, PIPE	1
8	E08-00011-48	3/8"MNPT X 3/8"FNPT X 90D	1
9	E08-00016-4T	ELBOW, 1/2" FNPT	1
10	E10-00021-58	TEE, STREE - 3/8	1
11	E13-00010-2	NIPPLE, PIPE - 1/4"	1
12	E15-00010-48	NIPPLE, CLOSE - 1/2"NPT	1
13	E15-00010-58	NIPPLE, HEX	1
14	F04-00790	SWITCH, PRESSURE	1
15	H05-31304	WASHER	4
16	K21-02214-3/8	KIT, OIL DRAIN - 3/8"	1
17	N07-20048	SCREW, CAP	4
18	N09-00053	PUMP, WATER - RK1528HN	1
19	R03-00794	PULLEY, DBL	1
20	R04-00001	BUSHING, PULLEY	1
21	W02-10030-8	BARB, HOSE	1
22	W02-10031	BARB, HOSE	2
23	W02-10057-8	BARB, HOSE	1

# Pump Maintenance

1. Drain all of the water out of the pump.
2. Run a 50% solution of a RV or non-toxic/biodegradable antifreeze through the pump.
3. Flush the pump with fresh water before the next use.
4. In freezing conditions failure to do this may cause internal pump damage.
5. For long periods of storage in non-freezing areas the solution will keep the seals and O-rings lubricated.

## Service Pumps

### Servicing the Valves

The inlet and discharge valves in this series pumps are all the same. The valves are located under the six 24mm hex plugs. The inlet valves are located on the lower row and the discharge valves are located on the top row of the pump head.

Tools required: 24mm socket, ratchet, needle nose pliers, mechanics pick and torque wrench.

### Valve Removal:

1. Remove the valve cap.
2. Inspect the valve cap O-ring for any damage, replace if necessary. (See Figure 10)
3. Use the needle nose pliers to remove the valve. (See Figure 11)



Figure 10



Figure 11

# Valve Service, Removal, Installation

## Service Pumps (continued)

4. Use a small probe to move the poppet up and down to assure that the valve is functioning properly and that no debris is stuck in the valve. (See Figure 12)



Figure 12

5. Using the mechanics pick remove the valve seat O-ring and inspect for any damage, replace if necessary. (See Figure 13)



Figure 13

## Valve Assembly:

1. Install the valve seat O-ring squarely into the bottom of the manifold. (See Figure 14)
2. Insert the valve assembly squarely into the port pushing it into the O-ring. (See Figure 15)
3. Install the valve cap and torque to the proper specification. (See Figure 16) (See parts breakdown)



Figure 14



Figure 15



Figure 16

## Servicing the Packings/Seals

To access the water seals for inspection or replacement, you will first need to remove the head of

Tools required: 6mm hex socket, ratchet, (2) long screwdrivers, reversible pliers, mechanics pick and torque wrench.

## Disassembly:

1. First remove the eight 6mm head bolts. (See Figure 17)
2. Place the screwdrivers as shown between the head and crankcase of the pump, lifting one up and the other down. The head should start to lift off of the plungers. (See Figure 18)



Figure 17

3. When you remove the head you may notice that some of the water seals have stayed on the plungers and some in the head. (See Figure 19) To remove the seals from the plungers simply turn the assemblies and pull off.



Figure 18

4. If the seal assemblies are in the head use the reversible pliers to grab the seal retainer on the inside bore

(NOTE: Use a rag so you do not mar the piston guide area), twist the retainer in either direction



Figure 19



Figure 20

# Packing Service

## Service Pumps (continued)

(NOTE: This is done to free the retainer O-ring which is stuck to the manifold) and lift out. (See Figure 20 & 21)



Figure 21

5. With your fingers pull the high pressure seal and head ring out of the head. (See Figure 22)



Figure 22

6. The low-pressure seal is located in the brass seal retainer. Using the mechanics pick go in between the seal and retainer, twist and pull, the seal will come out of the gland. (See Figure 23 & 24)



Figure 23

7. Remove the seal retainer O-ring with the mechanics pick. (See Figure 25)



Figure 24

## Assembly:

1. Install the plastic head ring into the head (*the flat side is on the bottom*). (See Figure 26)



Figure 25

2. Install the high-pressure seal. Place the seal so the open "V" portion is toward the head ring. You need to place the



Figure 26

seal at an angle and pull and push to work the seal into position with your fingers (*do not use and tools you may damage the seal*). Make sure the seal is totally seated against the head ring. (See Figure 27 & 28)



Figure 27

3. Installing the low-pressure seal. You want the open side of the seal to be pointed toward the water side of the head (toward the high-pressure seal) and the flat side toward the drive end of the pump.



Figure 28

Place the seal into the gland at an angle, with your finger push the exposed side of the seal towards the center and work the seal (See Figure 29, 30 & 31) into position. After the seal is in the gland you can work it into its proper position.



Figure 29

4. Install the retainer O-ring. (See Figure 32)



Figure 30



Figure 31



Figure 32

# Plunger Service

## Service Pumps (continued)

5. Squarely seat the retainer into the head and push with even pressure until it snaps into position. (See Figure 33)



Figure 33

## Servicing the Plungers

If the plungers are not damaged they do not need any servicing.

Tools required: 16mm socket, ratchet, mechanics pick, taper blade gasket scraper, thread sealant and torque wrench.

**NOTE:** Be very careful when working with the plungers, they are made from ceramic which is brittle and can be damaged.

Any time you remove a plunger it is recommended you replace the slinger washer, O-ring and top plunger washer. The washers are a cushion for the ceramic plunger and compress when first used and the O-ring will take a set to create a seal and usually will not spring back to its original shape. By not replacing these parts you run the risk of breaking a plunger or having a water leak.

### Disassembly:

1. Remove the plunger retainer nut. (See Figure 34)
2. Insert the gasket scraper between the copper washer and plunger to remove the washer. (See Figure 35)



Figure 34



Figure 35

3. Twist and pull the plunger off the plunger rod.
4. Remove the plunger rod O-ring seal and split back-up ring with the mechanics pick. (See Figure 36 & 37)
5. Remove brass slinger. At this point clean any thread locker that is left on the plunger rod and retaining nut threads. (See Figure 38)



Figure 36



Figure 37



Figure 38



Figure 39



Figure 40

- ### Assembly:
1. Install the slinger washer. (See Figure 39)
  2. Install the plunger rod O-ring and split back-up ring. Place a light film of oil on the O-ring and back-up ring. (See Figure 40)
  3. Install the plunger by pushing straight down and twisting slightly in either direction (See Figure 41)

**(NOTE:** Be sure that the back-up ring is fully seated). Make sure you fully seat the plunger.



Figure 41

# Head Installation - Torque Sequence

## Service Pumps (continued)

4. Install the small copper washer on top of the plunger and place a small quantity of thread sealant in the thread. Install the plunger nut and tighten to the required torque. (See Figure 42 & 43) (See parts breakdown)



Figure 42



Figure 43

## Pump head to drive end Installation

1. Turn the crankshaft to align the plungers as shown. (See Figure 44)
2. Place the head evenly onto the plungers and push it until it makes contact with the drive end of the pump. (See Figure 45)
3. Torque the head bolt as shown in the tightening sequence diagram. (See Figure 46 & 47) (See parts breakdown).



Figure 44



Figure 45



Figure 46




Figure 47

## Oil Change

Change oil after first 50 hours of use. Then every 500 hours. Refer to parts breakdown for oil type.

# Pump Specifications



ALL DIMENSIONS ARE IN INCHES UNLESS OTHERWISE NOTED. 25.4 MM = 1 INCH

## PERFORMANCE

DISCHARGE VOLUME.....4.0 GPM / 15.1 LPM  
 PUMP HEAD PRESSURE.....4000 PSI / 275.0 BAR

## GENERAL

CRANKSHAFT ROTATION.....CLOCKWISE AND COUNTER CLOCKWISE  
 MAXIMUM SPEED.....1450 RPM  
 MAXIMUM PUMPED FLUID TEMPERATURE.....165°F / 74°C  
 INLET PRESSURE.....-9 IN HG @ 75°F TO 116 PSI / -0.3 BAR @ 24°C TO 8 BAR  
 WEIGHT (WET).....20.0 LBS / 8.8 KG

## LUBRICATION

OIL CHANGE INTERVAL .....AFTER FIRST 50 HOURS THEN AFTER 500 HOURS  
 OIL TYPE.....SAE 30 (NON-DERTERGENT)  
 CRANKCASE CAPACITY.....15.0 FL OZ / 0.44 LT

## TORQUE

VALVE PLUG.....40 FT LBS / 5.5 KG M REAR COVER TO CRANKCASE.....18 FT LBS / 2.4 KG M  
 MOUNT TO CRANKCASE.....32 FT LBS / 4.4 KG M RETAINER TO CRANKCASE.....18 FT LBS / 2.4 KG M  
 \* PLUNGER NUT TO CROSSHEAD.....8.8 FT LBS / 1.2 KG M HEAD TO CRANKCASE.....18.0 FT LBS / 2.5 KG M


**\*NOTE:** When plunger nut is removed, install a new copper washer and flinger washer to ensure proper fit and seal of ceramic plunger. If same copper washers are reused cracking or a poor seal may result.

## REPAIR PARTS PACKAGES

PART NO.	DESCRIPTION	ITEM	QTY	PART NO.	DESCRIPTION	ITEM	QTY	PART NO.	DESCRIPTION	ITEM	QTY
N09-992864	VALVE ASSEMBLIES			N09-991857	V-PACKING, SEAL, & O-RING			N09-992757	PLUNGERS - 18MM		
	ASSY, CHECK VALVE	36	6		SEAL, WATER	21	3		PLUNGERS	41	3
	O-RING	35	6		O-RING	22	3				
N09-991855	OIL SEALS & O-RINGS				PACKING, V - 18MM	24	3	N09-991829	ADAPTER, MALE - 18MM		
	O-RING, RETAINER	4	2						ADAPTER, MALE	25	3
	O-RING, COVER	11	1								
	SEAL, OIL	45	3								
	SEAL, OIL - CRANKSHAFT	17	1								



# Exploded View



## PARTS LIST

ITEM	PART NO.	DESCRIPTION	ITEM	PART NO.	DESCRIPTION
1	N09-850370	SCREW, CAP	24	N09-880320	V-PACKING - 18MM
2	N09-1380050	RETAINER, BEARING - CLOSED	25	N09-960110	ADAPTER, MALE - 18MM
3	N09-1380120	SHIM - 0.1 MM	26	N09-1981180	PLUG - 3/8" NICKEL PLATED
4	N09-640030	O-RING	27	N09-960870	PLUG - 1/2" NICKEL PLATED
5	N09-2280240	BEARING	28	N09-180101	O-RING
6	N09-1382770	CRANKCASE	29	N09-1381070	HEAD, PUMP - NICKEL PLATED
7	N09-0880130	DIPSTICK, OIL	30	N09-1381850	WASHER, FLAT
8	N09-1380920	CROSSHEAD	31	N09-820150	SCREW, CAP
9	N09-1380060	PIN, CROSSHEAD	32	N09-1380690	PLUG - 1/4" NICKEL PLATED
10	N09-1383050	ROD, CONNECTING	33	N07-20028	O-RING
11	N09-1780510	O-RING	34	N09-992864	KIT, VALVE ASSEMBLY
12	N09-1789010	COVER, PUMP HOUSING - REAR	35	P04-00212	O-RING
13	N09-1343510	SCREW, CAP	36	-----	ASSEMBLY, VALVE
14	C03-00503-01	O-RING	37	N09-0960160	O-RING
15	N09-880530	PLUG - 3/8"	38	N09-960850	PLUG - S.S.
16	N09-1380040	RETAINER, BEARING - OPEN	39	N09-962010	NUT, HEX
17	N09-880520	SEAL, OIL	40	N09-962000	WASHER, FLAT - COPPER
18	N09-840370	BEARING	41	N09-1380940	PLUNGER - 18MM
19	N09-1380520	KEY	42	N09-1380950	WASHER, FLINGER - COPPER
20	N09-2280060	CRANKSHAFT	43	N09-600180	O-RING
21	N09-880330	SEAL, WATER - 18MM	44	N09-1080401	RING, ANTI-EXTRUSION
22	N07-20016	O-RING	45	N09-880520	SEAL, OIL
23	N09-1380090	ADAPTER, FEMALE - 18MM			

# Pump Maintenance Record

## Oil Change

Month/Day/Year

Operating Hours

Oil Brand & Type



## Pump Service

Month/Day/Year

Operating Hours

Type of Service


# Unloader Assembly



**ASSEMBLY, UNLOADER**  
**4355X-00515**  
**2/12/2014**

## Relief Valve

**WARNING:** The relief valve has been factory set and is a field nonadjustable part. Please contact the factory before setting the valve and will void the manufacturer warranty.

If pressure from should exceed safe limits it will automatically open to relieve dangerous system pressure overloads which can harm equipment and can also be dangerous for the operator.

**Caution:** *Inspect relief valve annually for any obstruction.*


ITEM NO.	Part Number	PART DESCRIPTION	QTY.
1	3305X-00514	BRACKET, UNLOADER	1
2	C03-00509-45	VALVE, RELIEF - SS	1
3	C07-04504-MA	VALVE UNLOADER	1
4	C09-00008	VALVE, EASY START	1
5	E08-00011-58	ELBOW, PIPE	1
6	E09-00003-2	PLUG, PIPE	1
7	E10-00003-5	TEE, PIPE	2
8	W02-10040-8	BARB, HOSE	1

# Specifications

p/n C07-04504M-A

## Specifications

Maximum Flow	10.5 gal/m / 40L/m
Unloading Press	
Rated	4050 psi / 280 bar
Max	4500 psi / 310 bar
Maximum Temperature	195°F / 88°C
Weight	1.54 lbs / 700 G
Bypass	3/8 FNPT
Inlet	3/8 FNPT
Discharge	3/8 MNPT



# Parts List

## p/n C07-04504M-A

Item	Part Number	Description	Qty	Kit
1	C07-04504-11	Guide, Piston	1	
2	C07-04504-01	O-Ring	2	*
3	C07-04504-09	Piston – SS	1	
4	C07-04504-02	Ring, Back-Up	1	*
5	N07-20028	O-Ring	1	*
6	-----	Housing	1	
7	C07-04500A-05	Kit Seat & O-Ring	1	*
7A	C07-02300-08	O-Ring 1/16CS x 11/16OD	1	
9	C07-04500-03	Ball, SS-13/32	1	
10	C07-04504-03	Spring, 1.6x11x20MM	1	
11	C07-04504-04	Coupling, Inlet 3/8 NPT	1	
12	N16-28110084	Washer, Flat	2	
13	C07-04504-05	Plug-3/8NPT	2	
14	C07-04504-07	Ring, back-up	1	*
15	P04-00215	O-Ring, 1.78 x 6.07mm	1	*
16	C07-04504-08	O-Ring, 3 x 6mm	2	*
17	C07-04504-12	Valve, Check	1	
18	C07-01009A-18	Spring, Compression	1	
19	C07-04504-16	O-Ring, 1/16cs x 5/8	1	*
20	C07-04504M-10	Fitting, Outlet – 3/8" M	1	
21	C07-04504-14	Nut, Hex	2	
22	C07-04504-13	Follower, Spring	1	
23	C07-04504-15	Nut, Hex - Brass	1	
24	C07-04500-13	Spring, Comp. Blue	1	
	<b>C07-9904504</b>	<b>Kit, Repair - Parts Package</b>		*

ATTENTION: the nut in position 21 is a mechanical security device that limits the maximum pressure; it must absolutely NOT be removed.

MAINTENANCE STANDARD: every 400 working hours, check and lubricate the seals with water resistant grease.

**NOTE: CONVERTING**


C07-04504-A to C07-04504M-A

Replace outlet fitting item #24 p/n C07-04500-17 with item #20 C07-04505M-10

NOTE: Outlet connection fittings will have to be changed.

# Maintenance - Exploded View

p/n C07-04504M-A



## UNLOADER PRESET AT FACTORY – DO NOT READJUST Unloading Adjustment – Adjustment only after repair or replacement

1. Install an appropriate pressure gauge in pump head outlet. The gauge should have a range twice the operating pressure.
2. Install the spray nozzle in the end of the wand.
3. Ensure the relief valve is set properly.
4. Loosen top lock nut (upper Item 21) and turn the nut (lower Item 21) counter clockwise until minimum spring tension.
5. With machine turned on, open the trigger gun, start the pump, and observe pressure gauge reading. Slowly loosen the nut (lower Item 21) until pressure starts to drop on the gauge.
6. Tighten adjusting nut (lower Item 21) on the unloader. Pressure should start to increase. Tighten adjusting nut (lower Item 21) until pressure stops climbing.
7. Close and open the trigger gun to check unloading pressure and bypass function of the unloader valve. The unloading pressure should not exceed operating pressure more than 400 PSI.
8. Lock the setting by tightening the lock nut (upper Item 21).


# Trouble Shooting

p/n C07-04504M-A

## Troubleshooting

Trouble	Possible Cause	Remedy
<b>Frequent valve recycles</b>	Damaged check valve O-ring	Remove and replace
	Leaking connections	Check or renew
	Restricted bypass or too small diameter of	Clean or adapt passage diameter
<b>Valve does not reach pressure</b>	Piston O-rings worn out	Remove and replace
	Debris between seat and shutter	Clean the seat
	Seat worn out	Remove and replace
	Nozzle worn out	Remove and replace
	Incorrect choice of nozzle	Fit with smaller nozzle
<b>High pressure peaks at gun closure</b>	There is not a minimum of 5% of total flow discharged in bypass	Reset Correctly
	Excessive flow in bypass	Change type of valve or adjust passages
	Adjustment with spring totally compressed	Loosen adjustment screw and eventually
<b>Valve does not discharge at low pressure at gun closure</b>	Jammed check valve	Jammed check valve
	Debris on check valve	Clean

# Pre-Cleaner Assembly (4355X-000000)




**PRE CLEANER ASSEMBLY**  
**4355X-00657 S/N 271645 & UP**  
**08/08/2014**

ITEM NO.	PART NUMBER	PART DESCRIPTION	QTY.
1	216AX-00164F	HANGER, GUN	1
2	3242-00206	COIL, PIPE - TALL	1
3	330X-00138	BASE - COIL MOUNT WELDMENT	1
4	330X-00179F	HANDLE, POWDER COAT	1
5	4355X-00130FL	FRAME, END - LEFT	1
6	4355X-00130FR	FRAME, END - RIGHT	1
7	4355X-00133	CHANNEL, MOTOR-MOUNT	1
8	4355X-00400	ASSEMBLY, BURNER	1
9	90-00119	INSULATION - 1 x 14DIA	1
10	AP34-01803	PIPE, 3/4" X 18 3/4"	2
11	AR34-03000	AXLE ROD	2
12	AS11-02408NPB	BASE PLATE	1
13	AS11-02513NPB	FUEL TANK MOUNT	1
14	F05-00488	13HP HONDA	1
15	G02-10016C	ASS'Y, TIRE & RIM - 13"	4
16	H04-25002	SCREW, CAP	6
17	H04-31313	SCREW, CAP - 5/16-18UNC X 1	16
18	H04-31331	SCREW, CAP	4
19	H05-31300	WASHER, FLAT - 5/16	8
20	H05-50001	WASHER, HELICAL LOCK - 1/2"	8
21	H06-25006	NUT, TINNEMAN - 5/16	16
22	H06-25007	NUT, TINNEMAN - 1/4"	6
23	H06-31300	NUT, LOCK - 5/16"	4
24	H06-37500	NUT, LOCK-3/8-16UNC HEX	3
25	H06-50001	NUT, 1/2 - 20UNF	8
26	H06-75002	COLLAR, SHAFT - 3/4"	4
27	H10-50000	MOUNT, SHOCK	4
28	Z01-00048	CAP, VINYL - ROUND	4
29	Z01-05043	INSULATION, CERAMIC FIBER	2
30	Z02-02611	PALLET ASSEMBLY	1




# (4355X-000020)



**PRE CLEANER ASSEMBLY**  
**4355X-05657 S/N 271645 & UP**  
**08/08/2014**

ITEM NO.	PART NUMBER	PART DESCRIPTION	QTY.
1	216AX-00164F	HANGER, GUN	1
2	S3242-05206	COIL, PIPE - TALL	1
3	330X-00138	BASE - COIL MOUNT WELDMNT	1
4	330X-00179F	HANDLE, POWDER COAT	1
5	4355X-00130FL	FRAME, END - LEFT	1
6	4355X-00130FR	FRAME, END - RIGHT	1
7	4355X-00133	CHANNEL, MOTOR-MOUNT	1
8	4355X-00400	ASSEMBLY, BURNER	1
9	90-00119	INSULATION - 1 x 14DIA	1
10	AP34-01803	PIPE, 3/4" X 18 3/4"	2
11	AR34-03000	AXLE ROD	2
12	AS11-02408NPB	BASE PLATE	1
13	AS11-02513NPB	FUEL TANK MOUNT	1
14	F05-00488	13HP HONDA	1
15	G02-10016C	ASS'Y, TIRE & RIM - 13"	4
16	H04-25002	SCREW, CAP	6
17	H04-31313	SCREW, CAP - 5/16-18UNC X 1	16
18	H04-31331	SCREW, CAP	4
19	H05-31300	WASHER, FLAT - 5/16	8
20	H05-50001	WASHER, HELICAL LOCK - 1/2"	8
21	H06-25006	NUT, TINNERMAN - 5/16	16
22	H06-25007	NUT, TINNERMAN - 1/4"	6
23	H06-31300	NUT, LOCK - 5/16"	4
24	H06-37500	NUT, LOCK-3/8-16UNC HEX	3
25	H06-50001	NUT, 1/2 - 20UNF	8
26	H06-75002	COLLAR, SHAFT - 3/4"	4
27	H10-50000	MOUNT, SHOCK	4
28	Z01-00048	CAP, VINYL - ROUND	4
29	Z01-05043	INSULATION, CERAMIC FIBER	2
30	Z02-02611	PALLET ASSEMBLY	1

# Oil Burner




**ASSEMBLY, BURNER**  
**p/n: 4355X-00400**  
**10/29/2008**

ITEM NO.	PART NUMBER	PART DESCRIPTION	QTY.
1	E08-00006-2	ELBOW, PIPE	1
2	E13-00010-2	NIPPLE, PIPE - 1/4"	1
3	V00-173140	BURNER, OIL	1
4	V04-00308	FILTER, FUEL	1
5	V2.25 80DB	NOZZLE, BURNER	1
6	W02-10019-8	BARB, HOSE	1
7	W02-10031	BARB, HOSE	1

# Fuel Filter

## Specifications, Trouble Shooting

p/n V04-00308



### Specifications

Maximum Flow	15 GPM / 57 LPM
Maximum Filtration	2 Microns
Maximum Temperature	212°F / 100°C
Weight	1.0lbs / 340gm
Inlet	¼ NPT
Outlet	¼ NPT

All dimensions are in inches unless otherwise noted.  
25.4 mm = 1 inch

### Maintenance Procedures

#### Priming the machine

Shut off the fuel tank valves. Spin off the clear bowl, fill with clean fuel and coat the round gasket (3) with fuel. Reinstall the clear bowl and tighten ¼ to 1/3 turns after the gasket contacts the upper housing. Turn on the fuel tank valves. Start the machine and check that there are no leaks.

#### Draining water

Check the collection bowl daily. Drain off water contaminants by unscrewing the clear bowl turning counter-clockwise. Start the machine and allow air to purge from the fuel system prior to operating the equipment.

#### Element replacement frequency

Frequency of element replacement is determined by contamination level in the fuel. Replace the element every 500 hours.

Note: Foul smelling diesel fuel is an indication of microbiological contamination. A change in fuel source is recommended. Always carry a spare filter element as one tank full of contaminated fuel will plug the fuel filter element prematurely.

#### Element replacement procedure

1. Shut off the fuel tank valves.
2. Unscrew the clear bowl turning counter-clockwise.
3. Remove and discard the filter element.
4. Follow listed procedures under "PRIMING."

# Maintenance Schedule

## Filter, Fuel p/n V04-00308

### Maintenance Schedule

#### Gaskets

Inspect for deterioration or tearing.

Weekly  
EVERY  
100 HRS

Remove and replace.

#### Bowls

Inspect rim of bowl to insure it is free of nicks, cracks, or scratches.

#### Filter Element

Inspect for damage or deterioration.

Remove and replace.

#### Fuel Bowl

If contaminants are found, check more frequently.



### PART LIST

ITEM	PART NUMBER	PART DESCRIPTION	QTY
1	V04-00308-02	Housing, Upper	1
2	V04-00308-07	Assembly, Drain	1
3	V04-00308-K	Bowl, Amber – 3"	1
4	V04-00308-01	Element, Filter	1
5	V04-00308-05	O-Ring – 3/32CS x 2 1/2ID	1
6	V04-01300-08	O-Ring – 1/16CS x 5/16ID	1
7	-----	Plug, Pipe	1
8	V04-00308-03	Ring, Flat	1
9	V04-00308-K	Kit, Replacement Bowl	1
10	V04-00308-04	Vent Plug & O-ring	1

## Troubleshooting

Trouble	Possible Cause	Remedy
<b>Fuel bowl leaking</b>	Deteriorated gasket	Remove and
	Housing cracked	Remove and replace housing
	Bowl rim cracked, nicked, or scratched	Remove and replace bowl
	Gasket missing	Replace gasket
	Loose fuel bowl	Tighten fuel bowl onto filter
<b>Air leaking into system (indicated by air bubbles in bowl during operation)</b>	Cracked component	Inspect filter bowl, filter housing, and gasket
	Loose filter bowl	Tighten fuel bowl onto fuel filter
	Loose valve assembly	Tighten valve assembly

# Burner Maintenance

## Fuel Filter, Adjustment Air Band , Fuel Pressure

### Air Band Adjustment

Note: The air band adjustment on this burner has been preset at the factor (elevation approximately 1400 feet). On equipment installed where elevation is substantially different, the air band(s) must be readjusted.

1. Loosen the cap screw retaining the air bands.
2. Move the air bands as indicated below with the machine in operation. Note: The air band should be set so the exhaust gives the smoke spot specified in the GENERAL section of the MACHINE SPECIFICATIONS on a Shell-Bacharach scale. If a smoke tester is not available, a smoky exhaust, oily odor, or sweet smell indicates insufficient air while eye-burning fumes indicate too much air.
3. Tighten the cap screw retaining the air bands.


### Fuel Pump Filter

Suntec Pump

1. Shut off fuel supply.
2. Loosen the 4 screws holding the cover to the fuel pump housing.
3. Take cover and cover gasket off and pull strainer off of pump housing.
4. Clean out any dirt remaining in the bottom of strainer cover. If there is evidence of rust inside of the unit, be sure to remove water in supply tank and fuel filter.
5. Turn on fuel supply. Failure to do so will result in fuel pump damage.

### Fuel Pump Pressure Adjustment


1. Install a 0-200 PSI Pressure Gauge.
2. Remove Plug on top of the fuel pump.
3. Insert a 1/8" Allen Wrench and turn clockwise to increase pressure and counter clockwise to decrease.
4. Remove Gauge and reinstall plug.



# Blower Fan Replacement, Transformer Test, Bus Bar Alignment

## Blower Fan Replacement

1. Shut off power to the burner and disconnect wires.
2. Loosen the two screws securing blower motor and fan to the housing.
3. Remove the blower.
4. Install the blower onto the shaft and place .030 feeler gauge on the motor as shown, sliding blower until it contacts feeler the gauge. Rotate wheel until set screw is centered on the flat of the motor shaft. Tighten set screws onto motor shaft.
5. Reinstall motor and blower assembly.
6. Reconnect wires and turn on power.



## Transformer Test

1. Remove burner junction box cover.
2. Turn on burner and make sure ignition transformer is receiving rated voltage.
3. Turn off burner.
4. Loosen screw and swing transformer away from burner gun assembly.
5. Turn on burner.
6. Short the high voltage terminals.
7. Open gap by drawing screwdriver away from one electrode while touching the other.
8. The spark should jump between 5/8 inches and 3/4 inches, if it doesn't jump, replace the transformer.
9. Turn burner off.
10. Partially close transformer. Check if buss bars align and contact transformer electrodes. If buss bars do not contact, see Buss Bar Alignment.
11. Close transformer, reposition retainer clip and tighten




## WARNING

Use screwdriver with a well insulated handle to avoid shock.



CORRECT



INCORRECT

## Buss Bar Alignment

1. With burner off, loosen screw and swing the transformer away from burner gun assembly.
2. Inspect the buss bars and transformer electrodes for pitting or corrosion.
3. Partially close the transformer. Check if the buss bars contact and are in alignment with transformer electrodes.
4. Proper adjustment is obtained by gently bending the buss bars until they spring against, parallel, and are in full contact with the transformer electrodes.
5. With buss bars aligned, carefully close and fasten the transformer.

# Burner Gun Removal & Replacement, Accessories, Electrode Adjustment

## Burner Gun Removal & Installation

1. Disconnect the fuel line from the burner gun assembly oil line fitting. Loosen the other end of the line and swing line out of the way.
2. Remove the retaining nut.
3. Loosen screw and swing transformer away from burner gun assembly.
4. Carefully remove the burner gun assembly.
  - 1) Check and replace electrode insulators if cracked.
  - 2) Clean burnt buss bars.
  - 3) Clean carbon off electrodes.
  - 4) Clean carbon off oil nozzle (use caution not to scratch face of nozzle or orifice).
  - 5) Check for a loose oil nozzle. Note: Check with dealer and/or replace nozzle with proper nozzle.
5. Gently replace burner gun assembly in air tube. CAUTION: Do not force. Forcing will cause electrode misalignment.
6. Reinstall the retaining nut.
7. Reinstall the oil line making sure both ends are tight.
8. Partially close transformer. Check if buss bars align and contact the transformer electrodes. If buss bars do not contact, see Buss bar Alignment.
9. Close transformer, reposition retainer and tighten screw.

## Accessories

p/n Y01-00041	Gauge-0- 200 PSI
p/n Z09-00004	Bacharach Smoke Tester
p/n Y01-00090	Allen Wrench 1/8" #8
p/n z01-00092	Fuel Nozzle Changing Wrench



**Z01-00095**

## Electrode Assembly Adjustment

1. Loosen screws holding electrode assemblies.
2. Raise electrode tips 5/32" above surface plane or end of oil nozzle.
3. Place each electrode tip 5/16" from center of spray nozzle hole, maintaining previous measurement.
4. Spread electrode tips to 1/8" gap maintaining previous measurements.
5. When the proper measurements are obtained, gently tighten screws that hold electrode assembly in place. CAUTION: Do not over tighten, as this will cause the electrode insulator to fail.






FIGURE 1

# Burner Breakdown

V00-173140



V-30537-011





# Burner Parts List

## Burner Breakdown Parts List

### p/n V00-173140

**20130502**

Item	Part No.	Description			
			*16	V-21723-014	Cover, Housing – Rear Hinge
1	V-101126-002	Kit, Motor/Adapter	17	V-101256-001	Gasket, Cover – Rear Hinge
1A	V-21993-006	Motor, EI.-12VDC 3900 RPM	18	H04-31301	Screw, Self Tap
1B	---	Adapter, Motor	19	V04-00401	Detector, Cad Cell
1C	---	Bushing	20	V-12689	Plug
1D	V-101119-001	Coupling, Shaft	21	V00-13392	Cover, Slot
2	H04-19000	Screw, Self Tap	22	V00-14296	Nut, Lock – Oil Line
3	V00-101317001	Fan, Burner w/ Set Screw	23	V00-14452-1	Line, Oil
4	H04-31302	Screw, Set	24	H04-31313	Screw, Cap
5	V-100603	Screw	25	V-101119-001	Coupling, Shaft
6	V-62899-001	Cover, Control Box	26	V00-14283	Pump, Fuel
7	H04-19010	Screw, Machine	27	V00-13494-1	Elbow, Flare
8	V-63355-001	Box, Control – Side Mount	28	V-20602-002	Band, Air – Outer
*9	V-100732-001	Spring, Comp. (w/V00-99006)	29	V-20601-002	Band, Air – Inner
*10	V-101308-001	Igniter, 12V (w/V00-99006)	30	V-21866-002	Assembly, Housing
*11	V-100603-016	Screw, Self Tap	31	V-30537-011	Assembly, Gun
*12	V-100730-003	Mount, Igniter	32	V-22044-004	Air Tube
*13	V-100603-015	Screw, Self Tap (w/V0099006)	33	V00-14160	Cone, Air - #4A
14	V-100889-002	Timer, Igniter – 12V	34	V00-12484	Gasket
*15	V00-12694	Screw, Machine	35	V00-12699	Screw, Air Cone
			*	V00-99006	Kit, 12V Igniter

## Burner Gun Breakdown Parts List

### p/n V-30537-011

Item	Part No.	Description			
			7	V-100598-002	Ass'y, Electrode – LH
1	V-100597-002	Ass'y, Electrode – RH	*7A	-----	Stem, Electrode – LH
*1A	---	Stem, Electrode – RH	7B	V00-12574	Insulator, Electrode
1B	V00-12574	Insulator, Electrode	7C	V-13499-002	Bar, Buss – T
1C	V-13499-002	Bar, Buss – T	7D	V00-13110	Nut, Pal
1D	V00-13110	Nut, Pal	8	V00-13409	Plate, Baffle – 2 1/2"
2	V00-12408	Bushing, Insulator	9	V00-14310	Support, Electrode
3	V00-12694	Screw, machine	10	V00-14442	Spring, Electrode Support
4	H04-19002	Screw, Set	11	H04-16400	Screw, Thread Cutting
5	V00-12695	Screw, Machine	12	V00-12362	Adapter, Nozzle
6	-----	Assembly, Oil Pipe – 7"			

# Troubleshooting

## Pump

Trouble	Possible Cause	Remedy
Oil leaking in the area of water pump crankshaft	Worn crankshaft seal, bad bearing, grooved shaft, or failure of retainer o-ring.	Remove and replace.
Excessive play on crankshaft	Defective bearings.	See "Worn bearing."
	Excess shims.	Set up crankshaft.
Loud knocking in pump	Loose connecting rod screws.	Tighten connecting rod screws per PUMP SPECIFICATIONS
	Worn connecting rod.	Replace connecting rod per PUMP MAINTENANCE.
	Worn bearings.	Replace bearings per PUMP MAINTENANCE.
	Loose plunger bushing screw.	Tighten plunger screw per PUMP SPECIFICATIONS.
Oil leaking at the rear portion of the pump	Damaged or improperly installed oil gauge window gasket or rear cover.	Replace gasket or o-ring.
	Oil gauge loosed.	Tighten oil gauge.
	Rear cover screws loose.	Tighten rear screws to torque values in PUMP SPECIFICATIONS.
	Pump overfilled with oil, displaced through crankcase breather hole in oil cap/dipstick.	Drain oil. Refill to recommended oil level as stated in OIL LEVEL in PUMP MAINTENANCE.
Water in crankcase	May be caused by humid air condensing into water inside.	Maintain or step up lubrication schedule.
	Worn or damaged plunger screw o-ring.	Remove and replace. See PLUNGER SERVICE in PUMP MAINTENANCE.
Worn bearing	Excessive belt tension.	See BELT TENSION in MACHINE MAINTENANCE.
	Oil contamination.	Check oil type and change intervals per PUMP SPECIFICATIONS.
Short bearing life	Excessive belt tension.	See BELT TENSION in MACHINE MAINTENANCE.
	Misalignment between pump and motor.	Re-align pump and motor.
	Oil has not been changed on regular basis.	Check oil type and change intervals per PUMP SPECIFICATIONS.
Short seal life	Damaged plunger bushing.	Replace plunger bushing.
	Worn connecting rod.	Replace connecting rod.
	Excess pressure beyond the pump's maximum rating.	Match pressure stated in PUMP SPECIFICATIONS.
	High water temperature.	Lower water temperature stated in PUMP SPECIFICATIONS.

Dirty or worn check valves	Normal wear.	Remove and replace.
	Debris.	Check for lack of water inlet screens.
Presence of metal particles during oil change	Failure of internal component.	Remove and disassemble to find probable cause.
	New pump.	New pumps have machine fillings and debris and should be drained and refilled per PUMP SPECIFICATIONS.
Water leakage from under head	Worn packing.	Install new packing.
	Cracked/scored plunger.	Remove and replace plunger.
	Failure of plunger retainer o-ring.	Remove and replace plunger retainer o-ring.
Loud knocking noise in pump	Pulley loose on crankshaft.	Check key and tighten set screw.
	Defective bearing.	Remove and replace bearing.
	Worn connecting rod, crankshaft, or crosshead.	Remove and replace.
Frequent or premature failure of the packing	Scored, damaged, or worn plunger.	Remove and replace plungers.
	Overpressure to inlet manifold.	Reduce inlet pressure.
	Abrasive material in the fluid being pumped.	Install proper filtration on pump inlet pumping.
	Excessive pressure and/or temperature of fluid being pumped.	Check pressures and fluid inlet temperature. Be sure they are within specified range.
	Over pressure of pumps.	Reduce pressure.
Running pump dry.	Do not run pump without water.	
Low Pressure	Dirty or worn check valves.	Clean/replace check valves.
	Worn packing.	Remove and replace packing.
	Belt slipping.	See BELT TENSION in MACHINE MAINTENANCE.
	Improperly sized spray tip or nozzle.	See MACHINE SPECIFICATIOSON for specified spray tip or nozzle.
	Inlet filter screen is clogged.	Clean inlet filter screen.
	Pitted valves.	See VALVE SERVICE in PUMP MAINTENANCE.
Erratic pressure; pump runs rough	Dirty or worn check valves.	Clean/replace check valves.
	Foreign particles in valve assemblies.	
	High inlet water temperature.	See temperature in PUMP SPECIFICATIONS.

Excessive vibration	Dirty or worn check valves	See "Dirty or worn check valves."
Scored plungers	Abrasive material in fluid being pumped.	Install proper filtration on pump inlet plumbing.
Fitted plungers	Cavitation.	Decrease inlet water temperature and/or increase inlet water pressure.
Cavitation	High inlet fluid temperature, low inlet pressure.	Lower inlet fluid temperature and raise inlet fluid pressure.

## Burner

Trouble	Possible Cause	Remedy
Burner will not ignite	Electrodes out of alignment.	See "ADJUSTING ELECTRODE ASSEMBLY" in BURNER MAINTENANCE SECTION.
	Electrode insulator failure.	Remove and replace if there are breaks, cracks, or spark trails.
	Water flow switch not closing.	Adjust, repair, or replace switch.
	Vacuum switch not closing.	Adjust, repair, or replace switch.
	Temperature control switch not closing.	Adjust or replace the TEMPERATURE CONTROL.
	Fuel solenoid valve not opening.	Clean, repair, or replace solenoid.
	Weak transformer.	Clean and check transformer terminals. Check transformer for spark pre "TRANSFORMER TEST" in BURNER MAINTENANCE SECTION.
	Faulty cad cell (if equipped).	Clean and test cad cell, replace if required.
	Faulty primary control (if equipped).	Replace primary control.
	Burner motor thermal protector locked out.	See "Burner motor thermal protector locked out."
	Wiring.	All wire contacts are to be clean and tight. Wire should not be cracked or frayed.
	Burner switch.	Test switch operation. Remove and replace as necessary.
	Pump pressure.	See "Low fuel pressure."
	Venting.	A downdraft will cause delayed ignition. Soot deposits on the coil and burner can interrupt air flow, and cause shorting of the electrodes. Clean as required.
	Sooting.	Soot deposits on the coil and burner can interrupt air flow, and cause shorting of the electrodes. Clean as required.
	No fuel.	See "No fuel."

No fuel	Clogged fuel filter.	Remove and replace filter per FUEL FILTER SECTION.
	Fuel leak.	Repair as necessary.
	Kinked or collapsed fuel line.	Remove and replace fuel line.
	Low fuel pressure.	See "Low fuel pressure."
	Faulty burner oil pump.	Adjust pressure or replace.
	Air leak in intake lines.	Tighten all fittings.
	Clogged burner nozzle.	Remove and replace (do not clean).
Low fuel pressure	Clogged fuel filter.	See "No Fuel."
	Clogged fuel pump filter screen.	Remove pump cover and clean strainer using a brush and clean fuel oil, diesel oil or kerosene.
	Fuel oil too viscous.	Operate a lighter oil or in warmer area.
	Air leaks in intake lines.	Tighten all fittings.
	Kinked or collapsed fuel line.	Remove and replace.
	Burner shaft coupling slipping.	Remove and replace.
	Fuel nozzle worn.	Remove and replace with specified nozzle on BURNER ASSEMBLY.
	Faulty oil pump.	Remove and replace.
Pulsating pressure	Partially clogged fuel pump strainer or filter.	Remove and replace strainer per FUEL PUMP FILTER in OIL BURNER MAINTENANCE section.
	Air leaking around fuel pump cover.	Check fuel pump cover screws for tightness and damaged gasket.
Unit smokes	Improper fuel.	Refuel with FUEL specified on MACHINE SPECIFICATIONS.
	Air to burner insufficient.	See AIR BAND ADJUSTMENT in OIL BURNER MAINTENANCE section.
	Fuel nozzle interior loose.	Replace nozzle.
	Water in fuel	Inspect fuel filter for water presence.
	Gun out of alignment.	Bend oil pipe to center burner nozzle.
Burner motor thermal protector kicked out	Low voltage.	Voltage must match those specified in the BURNER section of MACHINE SPECIFICATIONS section.
	Fuel too viscous.	See "Low fuel pressure."
	Fuel pump defective.	Check that fuel pump turns freely.
	Motor defective.	Call service technician or take motor to repair/warranty station.

Delayed ignition (rumbling, noise starts)	Dirty or damaged electrodes.	Clean or replace.
	Air adjustment open too far.	Readjust per AIR BAND ADJUSTMENT in OIL BURNER MAINTENANCE section.
	Poor fuel spray pattern.	Remove and replace with fuel nozzle specified in BURNER ASSEMBLY.
	Incorrect electrode setting.	Readjust per ADJUSTING ELECTRODE ASSEMBLY in OIL BURNER MAINTENANCE section.
	Weak transformer.	See TRANSFORMER CHECK on OIL BURNER MAINTENANCE section.
Burner does not electrically come on	Burner motor reset button tripped.	Reset if necessary. CAUTION: Do not keep hitting the "reset" button if you have oil pressure you are just filling the burner combustion chamber with oil and if ignited will cause an explosion.
	High limit temp control reset tripped if so equipped.	Reset if necessary.

## Water Heater

<b>Trouble</b>	<b>Possible Cause</b>	<b>Remedy</b>
Machine will not rise to operating temperature	Low fuel pressure.	See BURNER on MODEL SPECIFICATIONS for specified pressure.
	Water in fuel piping.	Drain fuel tank and remove and replace filter per FUEL FILTER INSERT.
	Fuel filter clogged.	Remove and replace fuel filter element per FUEL FILTER INSERT.
	Poor combustion.	See "Poor combustion."
	Improper fuel supply.	Use fuel specified in BURNER section of the MODEL SPECIFICATIONS.
	Temperature control inoperative (if equipped).	See TEMPERATURE CONTROL INSERT.
Machine overheats	Insufficient water.	See "Low operating pressure" on MACHINE TROUBLESHOOTING insert.
	Temperature control inoperative.	See TEMPERATURE CONTROL INSERT.
	Improper fuel supply.	Use fuel specified in BURNER section of the MODEL SPECIFICATIONS.
Dry steam (very little moisture, very hot steam)	Insufficient water.	See "Low operating pressure" on MACHINE TROUBLESHOOTING insert.
	Improper fuel supply.	Use fuel specified in BURNER section of the MACHINE SPECIFICATIONS.
	Improper fuel pressure.	See BURNER on MODEL SPECIFICATIONS for specified pressure.

# Water Heater

Machine smokes (sweet smelling exhaust)	Improper fuel supply.	Use fuel specified in BURNER section of MODEL SPECIFICATIONS.
	Insufficient combustion air.	See AIR BAND ADJUSTMENT on OIL BURNER MAINTENANCE insert.
	Leaking fuel system.	Correct leakage problem.
	Clogged or improper burner nozzle.	Remove (DO NOT CLEAN) and replace nozzle per BURNER ASSEMBLY INSERT.
	Loose burner nozzle.	See BURNER MAINTENANCE insert.
Machine fumes (exhaust burns eyes)	Too much combustion air.	See BURNER TROUBLESHOOTING insert.
	Improper fuel pressure.	See FUEL on MODEL SPECIFICATIONS for specified pressure.
Excessive oil dripping from laydown coil condensate.	Loose nozzle.	See BURNER TROUBLESHOOTING insert.
	Fuel pressure too high.	See FUEL PRESSURE ADJUSTMENT section on BURNER MAINTENANCE insert.
	Burner nozzle defective.	Remove and replace with appropriate nozzle found on the BURNER ASSEMBLY or BREAKDOWN insert.
	Incorrect burner nozzle.	Remove and replace with appropriate nozzle found on the BURNER ASSEMBLY or BREAKDOWN insert.
Poor combustion	Low fuel pressure.	See "Low fuel pressure" on BURNER TROUBLESHOOTING insert.
	Improper fuel supply.	See "Low fuel pressure" on BURNER TROUBLESHOOTING insert.
	Insufficient combustion air.	See AIR BAND ADJUSTMENT section on OIL BURNER MAINTENANCE.

# Warranty

## Warranty Policy

Machines are guaranteed to be free from defects in material or workmanship under normal use and service for period of one year after delivery from the factory. Any part (other than vendor items) that is determined to be warranty will be repaired or replaced at **NO CHARGE** provided the warranty registration form is filled out in its entirety and the part is sent back freight prepaid. Any replacement parts accepted as warranty will be returned to you freight prepaid.

Our heating coil will carry a seven-year prorated warranty credit. The manufacturer will repair or replace the coil without charge for five years after delivery date from the factory for any defect in the coil that was caused by workmanship or defective steel. After the five years have expired, the credit will be prorated as follows:

First 5 years 100% Credit

Years 6 & 7 50% Credit

After 7 Years No Credit Allowed

All parts supplied to us by other manufacturers will be subject to their guarantee and warranty. Generators, motors, and engines are required by vendors to be repaired or replaced by authorized warranty repair stations. The manufacturer will assist you in locating warranty stations around the country in cases where that is necessary. Select items carry a six-month warranty such as unloaders, triggers guns, etc.

The manufacturer, at its option, will repair or replace defective parts only, and does not allow for field labor charges for removal, installation, analysis, travel expense, or special freight expenses incurred for replacement parts.

Warranty does not apply to normal wear and tear including, but not limited to, freezing damage, freight damage, damage caused by misuse or misapplication, chemical related failures, contaminated filters and screens, moisture related fuel pump failures, stuck check valves, pump packings or seals, nozzles or orifices, paint, hoses, and gauges.



# Evaporative Emission Control Warranty Statement

## YOUR WARRANTY RIGHTS AND OBLIGATIONS

The EPA and California Air Resources Board and Alkota Cleaning Systems is pleased to explain the evaporative emission control system's warranty on your 2017 small off-road engine equipment. New equipment that use small off-engines must be designed, built, and equipped to meet the stringent anti-smog standards. Alkota Cleaning Systems must warrant the evaporative emission control system on your small off-road engine for the period listed below provided there has been no abuse, neglect or improper maintenance of your equipment.

Your evaporative emission control system may include parts such as: fuel tanks, fuel lines, fuel caps, valves, canisters, filters, vapor hoses, clamps, connectors, and other associated components.

### MANUFACTURER'S WARRANTY COVERAGE:

This evaporative emission control system is warranted for two years. If any evaporative emission-related part on your equipment is defective, the part will be repaired or replaced by Alkota Cleaning Systems.

### OWNER'S WARRANTY RESPONSIBILITIES:

- As the small off-road engine equipment owner, you are responsible for performance of the required maintenance listed in your owner's manual. Alkota Cleaning Systems recommends that you retain all receipts covering warranty issues on your Evaporative system (tank, fuel cap-fuel line and canister) but Alkota Cleaning Systems cannot deny warranty solely for the lack of receipts.
- As the small off-road engine equipment owner, you should however be aware that Alkota Cleaning Systems may deny you warranty coverage if your fuel tank and related evaporative components have failed due to abuse, neglect, or improper maintenance or unapproved modifications.
- You are responsible for presenting your Evaporative components to an Alkota Cleaning Systems service center as soon as the problem exists. The warranty repairs should be completed in a reasonable amount of time, not to exceed 30 days. If you have a question regarding your warranty coverage, you should contact: Kenny Barnes(1-605-934-2222,Ext 1440)

### GENERAL EVAPORATIVE EMISSIONS WARRANTY COVERAGE

The evaporative emissions warranty period begins on the date the engine or equipment is delivered to an ultimate purchaser. Alkota Cleaning Systems warrants to the ultimate purchaser and each subsequent purchaser that the engine is designed, built, and equipped so as to conform with all applicable regulations adopted by the Air Resources Board; and free from defects in materials and workmanship that cause the failure of a warranted part to be identical in all material respects to the part as described in the manufacturer's application.

### THE WARRANTY ON EVAPORATIVE EMISSIONS RELATED PARTS IS AS FOLLOWS:

- (1) Any warranted part that is not scheduled for replacement as required maintenance is warranted for the warranty period stated above. If any such part fails during the period of warranty coverage, the part will be repaired or replaced by Alkota Cleaning Systems at no charge to the owner. Any such part repaired or replaced under the warranty will be warranted for the remaining warranty period.
- (2) Any warranted part that is scheduled only for regular inspection is warranted for the warranty period stated above. Any such part repaired or replaced under warranty will be warranted for the remaining warranty period.
- (3) Any warranted part that is scheduled for replacement as required maintenance is warranted for the period of time prior to the first scheduled replacement point for that part. If the part fails prior to the first scheduled replacement, the part will be repaired or replaced by (the manufacturer) at no charge to the owner. Any such part repaired or replaced under warranty will be warranted for the remainder of the period prior to the first scheduled replacement point for the part.
- (4) Add-on or modified parts that are not exempted by the Air Resources Board may not be used. The use of any non-exempted add-on or modified parts by the ultimate purchaser will be grounds for disallowing a warranty claim. The manufacturer will not be liable to warrant failures of warranted parts caused by the use of a non-exempted add-on or modified part.

#### a) **Evaporative Emission Warranty Parts List:**

**Fuel tank**  
**Fuel cap**  
**Carbon canister**  
**Fuel line**

**Alkota Cleaning Systems,  
Inc.  
105 Broad Street  
Alcester, South Dakota, USA  
57001  
phone: 1-800-255-6823  
fax: 1-800-325-5682  
email: [info@alkota.com](mailto:info@alkota.com)  
web: [www.alkota.com](http://www.alkota.com)**



**Check us out on  
Facebook for updates  
and info**

**For full warranty information, contact your delivering distributor or contact the manufacturer at [info@warrantysvc.com](mailto:info@warrantysvc.com)**

