



Click Here To View  
Item at

[www.GapPower.com](http://www.GapPower.com)

*Sales • Rentals  
Parts & Service*

<b>Item ID</b>	<b>Item Description</b>	<b>Note</b>
VAL-KSL-B-01	BURNER CONE	
VAL-KSL-B-02	BURNER FLANGE	
VAL-KSL-B-03	DIFFUSER GASKET	
VAL-KSL-B-04	NOZZLE	0.85G
VAL-KSL-B-04A	NOZZLE	0.75G 2-STEP, SAME AS EPX-2-06A
VAL-KSL-B-05	WHIRL VANE	
VAL-KSL-B-06	ELECTRODE COVER	
VAL-KSL-B-06A	ELECTRODE COVER	
VAL-KSL-B-07A	ELECTRODE	
VAL-KSL-B-08	DIFFUSER	
VAL-KSL-B-09	NOZZLE NIPPLE	
VAL-KSL-B-10A	BURNER BASE	
VAL-KSL-B-10B	BURNER BASE	2-STEP ONLY
VAL-KSL-B-11	FLAME MONITOR SENSOR ONLY	
VAL-KSL-B-12B	FUEL PUMP W/ AIR VENT VALVE	
VAL-KSL-B-12C	FUEL PUMP W/ AIR VENT VALVE	2-STEP ONLY
VAL-KSL-B-13	FUEL FILTER COMPLETE	
VAL-KSL-B-14	FILTER ELEMENT	
VAL-KSL-B-15	FILTER NIPPLE	
VAL-KSL-B-16	PUMP BRACKET	
VAL-KSL-B-16A	PUMP BRACKET	From I
VAL-KSL-B-16B	PUMP BRACKET	2-STEP ONLY
VAL-KSL-B-17A	FUSE (3A)	
VAL-KSL-B-18	FUSE HOLDER	
VAL-KSL-B-18A	FUSE HOLDER	From Q-03

VAL-KSL-B-19B	POWER CABLE	
VAL-KSL-B-20B	CABLE STOPPER	
VAL-KSL-B-21	FUEL OUTLET LINE	
VAL-KSL-B-21A	FUEL OUTLET LINE	2-STEP ONLY
VAL-KSL-B-22	PUMP NOZZLE GROMMET	
VAL-KSL-B-23	FAN MOTOR	
VAL-KSL-B-23A	FAN MOTOR	2-STEP ONLY
VAL-KSL-B-24	STEP DOWN TRANSFORMER	
VAL-KSL-B-25B	BURNER CONTROL	
VAL-KSL-B-25C	BURNER CONTROL	From J-04 3 LED KBE5S
VAL-KSL-B-25D	BURNER CONTROL	2-STEP ONLY
VAL-KSL-B-26	BURNER CONTROL COVER	
VAL-KSL-B-26A	BURNER CONTROL COVER	2-STEP ONLY
VAL-KSL-B-27	IGNITION TRANSFORMER	
VAL-KSL-B-28	BURNER CONTROL CHASSIS	
VAL-KSL-B-28A	BURNER CONTROL CHASSIS	2-STEP ONLY
VAL-KSL-B-29	SWITCH ASSEMBLY	
VAL-KSL-B-30	CONTROL SUPPORT	
VAL-KSL-B-31	SHORT CIRCUIT CORD	
VAL-KSL-B-31V	SHORT CIRCUIT CORD	
VAL-KSL-B-32	FACE PLATE	
VAL-KSL-B-32A	FACE PLATE FOR 3 LED	3 LED KBE5S

VAL-KSL-B-32B	FACE PLATE FOR 2 STEP	2-STEP ONLY
VAL-KSL-B-33	BURNER COVER	
VAL-KSL-B-33V	PLASTIC BURNER COVER	
VAL-KSL-B-34	AIR VENT VALVE	
VAL-KSL-B-35	RETURN LINE	
VAL-KSL-B-35A	RETURN LINE	2-STEP ONLY
VAL-KSL-B-36	RETURN LINE NIPPLE	
VAL-KSL-B-37	NIPPLE FITTING NUT	
VAL-KSL-B-38-2	NOZZLE WRENCH	
VAL-KSL-B-38A	REPAIR SET (NEW)	
VAL-KSL-B-38B	O-RING FOR FUEL BOWL	
VAL-KSL-B-39	FUSE HOLDER BRACKET	
VAL-KSL-B-39A	FUSE HOLDER BRACKET	2-STEP ONLY
VAL-KSL-B-43	THERMOSTAT CABLE	
VAL-KSL-B-44	TIP OVER SWITCH	
VAL-KSL-B-45	TIP OVER SWITCH BRACKET	
VAL-KSL-B-46	TIP OVER SWITCH CABLE	
VAL-KSL-B-47	FLAME MONITOR HOLDER ONLY	
VAL-KSL-B-48	CAHNGE OVER SWITCH	2-STEP ONLY
VAL-KSL-B-49	WORE BINDING	2-STEP ONLY
VAL-KSL-B-50	HOSE CLAMP	2-STEP KSL-T-25 OR EPX-2-26
VAL-KSL-B-51	FUEL FILTER HEATER COMPLETE	2-STEP ONLY
VAL-KSL-HEATER	FUEL FILTER HEATER BOTTOM ONLY	
<b>Item ID</b>	<b>Item Description</b>	<b>Note</b>
VAL-KSL-NUT-BURNER	M8 NUT	

VAL-KSL-R-01	RADIATION DISK	
VAL-KSL-R-02	CONICAL INSULATOR	
VAL-KSL-R-03	CONICAL HOUSING	
VAL-KSL-R-03A	CONICAL HOUSING KL	
VAL-KSL-R-04	CAUTION LABEL PLATE	
VAL-KSL-R-05	BURNER FITTING PIECE	
VAL-KSL-R-06	BURNER GASKET	
VAL-KSL-R-07	BURNER SUPPORT	
VAL-KSL-R-08	VISOR	
VAL-KSL-R-09	PROTECTOR ASSEMBLY-KL	
VAL-KSL-R-10	RETAINER PLATE	
VAL-KSL-R-11	VISOR FITTING PIECE	
VAL-KSL-SCREW-COVER	SCREWS FOR PLASTIC COVER	
VAL-KSL-SCREW-GUARD	SCREW FOR GUARD	
VAL-KSL-SCREW-RAD	SCREW FOR RADIATION DISK	
VAL-KSL-T-01	PROTECTOR ASSEMBLY	
VAL-KSL-T-02	PROTECTOR SUPPORT	
VAL-KSL-T-02V	PROTECTOR SUPPORT	
VAL-KSL-T-04	FRAME-R-KS	
VAL-KSL-T-04A	FRAME-R-KL	From G-02
VAL-KSL-T-04V	FRAME-R-KL	
VAL-KSL-T-05	FRAME-L-KS	
VAL-KSL-T-05A	FRAME-L-KL	From G-02
VAL-KSL-T-05V	FRAME-L-KL	
VAL-KSL-T-06	FRAME CONNECTION PIPE	

VAL-KSL-T-06V	FRAME CONNECTION PIPE-KL	
VAL-KSL-T-07	KNOB	
VAL-KSL-T-08	HANDLE	
VAL-KSL-T-08V	HANDLE-KL	
VAL-KSL-T-09	PIPE END CAP	
VAL-KSL-T-09V	PIPE END CAP	
VAL-KSL-T-10	TANK LEG UPTO 2003/2004	
VAL-KSL-T-10A	TANK LEG	
VAL-KSL-T-10V	TANK LEG-KL	
VAL-KSL-T-11	WHEEL SHAFT	
VAL-KSL-T-11V	WHEEL SHAFT-KL	
VAL-KSL-T-12	WHEEL	
VAL-KSL-T-13	FUEL HOSE	2-STEP REQUIRE ONLY 1
VAL-KSL-T-14	RETURN NIPPLE	
VAL-KSL-T-14A	FLANGE CONNECTION	2-STEP ONLY
VAL-KSL-T-15	SUCTION GASKET	
VAL-KSL-T-16	SUCTION PIPE ASSEMBLY	For KS
VAL-KSL-T-16V	SUCTION PIPE ASSEMBLY-KL	For KL
VAL-KSL-T-17	FUEL GAUGE	For KS
VAL-KSL-T-17V	FUEL GAUGE-KL	For KL
VAL-KSL-T-18	TANK CAP	
VAL-KSL-T-19	TANK INLET FILTER	Discontinued from H-01
VAL-KSL-T-20	FUEL TANK	For KS
VAL-KSL-T-20V	FUEL TANK-KL	For KL
VAL-KSL-T-21	DRAIN GASKET	

VAL-KSL-T-22	DRAIN BOLT	Including T-21
VAL-KSL-T-23	GASKET	
VAL-KSL-T-24	PIPE CONNECTION	
VAL-KSL-T-24V	PIPE CONNECTION-KL	
VAL-KSL-T-25	HOSE CLAMP	KSL-B-50 OR EPX-2-26
VAL-MAT	HEAT SHIELD MAT	