

PART #		REMARKS
EPX-1-01	VISOR	
EPX-1-02	CAUTION LABEL PLATE	
EPX-1-03	CONICAL HOUSING ASSEMBLY	Include EPX-1-2
EPX-1-04	BURNER FITTING PIECE	
EPX-1-05	SUPPORT PIPE	
EPX-1-06	CONICAL INSULATOR	
EPX-1-07	RADIATION DISK	
EPX-1-08	KNOB BOLT	Same as KSL-T-7
EPX-1-09	WASHER	
EPX-1-10	PROTECTOR BRACKET(L)	
EPX-1-11	PROTECTOR BRACKET(R)	
EPX-1-12	PROTECTOR ASSEMBLY	
EPX-2-01	FUEL OUTLET LINE	
EPX-2-02	WHIRL VANE	
EPX-2-03	NOZZLE NIPPLE	
EPX-2-04	DIFFUSER	Same as KSL-B-8
EPX-2-05	ELECTRODE	Same as KSL-B-7A
EPX-2-06	NOZZLE	0.85G H Only
EPX-2-6A	NOZZLE	0.75G
EPX-2-07	DIFFUSER GASKET	Same as KSL-B-3
EPX-2-08	BURNER FLANGE	Same as KSL-B-2
EPX-2-09	BURNER CONE	Same as KSL-B-1
EPX-2-10	BURNER PACKING	
EPX-2-11	SPACER RING	
EPX-2-12	POWER CABLE	
EPX-2-13	ELECTRODE COVER	Same as KSL-B-6
EPX-2-14	PUMP NOZZLE GROMMET	
EPX-2-15	φ16 GROMMET	
EPX-2-16	RETURN LINE NIPPLE	
EPX-2-17	FUEL HOSE	L=450
EPX-2-18	BURNER BASE	
EPX-2-19	NIPPLE FITTING NUT	same as EPX-3-11
EPX-2-20	BASE GASKET	
EPX-2-22	FLAME MONITOR COMPLETE	
EPX-2-23	FAN MOTOR	
EPX-2-24	FUEL INTAKE LINE	
EPX-2-25	RETURN HOSE	
EPX-2-26	HOSE CLAMP	
EPX-2-27	FUEL PUMP WITH AIR VENT VALVE	
EPX-2-30	IGNITION TRANSFORMER	Same as KSL-B-27
EPX-2-31	PUMP TRANSFORMER BRACKET	
EPX-2-32	BURNER CONTROL COVER	
EPX-2-33	BURNER CONTROL BOARD	
EPX-2-34	CONTROL BOARD SUPPORT	Same as KSL-B-30
EPX-2-35	CONTROL BOARD SPACER	Same as NA-B-11
EPX-2-36	STEP DOWN TRANSFORMER	Same as KSL-B-24
EPX-2-37	OVERHEAT SENSOR	
EPX-2-38	OVERHEAT SENSOR CABLE	
EPX-2-39	TIP-OVER SWITCH	Same as KSL-B-44
EPX-2-40	FUSE HOLDER	Same as KSL-B-18A

EPX-2-41	FUSE	Same as KSL-B-17A
EPX-2-42	WIRE BINDING	
EPX-2-43	CONTROL BOARD CHASSIS	
EPX-2-44	NYLON CLAMP	
EPX-2-45	TEMPERATURE SENSOR	
EPX-2-46	INTERNAL THERMOSTAT CABLE	
EPX-2-47	OPERATION SWITCH CABLE	
EPX-2-48	CHANGE-OVER SWITCH	
EPX-2-49	OPERATION SWITCH	
EPX-2-50	INTERNAL THERMOSTAT KNOB	
EPX-2-51	EXTERNAL THERMOSTAT CONNECTOR	
EPX-2-52	OPERATING PANEL	
EPX-2-53	OPERATING BRACKET□	
EPX-2-54	BURNER COVER	
EPX-3-01	HANDLE	
EPX-3-02	HANDLE STAY BRACKET(L)	
EPX-3-03	HANDLE STAY BRACKET(R)	
EPX-3-04	FILTER HOSE NIPPLE	Same as KSL-B-15
EPX-3-05	STRAINER HEATER	
EPX-3-06	FILTER NIPPLE	
EPX-3-07	STRAINER HEATER RELAY CABLE	
EPX-3-08	O RING	Same as KSL-B-38
EPX-3-09	FILTER ELEMENT	Same as KSL-B-14
EPX-3-10	FILTER FITTING BRACKET	
EPX-3-11	NIPPLE FITTING NUT	same as EPX-2-19
EPX-3-12	SUCTION PIPE ASSEMBLY	
EPX-3-13	SUPPORT PIPE	
EPX-3-14	FUEL GAUGE	
EPX-3-15	TANK CAP	
EPX-3-16	SUCTION RETURN PLUG	Same as DS-T-05A
EPX-3-17	DRAIN BOLT GASKET	Same as KSL-T-21
EPX-3-18	DRAIN BOLT	Including EPX-3-17
EPX-3-19	FUEL TANK ASSEMBLY	
EPX-3-20	SIDE PANEL(L)	
EPX-3-21	SIDE PANEL(R)	
EPX-3-22	TANK SUPPORT BRACKET	
EPX-3-23	WHEEL BEARING ASSEMBLY	
EPX-3-24	WHEEL SPACER	
EPX-3-25	WHEEL	
EPX-3-26	WHEEL WASHER	
EPX-3-27	SHAFT CAP	
EPX-3-28	REPAIR SET	
EPX-3-29	NOZZLE WRENCH	Same as KSL-B-38-2
VAL-THERMO-01	EXTERNAL THERMOSTAT INSERT	
VAL-THERMO-02	EXTERNAL THERMOSTAT COVER	