




Click Here To View
Item at

www.GapPower.com

*Sales • Rentals
Parts & Service*





Parts Breakdown

6922NB

Products with multiple versions are listed in subsiding order with the newest version on top not indented

| <u>Fig #</u> | <u>Part ID</u> | <u>Part Name</u> | <u>Quantity</u> |
|--------------|----------------|---------------------------------|-----------------|
| 1 | 764361-9 | OUTER SLEEVE 20-37,6922NB | 1 |
| | 764320-3 | OUTER SLEEVE 20-37,6922NB | |
| 2 | 764419-4 | INNER SLEEVE 3/4-38, 6922NB | 1 |
| | 764351-2 | INNER SLEEVE 3/4-38,6922NB | |
| | 764325-3 | INNER SLEEVE 3/4-38,6922NB | |
| 3 | 165074-9 | CHIP ROD, 6922NB | 1 |
| 4 | 233444-1 | COMPRESSION SPRING 13, 6922NB | 1 |
| | 233087-9 | COMPRESSION SPRING 13, 6922NB | |
| 5 | 234143-8 | COMP. SPRING 25, 6922NB | 1 |
| | 233086-1 | COMP. SPRING, 6922NB | |
| 6 | 257940-5 | SPIRO LOCK WASHER 70, 6922NB-T2 | 1 |
| | 257919-6 | SPIRO LOCK WASHER 72, 6922NB | |
| 7 | 325688-8 | OUTER SUPPORT, 6922NB | 1 |
| | 324448-5 | OUTER SUPPORT, 6922NB | |
| | 322671-6 | OUTER SUPPORT, 6922NB | |
| 8 | 153872-3 | INNER SUPPORT CPL., 6922NB-T2 | 1 |
| | 152447-5 | INNER SUPPORT COMPLETE, 6922NB | |
| 9 | 211611-8 | BALL BEARING 6810, 6922NB | 1 |
| | 211653-2 | BALL BEARING 6811, 6922NB | |
| 10 | 310147-5 | CARRIER, 6922NB-T2 | 1 |
| | 311943-4 | CARRIER, 6922NB | |
| 11 | 212954-1 | NEEDLE CAGE 810, 6922NB-T2 | 4 |
| | 212072-5 | NEEDLE CAGE 1010, 6922NB | |
| 12 | 212954-1 | NEEDLE CAGE 810, 6922NB-T2 | 4 |
| | 212072-5 | NEEDLE CAGE 1010, 6922NB | |
| 13 | 227117-6 | SPUR GEAR 20, 6922NB-T2 | 4 |
| | 226272-1 | SPUR GEAR 20, 6922NB | |
| 14 | 216207-0 | WASHER 2542, 6922NB | 1 |
| 15 | 256228-0 | PIN 8, 6922NB-T2 | 4 |
| | 256229-8 | PIN 10, 6922NB | |
| 16 | 266022-2 | SCREW M8X8, 6922NB | 2 |
| 17 | 226269-0 | SPUR GEAR 25, 6922NB | 4 |
| 18 | 211044-7 | BALL BEARING 404, 6922NB | 4 |
| 19 | 226270-5 | SPUR GEAR 25, 6922NB | 4 |
| 20 | 212954-1 | NEEDLE CAGE 810, 6922NB-T2 | 4 |
| | 212027-0 | NEEDLE CAGE 811, 6922NB | |
| 21 | 226275-5 | SPUR GEAR 11, 6922NB | 1 |
| 22 | 256227-2 | PIN 8, 6922NB | 4 |
| 23 | 216207-0 | WASHER 2542, 6922NB | 1 |
| 24 | 226273-9 | SPUR GEAR 14, 6922NB | 1 |
| 25 | 256226-4 | PIN 4, LS1016L | 4 |
| 26 | 216403-0 | T.N. GAUGE 1528, 6922NB | 1 |
| | 216207-0 | WASHER 2542, 6922NB | |
| 27 | 227118-4 | INTERNAL GEAR 53-66, 6922NB-T2 | 1 |
| | 226277-1 | INTERNAL GEAR 53-66, 6922NB | |
| 28 | 233098-4 | COMPRESSION SPRING 4, 6922NB | 1 |
| 29 | 323855-9 | BRACKET, 6922NB | 1 |
| | 322667-7 | BRACKET, 6922NB | |
| 30 | 257929-3 | SPIRO LOCK WASHER 52, 6922NB | 1 |
| 31 | 257186-3 | RING 44, 6922NB | 1 |
| 32 | 211221-1 | BALL BEARING 6902,HR2511 | 1 |
| 33 | 911118-1 | P.H. SCREW M4X12, 6221D | 2 |
| 34 | 922123-3 | H.S.H. BOLT M4X14, 6922NB | 4 |
| 35 | 415353-8 | REAR COVER, 6922NB | 1 |
| 36 | 344062-1 | STOPPER PLATE, 6922NB | 1 |
| 37 | 311930-3 | ROD SUPPORTER, 6922NB | 1 |
| 38 | 211082-9 | BALL BEARING 699, 6922NB | 1 |
| 39 | 226812-5 | GEAR 14-41, 6922NB | 1 |



Parts Breakdown

6922NB

| | | | |
|----|----------|---------------------------------|---|
| 40 | 922123-3 | H.S.H. BOLT M4X14, 6922NB | 4 |
| 41 | 159930-3 | GEAR CASE COMPLETE, 6922NB | 1 |
| 42 | 263002-9 | RUBBER PIN 4, 5007MG | 1 |
| 43 | 210013-5 | BALL BEARING 698, 6922NB | 1 |
| 44 | 226475-7 | HELICAL GEAR 30, 6922NB | 1 |
| 45 | 212048-2 | THRUST NEEDLE, 6922NB | 1 |
| 47 | 211097-6 | BALL BEARING 6000LLB, 5740NB | 1 |
| 48 | 241873-4 | FAN 55, 6922NB | 1 |
| 49 | 517191-5 | ARMATURE ASS'Y 115V, 6922NB | 1 |
| 50 | 681614-0 | INS. WASHER, 9031 | 1 |
| 51 | 263014-2 | RUBBER PIN 4, 9217SPC | 1 |
| 52 | 211028-5 | B. BEARING 627LB, 6510LVR | 1 |
| 53 | 421485-1 | PROTECTOR, 6922NB | 1 |
| 54 | 643550-8 | BRUSH CAP , 9031 | 2 |
| 55 | CB408 | CARBON BRUSH SET, 195008-8 | 1 |
| | 195008-8 | CARBON BRUSH SET, 195008-8 | |
| | 191938-1 | CARBON BRUSH CB-408, 9501B-T1 | |
| 56 | 159675-3 | MOTOR HOUSING COMP., 6922NB | 1 |
| 57 | 922909-5 | H.S.H. BOLT M4X35, 6922NB | 4 |
| 58 | 922148-7 | H.S.H. BOLT M4X25, 6922NB | 4 |
| 59 | 134788-1 | GEAR HOUSING ASS'Y, 6922NB | 1 |
| 60 | 593266-4 | FIELD, 6922NB | 1 |
| 61 | 415350-4 | BAFFLE PLATE, 6922NB | 1 |
| 63 | 211031-6 | BALL BEARING 608LLB, 9227C | 1 |
| | 211033-2 | B. BEARING 608LB, 5007F | |
| 64 | 226476-5 | HELICAL GEAR 18, 6922NB | 1 |
| 65 | 211097-6 | BALL BEARING 6000LLB, 5740NB | 1 |
| 66 | 263002-9 | RUBBER PIN 4, 5007MG | 1 |
| 67 | 134790-4 | GEAR ASSEMBLY, 6922NB | 1 |
| 68 | 256225-6 | PIN 4, 6922NB | 1 |
| 69 | 911596-5 | P.H. SCREW M4X70, 6922NB | 2 |
| 70 | 857485-9 | NAME PLATE, 6922NB | 1 |
| 71 | 922148-7 | H.S.H. BOLT M4X25, 6922NB | 2 |
| 72 | 265925-7 | TAPPING SCREW BT4X20, 6201DW | 2 |
| 73 | 922148-7 | H.S.H. BOLT M4X25, 6922NB | 2 |
| 74 | 182634-2 | HANDLE SET, 6922NB | 1 |
| 76 | 265995-6 | TAPPING SCREW 4X18, BO4556K | 2 |
| 77 | 687052-4 | STRAIN RELIEF, 5007F | 1 |
| 78 | 651835-8 | SWITCH, 6920N | 1 |
| 79 | 414436-1 | SWITCH LEVER, 6922NB | 1 |
| 80 | 311928-0 | CHIP LEVER, 6922NB | 1 |
| 81 | 182634-2 | HANDLE SET, 6922NB | 1 |
| 82 | 682505-8 | CORD GUARD, 5007F | 1 |
| 83 | 664265-4 | CORD (2X16X8;SJ), 5007NBA | 1 |
| 84 | 819031-6 | MAKITA MARK, 6922NB | 1 |
| 85 | 819083-7 | N/A | 1 |
| 86 | 232146-6 | LEAF SPRING, 6922NB | 1 |
| 87 | 324447-7 | SPACER, 6922NB-T2 | 1 |
| | 322788-5 | SPACER, 6922NB | |
| 88 | 421497-4 | RUBBER RING, 6922NB | 1 |
| 89 | 257941-3 | SPIRO LOCK WASHER 62, 6922NB | 1 |
| 90 | 267282-9 | FLAT WASHER 60, 6922NB | 1 |
| | 153909-6 | OUTER SLEEVE 22-39 CPL., 6922NB | 1 |
| | 764360-1 | OUTER SLEEVE 22-39, 6922NB | |
| | 764319-8 | OUTER SLEEVE 22-39,6922NB | |
| | 764418-6 | INNER SLEEVE 22-39, 6922NB | 1 |
| | 764348-1 | INNER SLEEVE 22-39, 6922NB | |
| | 764322-9 | INNER SLEEVE 22-39,6922NB | |
| | 783001-0 | SLOTTED SCREWDRIVER, 2040 | 1 |
| | 823276-0 | STEEL CARRYING CASE, 6922NB | 1 |
| | 150479-6 | STEEL CARRYING CASE, 6922NB | |



Parts Breakdown

6922NB

810146-2

CAUTION LABEL, 6906

1