

Procedures and shortcuts ZONZINI DOMINO PLASMOID

https://youtu.be/l uHyrdibwck	 CALIBRATION PROCEDURE 1. Press to power the machine 2. Tie down the load 3. Press A to activate auto mode
https://youtu.be/1 HXixQTs6Yk	 FLOOR TO STAIRS – CLIMBING PROCEDURE 1. In auto mode, pull the joystick toward the stairs. The platform will adjust automatically. 2. When the machine is off the ground, it will switch to manual mode. Proceed up the stairs normally.
https://youtu.be/X u58LVBT0gc	 STOP At the edge of the landing Press for a few seconds to activate arms When the arms touch the landing, pull the joystick toward the operator When the tracks are completely on the landing, press to retract the arms



https://youtu.be/jr Act4ivxYE	<section-header><list-item><list-item><list-item><list-item><list-item></list-item></list-item></list-item></list-item></list-item></section-header>
https://youtu.be/B CwsrIORI-8	STAIR TO FLOOR – DESCENT PROCEDURE 1. When you reach the bottom of the stairs, the machine will switch to auto mode. The platform will adjust as you go down. Proceed normally until you are completely on the ground.
https://youtu.be/6 LTny59Ua8M	Scan the QR code for the complete training





